


User Guide

Vaisala Moisture, Hydrogen and Temperature Transmitter for Transformer Oil

MHT410



PUBLISHED BY

Vaisala Oyj
Vanha Nurmijärventie 21, FI-01670 Vantaa, Finland
P.O. Box 26, FI-00421 Helsinki, Finland
+358 9 8949 1

Visit our Internet pages at www.vaisala.com.

© Vaisala 2021

No part of this document may be reproduced, published or publicly displayed in any form or by any means, electronic or mechanical (including photocopying), nor may its contents be modified, translated, adapted, sold or disclosed to a third party without prior written permission of the copyright holder. Translated documents and translated portions of multilingual documents are based on the original English versions. In ambiguous cases, the English versions are applicable, not the translations.

The contents of this document are subject to change without prior notice.

Local rules and regulations may vary and they shall take precedence over the information contained in this document. Vaisala makes no representations on this document's compliance with the local

rules and regulations applicable at any given time, and hereby disclaims any and all responsibilities related thereto.

This document does not create any legally binding obligations for Vaisala towards customers or end users. All legally binding obligations and agreements are included exclusively in the applicable supply contract or the General Conditions of Sale and General Conditions of Service of Vaisala.

This product contains software developed by Vaisala or third parties. Use of the software is governed by license terms and conditions included in the applicable supply contract or, in the absence of separate license terms and conditions, by the General License Conditions of Vaisala Group.

Table of contents

1.	Safety	7
1.1	ESD protection.....	8
2.	About this document	9
2.1	Documentation conventions.....	10
2.2	Regulatory statements.....	10
2.2.1	FCC Part 15 compliance statement.....	10
2.3	Trademarks.....	11
3.	Product overview	12
3.1	Main features.....	12
3.2	Product parts and package contents.....	13
3.3	Measurement parameters and units.....	15
3.4	Oil types.....	16
3.4.1	Oil type information in order code.....	16
3.4.2	Oil-specific coefficients for ppm _w moisture measurement.....	16
3.5	Data logging.....	17
3.6	Status LEDs.....	17
4.	Installation	19
4.1	Planning the installation.....	19
4.1.1	Recommended installation locations.....	20
4.2	Mechanical installation.....	21
4.3	Electrical installation.....	28
4.4	Loop-powered display.....	31
4.4.1	Wiring the loop-powered display.....	32
4.5	Checklist after installation.....	33
4.6	Oil fittings check after installation.....	34
4.7	Removing the transmitter.....	34
4.8	Re-installing the transmitter in new location.....	35
5.	Analog output	37
5.1	Analog output overrange behavior.....	37
6.	Modbus	39
6.1	Overview of Modbus protocol support.....	39
7.	Vaisala Industrial Protocol	40
7.1	Connecting to MHT410 via service port.....	41
7.1.1	Installing driver for the USB service cable.....	41
7.1.2	Connecting USB service cable.....	42
7.1.3	Configuring terminal application settings.....	42
7.2	Serial commands summary.....	44
7.3	Device information and status commands.....	46

7.4	Serial line output and communication commands.....	52
7.4.1	Measurement output commands.....	52
7.4.2	Measurement output format commands.....	56
7.4.3	Serial line communication commands.....	59
7.5	Analog output commands.....	63
7.6	Calibration and adjustment commands.....	67
7.7	Other commands.....	68
8.	DNP3 protocol.....	71
8.1	Taking DNP3 protocol into use.....	71
9.	Vaisala MI70 Handheld Indicator.....	73
9.1	MI70 indicator overview.....	73
9.1.1	MI70 indicator parts.....	73
9.1.2	Basic display.....	74
9.1.3	Graphical display.....	74
9.1.4	Main menu.....	75
9.2	Installing and recharging MI70 batteries.....	75
9.3	Connecting MI70 to service port.....	76
9.4	Holding and saving the display.....	76
9.5	Recording data.....	77
9.5.1	Starting and stopping the recording.....	77
9.5.2	Viewing recorded data.....	78
9.5.3	Clearing data memory.....	78
9.6	Comparing readings with MM70 probe.....	78
9.7	Changing the rechargeable battery pack.....	79
10.	Vaisala Indigo520 Transmitter.....	81
10.1	Taking Indigo520 Modbus settings into use in MHT410.....	81
10.2	Cabling and cable gland.....	82
10.3	Indigo520 and MHT410 wiring diagram.....	83
10.4	MHT410 status messages shown in Indigo520.....	84
10.5	Settings in Indigo520.....	84
11.	Calibration and adjustment.....	85
11.1	H ₂ calibration and adjustment.....	85
11.1.1	Taking DGA sample and saving current H ₂ reading.....	85
11.1.2	Entering DGA H ₂ reading to transmitter.....	87
11.1.3	Clearing H ₂ calibration and adjustment.....	88
11.2	RS & T calibration and adjustment.....	89
12.	Troubleshooting.....	91
12.1	Error states.....	91
12.2	Changing bleed screw.....	92
13.	Technical data.....	93
13.1	MHT410 specifications.....	93
13.2	Spare parts and accessories.....	97

13.3	Dimensions.....	98
13.4	Wiring diagrams.....	99
13.5	Recycling.....	101
Appendix A: Operating principle.....		104
A.1	Method used for measuring moisture in oil.....	105
A.2	Transformer oil.....	105
Appendix B: Modbus reference.....		107
B.1	Default Modbus communication settings.....	107
B.2	Function codes.....	107
B.3	Data encoding.....	107
B.3.1	32-bit floating point or 32-bit integer format.....	108
B.3.2	16-bit integer format.....	108
B.4	Register map.....	108
B.5	Modbus registers.....	109
B.5.1	Measurement data registers.....	109
B.5.2	Status registers.....	111
B.6	Device identification objects.....	112
B.7	Exception responses.....	112
Appendix C: Moisture ppm_w calculation for transformer oils.....		113
C.1	Calculation model with average coefficients.....	113
C.2	Calculation model with oil-specific coefficients.....	113
Maintenance and calibration services.....		115
Technical support.....		115
Warranty.....		115

List of figures

Figure 1	MHT410 order code example (first digit 1 = mineral oil).....	16
Figure 2	Recommended installation locations.....	20
Figure 3	Loop-powered display 242003.....	32
Figure 4	Analog output overrange behavior.....	38
Figure 5	Analog output overrange behavior.....	64
Figure 6	MI70 indicator parts.....	73
Figure 7	MI70 basic display.....	74
Figure 8	Example of MI70 display with MHT410 in port I and MM70 probe in port II. Shown parameters: aw (I), aw (II), Δ aw.....	79
Figure 9	Wiring between Indigo520 and MHT410 screw terminals.....	83
Figure 10	MHT410 transmitter dimensions.....	98
Figure 11	Wiring Option 1: Wiring with four power supplies. Separate loop-powering and galvanic isolation for analog outputs. In transmitters ordered with Vaisala cable CBL210392-5M, the cable is pre-wired according to this option.....	99
Figure 12	Wiring Option 2: Wiring with two power supplies. Common loop-powering and galvanic isolation for analog outputs.....	100
Figure 13	Wiring Option 3: Wiring with one power supply. Non- isolated configuration for analog outputs sharing transmitter power supply.....	100
Figure 14	Wiring Option 4: Wiring with one power supply. Alternative wiring to option 3, providing reduced current loop area for analog outputs.....	101
Figure 15	Materials for recycling.....	102
Figure 16	Measuring hydrogen and moisture in oil with MHT410.....	104
Figure 17	Water solubility of transformer oils versus temperature. The margins show the range of variation of water solubility found in mineral oils.....	106

List of tables

Table 1	Document versions (English).....	9
Table 2	Related manuals.....	9
Table 3	Analog output values in different transmitter statuses.....	37
Table 4	Default serial interface settings.....	40
Table 5	Service port serial interface settings.....	43
Table 6	Serial commands.....	44
Table 7	? command.....	46
Table 8	alarm command.....	47
Table 9	errlog command.....	48
Table 10	errs command.....	49
Table 11	help command.....	50
Table 12	system command.....	50
Table 13	time command.....	51
Table 14	vers command.....	51
Table 15	intv command.....	52
Table 16	log command.....	52
Table 17	r command.....	55
Table 18	send command.....	55
Table 19	form command.....	56
Table 20	Output parameters for form command.....	57
Table 21	Modifiers for form command.....	58
Table 22	unit command.....	59
Table 23	addr command.....	59
Table 24	close command.....	60
Table 25	open command.....	60
Table 26	sdelay command.....	60
Table 27	seri command.....	61
Table 28	smode command.....	62
Table 29	aerr command.....	63
Table 30	aover command.....	63
Table 31	asel command.....	64
Table 32	atest command.....	66
Table 33	cdate command.....	67
Table 34	ctext command.....	67
Table 35	h2 da and h2 db commands.....	68
Table 36	h2 x command.....	68
Table 37	dnp3 addr command.....	68
Table 38	filt command.....	69
Table 39	frestore command.....	69
Table 40	reset command.....	70
Table 41	oil command.....	70
Table 42	h2 is command.....	70
Table 43	Default communication settings.....	71
Table 44	MHT410 communication settings for Indigo520.....	81
Table 45	MHT410 status messages shown in Indigo520.....	84

Table 46	Possible error messages via Vaisala Industrial Protocol.....	91
Table 47	MHT410 measurement performance.....	93
Table 48	MHT410 operating environment.....	94
Table 49	MHT410 inputs and outputs.....	94
Table 50	MHT410 mechanical specifications.....	95
Table 51	MHT410 compliance.....	96
Table 52	Display with relays (external option).....	96
Table 53	MHT410 spare parts and accessories.....	97
Table 54	Vaisala cable CBL210392-5M wire colors (when pre-wired).....	99
Table 55	Materials for recycling.....	103
Table 56	Optimal sensor positions.....	104
Table 57	Default Modbus RTU communication settings.....	107
Table 58	Supported Modbus function codes.....	107
Table 59	Interpretation of 16-bit signed integer values.....	108
Table 60	Modbus register blocks.....	109
Table 61	Modbus measurement data registers (read-only).....	109
Table 62	Modbus status registers (read-only).....	111
Table 63	Modbus device status bits.....	111
Table 64	Device identification objects.....	112
Table 65	Modbus exception responses.....	112

1. Safety

Vaisala Moisture, Hydrogen and Temperature Transmitter MHT410 for Transformer Oil delivered to you has been tested for safety and approved as shipped from the factory. Note the following precautions:



CAUTION! Read the Quick Guide (including installation instructions) carefully before installing the product.



WARNING! Ground the product and verify installation grounding periodically to minimize shock hazard.



DANGER! Severe risk of death and of damage to transformer:

Pay attention to transmitter installation depth and possible energized parts inside the power transformer to minimize electric shock hazard and equipment damage.



CAUTION! Do not modify the unit or use it in ways not described in the documentation. Improper modification or use may lead to safety hazards, equipment damage, failure to perform according to specification, or decreased equipment lifetime.



CAUTION! Do not try to close the ball valve when the transmitter is fully installed. The probe body goes through the valve into the oil flow, and trying to close the valve will damage the probe body and/or the valve. If you must close the ball valve while the transmitter is on the valve, first open the small tightening nut and pull the probe body out as far as possible. Then close the valve.



CAUTION! To avoid damage to the installation valve of the transformer, do not step on the transmitter when the transmitter is installed.



CAUTION! Follow the safety regulations related to the application and installation site.

1.1 ESD protection

Electrostatic Discharge (ESD) can damage electronic circuits. Vaisala products are adequately protected against ESD for their intended use. However, it is possible to damage the product by delivering electrostatic discharges when touching, removing, or inserting any objects in the equipment housing.

To avoid delivering high static voltages to the product:

- Handle ESD-sensitive components on a properly grounded and protected ESD workbench or by grounding yourself to the equipment chassis with a wrist strap and a resistive connection cord.
- If you are unable to take either precaution, touch a conductive part of the equipment chassis with your other hand before touching ESD-sensitive components.
- Hold component boards by the edges and avoid touching component contacts.

2. About this document

Table 1 Document versions (English)

Document code	Date	Description
M211737EN-H	March 2021	<p>This document.</p> <p>New chapters:</p> <ul style="list-style-type: none"> • Vaisala Indigo520 Transmitter (page 81) • Clearing H2 calibration and adjustment (page 88) <p>Updated content:</p> <ul style="list-style-type: none"> • Added silicone oil to the list of supported oils • Serial commands summary (page 44) • Calibration and adjustment commands (page 67) • Error states (page 91) • MHT410 specifications (page 93) • Status registers (page 111)
M211737EN-G	November 2018	<p>Previous version. Added natural and synthetic ester oil support information and instructions on checking the oil type set at the factory from the product label. Added instructions on configuring oil-specific moisture in oil calculation coefficients. Clarified the information on the temperature range for accurate measurement in hydrogen and temperature accuracy specifications and added sensor head temperature tolerance specification. Added instructions on using a safety pin with a warning label to lock the valve handle in open position after installation.</p>
M211737EN-F	May 2018	<p>Updated installation instructions regarding PTFE tape and installation depth. Added DNP3 protocol information. Added clarification about using the RS-485 line of the screw terminals with Modbus or Vaisala Industrial Protocol. Added maximum power consumption specification. Added new parameter options for analog outputs: daily, weekly, and monthly ROC and 24-hour average for H₂ and H₂O. Added clarification about the calculation of rate of change (ROC) readings. Changed unit "ppm" to "ppm_v" for H₂ and to "ppm_w" for H₂O.</p>

Table 2 Related manuals

Document code	Description
M211736EN	<i>Vaisala MHT410 Quick Guide</i>
M212287EN	<i>Vaisala Indigo520 User Guide</i>
M211784EN	<i>Loop-Powered Display 242003 for MHT410 Technical Note</i>

2.1 Documentation conventions



WARNING! Warning alerts you to a serious hazard. If you do not read and follow instructions carefully at this point, there is a risk of injury or even death.



CAUTION! Caution warns you of a potential hazard. If you do not read and follow instructions carefully at this point, the product could be damaged or important data could be lost.



Note highlights important information on using the product.



Tip gives information for using the product more efficiently.



Lists tools needed to perform the task.



Indicates that you need to take some notes during the task.

2.2 Regulatory statements

2.2.1 FCC Part 15 compliance statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



CAUTION! Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

2.3 Trademarks

HUMICAP® is a registered trademark of Vaisala Oyj.

Modbus® is a registered trademark of Schneider Automation Inc.

All other product or company names that may be mentioned in this publication are trade names, trademarks, or registered trademarks of their respective owners.

3. Product overview

Vaisala Moisture, Hydrogen and Temperature Transmitter MHT410 for Transformer Oil is designed for online monitoring of insulating oil in power transformers. The transmitter provides an accurate real-time measurement result of moisture, hydrogen and temperature measured in oil, enabling reliable conclusions on the transformer's condition without delay.

The transmitter provides digital and analog outputs of all the measured parameters.


3.1 Main features


- Reliable online measurement of transformer oil for the following parameters:
 - Moisture: relative saturation (%RS), water activity, and water content (ppm_w)
 - Hydrogen concentration (ppm_v in oil)
 - Temperature (°C and °F)
- Compatible with mineral oils, natural ester oils, synthetic ester oils, and silicone oils
- No need to take oil samples for measurement
- Installable and retro-fittable on a ball valve (ball valve thread: female 1.5" NPT)
- Low maintenance requirements due to excellent long term stability
- Outputs
 - Digital: Modbus, DNP3, and Vaisala industrial protocol over RS-485
 - Analog: three channels with scalable current output
- Status indication LEDs in the front panel
- Built-in data logging
- USB connectivity for service connections using an optional USB M8 cable
- Display options:
 - Loop-powered display for continuous use
 - MI70 handheld meter for temporary use
- Compatible with Vaisala Indigo500 series transmitters

More information

- [Oil types \(page 16\)](#)
- [Status LEDs \(page 17\)](#)
- [Data logging \(page 17\)](#)
- [Connecting to MHT410 via service port \(page 41\)](#)
- [Loop-powered display \(page 31\)](#)
- [Vaisala MI70 Handheld Indicator \(page 73\)](#)
- [Technical data \(page 93\)](#)

3.2 Product parts and package contents





No.	Item
1	= Electronics housing. The front cover is additionally connected to the housing with a grounding wire.
2	= Weather shield
3	= Bleed screw
4	= Probe body
5	= Small tightening nut, used to adjust and fix the depth of the transmitter in the valve. You can move the tightening nut and the mounting nut along the probe body.
6	= Mounting nut, used to fasten the transmitter in the ball valve. You can move the tightening nut and the mounting nut along the probe body.
7	= Hydrogen sensor
8	= Moisture and temperature sensors under the filter
9	= Product label
10	= Lead-throughs (2 pcs) with a minimum of one cable gland (size M20x1.5) or conduit fitting. Unused lead-throughs are plugged.
Installation Kit:	
11	= PTFE tape roll
12	= Allen keys (3 mm and 5 mm)
13	= Extra bleed screw and sealing ring
14	= Extra terminal blocks (4 x 4 screw terminals)

More information

- [Dimensions \(page 98\)](#)

3.3 Measurement parameters and units

Parameter	Abbreviation	Unit
H₂ concentration in oil		
• 1 h average • 24 h average	H ₂	ppm _v
Rate of change of H₂ concentration		
In a day	Daily ROC	ppm _v /day
In a week	Weekly ROC	ppm _v /week
In a month	Monthly ROC	ppm _v /month
Moisture in oil		
Relative saturation	RS	%RS
Water activity	aw (=RS/100)	(no unit)
H ₂ O concentration in oil (current)	H ₂ O	ppm _w
H ₂ O concentration in oil (24 h average)	H ₂ O	ppm _w
Rate of change of H₂O concentration in oil		
In a day	Daily ROC	ppm _w /day
In a week	Weekly ROC	ppm _w /week
In a month	Monthly ROC	ppm _w /month
Temperature		
Oil temperature	T	°C or °F

The rate of change (ROC) for H₂ and for H₂O shows the difference in ppm between the latest 24-hour average and the 24-hour average 1 day ago (daily ROC), 7 days ago (weekly ROC), or 30 days ago (monthly ROC). ROC readings are updated every 12 hours.

After starting up or resetting the transmitter, ROC readings are available as follows:

- Daily ROC: after 2 days
- Weekly ROC: after 8 days
- Monthly ROC: after 31 days

Before the ROC readings are available, the ROC measurement registers in digital outputs contain a "NaN" value, and the ROC analog outputs are set to 3.0 mA (= measurement not ready).

3.4 Oil types

MHT410 is compatible with the following oil types:

- Mineral oils
- Natural ester oils
- Synthetic ester oils
- Silicone oil



CAUTION! Never use MHT410 with any other oil type than the one configured for the unit at the factory. Using the transmitter with a different oil type requires sending the unit to Vaisala for reconfiguration.

The oil type that MHT410 measures (mineral oils, natural ester oils, synthetic ester oils, or silicone oil) is selected when ordering the transmitter. For instructions on checking the oil type set at the factory from the product label, see [Oil type information in order code \(page 16\)](#).

3.4.1 Oil type information in order code

MHT410 has been configured for a specific oil type based on the selection made when ordering the transmitter, and must not be used with other oil types. The oil type configuration set at the factory can be checked from the first digit (1, 2, 3, or 4) of the order code in the MHT410 product label.




Figure 1 MHT410 order code example (first digit 1 = mineral oil)

- 1 First digit of the order code. The oil type configuration is shown in the first digit as 1, 2, 3, or 4:
 - 1 = Mineral oils (shown)
 - 2 = Natural ester oils
 - 3 = Synthetic ester oils
 - 4 = Silicone oils

3.4.2 Oil-specific coefficients for ppm_w moisture measurement

MHT410 can be ordered with ppm_w moisture output (average mass concentration of water in oil). The calculation model that MHT410 uses for ppm_w measurement is based on the average water solubility behavior of transformer oils (see [Calculation model with average coefficients \(page 113\)](#)). If additional accuracy is required, you can configure oil-specific coefficients into MHT410 using Vaisala Industrial Protocol serial commands (see [Table 41 \(page 70\)](#)), or contact Vaisala about setting the coefficients.

More information

- [Moisture ppmw calculation for transformer oils \(page 113\)](#)
- [Other commands \(page 68\)](#)

3.5 Data logging

The transmitter automatically saves the measurement readings and other events in a log every 12 hours (configurable interval). The log can contain approximately 32000 entries.

The following events are logged:

- Hydrogen (ppm_v) reading as 1 h average or 24 h average
- Moisture in oil (%RS and ppm_w) and temperature (°C) readings as instant values or 24 h averages
- Power outages
 - Short power outages that don't turn off transmitter power (flagged "UPS")
 - Long power outages that turn off transmitter power (flagged first as "UPS" and then as "Reset")
- Manual resets (flagged as "Reset")
- Uptime and total operating time
- Occasions of exceeding hydrogen alarm level (optional)

To view the log and change the logging settings, use Vaisala Industrial Protocol.



You can save the log as a file from PuTTY by configuring the following settings in PuTTY before opening the connection:

In the **Session > Logging** view:

- **Session logging:** Select "Printable output".
- **Log file name:** Type a name for the log file (use the file extension .txt) and browse to the save location.







To prevent the log from getting very long, consider saving and then clearing the log every few years.

More information

- [Vaisala Industrial Protocol \(page 40\)](#)
- [Measurement output commands \(page 52\)](#)

3.6 Status LEDs

When the transmitter is ON, one of the LEDs is always illuminated (solid or blinking). If no LED is illuminated, the transmitter is OFF.

LED color and text	Description
Green, blinking:   -- Wait...	Transmitter is preparing H ₂ measurement after start-up or reset.
Green, solid:  ● -- OK	Transmitter is measuring.
Red, blinking:   -- Alarm	H ₂ concentration is above the alarm limit.
Red, solid:  ● -- Error	Transmitter is in error state.

4. Installation



Before you install the transmitter:

- Go through the check list in section [Planning the installation \(page 19\)](#).
- Read this whole guide carefully.



CAUTION! Make sure the oil type of the transformer matches the oil type configured for MHT410. See [Oil type information in order code \(page 16\)](#).



The installation instructions in this section are the same as in the MHT410 Quick Guide.

4.1 Planning the installation

- Choose the installation location on the transformer (see [Recommended installation locations \(page 20\)](#)).



CAUTION! Make sure the installation valve and threads are appropriate from the valve specifications. The correct thread of the valve is **female 1.5" NPT**. Do not install the transmitter in a valve with a different thread. For example, the R thread is incorrect. If you use a different thread than female 1.5" NPT, your equipment may be damaged and the connection is not leak tight. If you are not sure which thread your installation valve has, verify the thread with a 1.5" NPT thread gauge.

- Make sure the oil type of the transformer matches the one configured for MHT410 (mineral oil, natural ester oil, synthetic ester oil, or silicone oil).
- Make sure you have all the required tools for installing the transmitter. The required tools are presented in the installation instructions.
- Choose the output signals: analog and/or digital.
- Choose the electrical wiring option. If the transmitter was ordered with the Vaisala cable CBL210392-5M, the cable is already pre-connected to the transmitter according to Wiring Option 1.

More information

- [Wiring diagrams \(page 99\)](#)

4.1.1 Recommended installation locations

The probe must always be installed in a valve. The correct thread of the valve is **female 1.5" NPT**. Do not install the transmitter in a valve with a different thread. For example, the R thread is incorrect. If you use a different thread than female 1.5" NPT, your equipment may be damaged and the connection is not leak tight.







Figure 2 Recommended installation locations

Recommendation	Description
<p>✓✓✓</p> <p>Recommended: Straight section in the radiator's outlet pipe.</p>	<p>This is the best location for the transmitter.</p> <p>The oil is measured in flow, which makes the oil sample representative and instant. This is essential especially for correct oil moisture measurement.</p> <p>Compared to the radiator inlet pipe, oil in the outlet pipe is cooled, preventing unnecessary heating of the sensors and the transmitter.</p>

Recommendation	Description
 <p>Possible alternative: Wall of the oil tank, high enough from the bottom to enable proper oil movement.</p>	<p>An instrumentation valve is recommended. This is a typical valve that is meant for oil analysis.</p> <p>Moisture response time is moderate depending on the oil volume and transmitter installation.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;">  <p>DANGER! Severe risk of death and of damage to transformer:</p> <p>Pay attention to transmitter installation depth and possible energized parts inside the power transformer to minimize electric shock hazard and equipment damage.</p> </div>
 <p>Not recommended: Drain valve of the oil tank.</p>	<p>The moisture response can be poor due to static oil flow. There is also a risk of separated water (leading to wrong results) and oil sludge (risk of sensor contamination and clogged filters).</p>

4.2 Mechanical installation




CAUTION! Before you install the transmitter:

- Make sure there is no negative pressure in the transformer. If there is negative pressure when you open the bleed screw during installation, air will flow into the transformer oil tank.
- Do not open the ball valve on the transformer until you are instructed to do so in this guide.
- Make sure the bleed screw on the mounting nut is closed.




- 2 wrenches (50 mm and 36 mm)
- Allen key (3 mm, provided)
- PTFE tape (provided)
- Gloves
- Bucket and cloth


- ▶ 1. Remove the protective cap with sorbent packet from the mounting nut. In case of rain, do not let any water fall on the filter.




2. Apply PTFE tape tightly on the mounting nut threads.
 - a. Before you start, clean the threads with a cloth.
 - b. To make sure you wrap the tape in the correct direction, hold the transmitter so that the product label is facing you and the mounting nut points away from you.
 - c. Start wrapping counter-clockwise from the second thread on the tip of the mounting nut.
 - d. Wrap each round very tightly about half way on top of the previous round so that the tape overlaps. Stretch the tape for optimal tightness. Apply a couple of rounds of tape.




3. Make sure the bleed screw is closed. Fasten the mounting nut on the ball valve to **fingertightness** with your hand. Leave the bleed screw directly on top of the nut.
If you cannot position the bleed screw on top of the mounting nut by tightening just with your hand, you can use a wrench (50 mm) to turn the mounting nut **a maximum of a ½ turn**.

 **CAUTION!** If you need to loosen the mounting nut after you have fastened it on the valve, you must remove the transmitter from the valve, remove the PTFE tape, and start again from [step 2](#) with new PTFE tape.



4. With a 3 mm Allen key, loosen the bleed screw. Place a bucket under the mounting nut.




5. Start opening the valve very carefully to let air out through the bleed screw.



CAUTION! If you open the valve too quickly, the air inside the mounting nut will flow into the transformer instead.

When oil flows out, close the bleed screw. Clean the area with a cloth and open the ball valve fully.




6. Continue tightening the mounting nut with a wrench. Be very careful not to over-tighten the connection. Approximately 5 ... 8 mm of the mounting nut threads remain outside the valve.




If the connection leaks after you have tightened the mounting nut, check the thread type of the installation valve.

- If the valve thread is **other than female 1.5" NPT (incorrect)**, do not install the transmitter in that valve.
- If the valve thread is **female 1.5" NPT (correct)**, close the valve, open the mounting nut and remove the transmitter, remove old PTFE tape and apply a thicker layer of new PTFE tape. Then continue from [step 3](#).





7. Push the probe to the correct depth. The correct depth depends on where the installation valve is located: radiator pipe or transformer wall.

- **Valve in radiator pipe:** Install the probe so that the back of the weather shield is 180 ... 190 mm from the pipe surface.




- **Valve in transformer wall:** Install the probe so that the back of the weather shield is 200 mm from the transformer wall.





 **DANGER! Severe risk of death and of damage to transformer:** Pay attention to transmitter installation depth and possible energized parts inside the power transformer to minimize electric shock hazard and equipment damage.

When the probe is in the correct depth, turn the transmitter 90 degrees two to three times to remove any air bubbles from the sensor area.

- Tighten the small tightening nut with a wrench until the probe is securely fastened.



- Press the caution sticker on the MHT410 weather shield or other visible location nearby, and lock the handle of the valve in the open position with the safety pin.



More information

- [Dimensions \(page 98\)](#)

4.3 Electrical installation



When connecting MHT410 to the Indigo520 transmitter, see also [Indigo520 and MHT410 wiring diagram \(page 83\)](#).




If MHT410 was ordered with the Vaisala cable CBL210392-5M, the cable is already pre-connected to MHT410 according to Wiring Option 1.




If cable is not pre-wired:

- Allen key (5 mm, provided)
- 2 medium wrenches (24 mm)
- Flat head screwdriver (2.5 mm)
- Wire-cutting pliers
- Suitable cable. You can order the following cables from Vaisala:
 - 5 m shielded PUR cable (order code: CBL210392-5MSP)
 - 10 m shielded PUR cable (order code: CBL210392-10MSP)


- ▶ 1. Open the electronics housing with a 5 mm Allen key to access the screw terminals.




2. Hold the upper nut of the cable gland in place with a wrench (24 mm), and loosen the sealing nut of the gland with another wrench (24 mm).




3. Lead the cable through the sealing nut and the rubber seal. Turn the shield over the edge of the rubber seal.



4. Lead the cable through the cable gland. Push the rubber seal back in place with the shield. Cut off any excess shield. Tighten the sealing nut with wrench (24 mm).



5. Pull the screw terminal blocks (2 pcs) off from the circuit board.



6. Connect the wiring to the detachable screw terminals according to your chosen wiring option. Note that wiring for digital output (RS-485) is the same in all wiring options.

7. When you are finished with the wiring, plug the screw terminals back in and close the electronics housing.

More information

- [Wiring diagrams \(page 99\)](#)
- [Wiring diagrams \(page 99\)](#)

4.4 Loop-powered display

The analog outputs of the transmitter can be connected to an external loop-powered LED display (order code 242003). The display is a pre-configured Nokeval 302 display intended for Vaisala MHT410 hydrogen channel measurements.

The display also includes two alarm relays to trigger an external hydrogen warning and alarm.

This display can be configured for other parameters (moisture/temperature in oil). If needed, you can install up to three displays, each showing a different parameter.

The default display settings are presented in the Vaisala Technical Note inside the display package. If needed, configure the display functions and scaling according to the manufacturer's instructions delivered with the display. Manufacturer's documentation is also available from www.nokeval.com.



Figure 3 Loop-powered display 242003



The loop resistance of the display must be included in the loop resistance calculation for the complete current loop. For the loop resistance of the display, refer to the manufacturer's documentation.

More information


- [Wiring the loop-powered display \(page 32\)](#)

4.4.1 Wiring the loop-powered display



If one of the cable lead-throughs on your transmitter is plugged and you want to use that lead-through for the Nokeval display cable, you can order a cable gland from Vaisala.

- ▶ 1. Connect the loop-powered display to the transmitter as shown in the following wiring diagram. In the diagram, the display is connected to analog output Channel 1 according to Wiring Option 1.



All the Wiring Options (1, 2, 3, and 4) have the same principle for connecting the display:

- Wire from port 1 of the display connects to the minus port of the transmitter's analog output channel (for example, to "-CH1").
- Wire from port 2 of the display connects to where the minus port wire of the analog output channel would have connected without the display.

More information

- [Spare parts and accessories \(page 97\)](#)
- [Wiring diagrams \(page 99\)](#)

4.5 Checklist after installation

After the installation, check the following indicators to make sure the installation was successful:

- No oil is leaking from the transformer and the transmitter.
If the connection leaks after you have tightened the mounting nut, the probable reason is that the PTFE tape was applied incorrectly or the valve thread is other than female 1.5" NPT.

- The H₂ level LED indicator settles to a solid green. Note that it can take up to 30 minutes for the H₂ level measurement to settle after start-up or reset.
 - Solid **green** indicates that the H₂ level is below alarm limit.
 - Blinking **red** indicates that the H₂ level is above alarm limit (by default, the alarm is off).
- After the initial stabilization period (approx. 24 h power on), the reading is correct.

4.6 Oil fittings check after installation

After the first month of continuous use, all oil fittings should be checked for leaks.

An annual check thereafter is recommended.

4.7 Removing the transmitter



To disconnect wiring:

- Allen key (5 mm, provided)
- 2 medium wrenches (24 mm)
- Flat head screwdriver (2.5 mm)

To remove transmitter:

- Large wrench (50 mm)
- Medium wrench (36 mm)
- Gloves
- Bucket and cloth



CAUTION! Do not try to close the ball valve when the transmitter is fully installed. The probe body goes through the valve into the oil flow, and trying to close the valve will damage the probe body and/or the valve.

- ▶ 1. If needed, disconnect the wiring:
 - a. Open the front cover and disconnect the wires from the detachable screw terminals.
 - b. Hold the upper nut of the cable gland in place with a wrench (24 mm), and loosen the sealing nut of the gland with another wrench (24 mm).
 - c. Pull the cable out of the cable gland.
 - d. Re-attach the cable gland in its place.
2. Put a bucket under the ball valve to catch any oil falling from the valve.

3. Loosen the small tightening nut with a wrench.



To keep the larger mounting nut from opening, hold it in place with a wrench as you are opening the smaller tightening nut.

4. Pull the transmitter outward so that the probe body is out of the ball valve.
5. Close the ball valve.
6. Open the mounting nut with a wrench and pull the transmitter out. Use the cloth to clean up any spills.



Always make sure the bleed screw is closed before you turn the mounting nut with a wrench.

4.8 Re-installing the transmitter in new location

If you re-install the transmitter in a new location, you must initialize the transmitter after the re-installation by connecting to the service port and giving the initialization command using Vaisala Industrial Protocol.

- ▶ 1. Remove the transmitter. See [Removing the transmitter \(page 34\)](#).
2. Install the transmitter in the new location as instructed in [Installation \(page 19\)](#) and its subsections.
3. Connect to the transmitter via the service port and start communication using Vaisala Industrial Protocol.
 - a. Connect to the service port ([Connecting to MHT410 via service port \(page 41\)](#)).
 - b. If needed, install the USB driver ([Installing driver for the USB service cable \(page 41\)](#)).
 - c. Connect the USB cable ([Connecting USB service cable \(page 42\)](#)).
 - d. Configure the terminal application settings ([Configuring terminal application settings \(page 42\)](#)).
4. Start the initialization sequence by issuing the command `h2`. The transmitter starts outputting H₂ measurement data.

```
> h2
Start hydrogen measurement module command line operation, quit by pressing
+
15832291.00 33.5719 50.06586 209.87 8413520 8410294 106 0.0 0 28.7938 0
15832292.00 33.5852 50.06617 209.82 8413484 8410254 106 0.0 0 28.7938 0
...
```

5. Stop the output by pressing the **Esc** key:

```
...
15832292.00 33.5852 50.06617 209.82 8413484 8410254 106 0.0 0 28.7938 0
<"Esc key">
H2scan:
```

6. Give the initialization command `is`, and when asked to erase the data log, confirm by pressing the `y` key.

```
H2scan: is

Clearing old data:
...wait...Erase the Data Log (Y/N)? y
Clearing log

; SSN=B13.21L.10306TN1X, FW=3.85F , MDN=104400-FF02-P1, DF=0xB4B4s, L
TimeSec PcbTemp SnsrTemp HCurrent Res1Adc AdjRes1 H2Res.ppm
H2.ppm H2_DG.ppm OilTemp H2_G.ppm H2_SldAv Messages
```

7. Start the H₂ measurement output again by pressing the `v` key.

```
v
15832363.00 31.9850 30.88629 0.00 8087342 8087342 641 - - - - htr_off
wait
15832364.00 31.9565 30.84680 0.00 8086663 8086663 582 - - - - htr_off
wait
...
```

8. Finish the initialization sequence by pressing the `+` key.

```
...
15832364.00 31.9565 30.84680 0.00 8086663 8086663 582 - - - - htr_off
wait
<"+" key">
Quit hydrogen measurement module command line operation
```

9. Close the PuTTY terminal application.
10. Disconnect from the service port and close the transmitter cover.

5. Analog output

There are three analog output channels available for H₂, moisture in oil, and temperature using 4 ... 20 mA current outputs.

The parameter for each output is configured at the factory according to order. If needed, you can change the parameters using the **asel** command via Vaisala Industrial Protocol.

Table 3 Analog output values in different transmitter statuses

Transmitter status	Analog output value
Normal	4 ... 20mA
Error	3.5 mA (default)
Measurement not ready	3.0 mA

More information

- [Analog output commands \(page 63\)](#)

5.1 Analog output overrange behavior

If the measured hydrogen, moisture and temperature levels go below or above their scaled range, the analog output is clipped at the low (4 mA) or high (20 mA) end of the output range. This means the analog output will not indicate measurement readings that are outside the scaled ranges.

If needed, you can allow the analog outputs to extend 10 % of the range over 20 mA using the **aover** command via Vaisala Industrial Protocol. With this extension, the allowed range for analog outputs is 4 ... 21.6 mA. The **aover** command does not affect the scaling of the outputs.

You can also change the scaling of the outputs for each channel using the **asel** command via Vaisala Industrial Protocol.




Figure 4 Analog output overrange behavior

More information

- [Analog output commands \(page 63\)](#)

6. Modbus

6.1 Overview of Modbus protocol support

MHT410 can be accessed using the Modbus serial communication protocol on the RS-485 line of the screw terminals. The supported Modbus variant is Modbus RTU (Serial Modbus).

The supported Modbus functions and registers are described in [Modbus reference \(page 107\)](#).

By default, the RS-485 line of the screw terminals is in Modbus mode. The pre-configured default communication settings are presented in the following table.

Description	Default value
Serial bit rate	19200
Parity	None
Number of data bits	8 (read-only)
Number of stop bits	1
Modbus device address	240

You can change the serial line communication settings using Vaisala Industrial Protocol.



The minimum time between requests from Modbus is 1 second.

More information

- [Modbus reference \(page 107\)](#)
- [Serial line communication commands \(page 59\)](#)
- [Vaisala Industrial Protocol \(page 40\)](#)

7. Vaisala Industrial Protocol

The transmitter provides an implementation of the Vaisala Industrial Protocol that can be used for service and configuration use, or for interfacing with the system to which the transmitter is integrated. The protocol is a plaintext protocol suitable for use both by human operators and automated systems.

You can access the Vaisala Industrial Protocol in two ways:

- For temporary connection with a computer, use the service port. See [Connecting to MHT410 via service port \(page 41\)](#).
- For permanent connection, use the RS-485 line of the screw terminals.



The RS-485 line of the screw terminals is in Modbus mode by default. To use Vaisala Industrial Protocol on the RS-485 line, you must first change the communication mode for that line:

1. Connect to the service port (see [Connecting to MHT410 via service port \(page 41\)](#)).
2. Change the mode using the **smode** command (see [Table 28 \(page 62\)](#)).



You can use Vaisala Industrial Protocol via the RS-485 line of the screw terminals and the service port at the same time. However, the transmitter responds to the commands one at a time from either line, which may result in delayed responses if a command is entered from one line while another command is in progress on the other line.

Table 4 Default serial interface settings

Property	Description/Value
Baud rate	19200
Parity	None
Number of data bits	8
Number of stop bits	1
Flow control	None

More information

- [Serial commands summary \(page 44\)](#)

7.1 Connecting to MHT410 via service port



- Vaisala USB service cable (item code 219690)
- Computer with:
 - Windows operating system
 - Free USB port
 - Terminal application (for example, PuTTY, available from www.vaisala.com)
 - Driver for Vaisala USB service cable installed (available on the cable installation media and from www.vaisala.com/software)

You can connect to the MHT410 transmitter via Vaisala Industrial Protocol on a computer using the service port located under the transmitter cover.

If you have not used the Vaisala USB service cable before, install the driver before attempting to use the cable.


7.1.1 Installing driver for the USB service cable



Only Windows® operating systems are supported by the driver of the USB service cable.

- ▶ 1. Connect the USB service cable to a USB port on your computer. Windows® detects the new device and installs the appropriate driver.
2. Open **Devices and Printers** from the Windows® Start menu. Use search to find it if necessary (search for "devices").

3. Locate the cable in the list of devices:
 - If the device is listed as **Vaisala USB Device** with a COM port number in brackets, the cable is ready for use. **Note the COM port number, you will need it later.**
 - If the device is listed as **Vaisala USB Instrument Cable** without a COM port number listed, you must install the driver manually.



4. To install the driver manually:
 - a. Disconnect the USB service cable from the computer.
 - b. Download the Vaisala USB driver at <http://www.vaisala.com/software> (select the appropriate USB Instrument Driver Setup for your cable).
 - c. Run the USB driver installation program *Vaisala USB Device Driver Setup.exe*. Accept the installation defaults.
 - d. Go back to [step 1](#) and verify that the driver installation works as expected.

7.1.2 Connecting USB service cable


To connect the USB service cable to the service port:

- ▶ 1. Make sure the USB service cable is connected to your computer.
2. Open the 4 hex screws on the cover of the transmitter using a 5-mm Allen key, and open the cover.
3. Connect the USB service cable to the service port connector on the transmitter circuit board.
4. Configure the terminal application settings.

7.1.3 Configuring terminal application settings

The steps below describe how to connect to the transmitter using the PuTTY terminal application for Windows (available for download at www.vaisala.com) and a USB service cable:

- 1. Make sure the USB service cable is connected to your PC and the service port of the transmitter.
- 2. Start the PuTTY application.
- 3. Select **Connection > Serial & USB** and check that the correct COM port is selected in the **Serial or USB line to connect to** field. If you are using the PuTTY terminal application supplied by Vaisala, you can select **USB Finder...** to open the Vaisala USB Instrument Finder program.



- 4. Check that the other serial settings are correct, and change if necessary.

Table 5 Service port serial interface settings

Property	Value
Baud rate	19200
Parity	None
Data bits	8
Stop bits	1
Flow control	None

- 5. Select **Terminal**. Use the following settings:
 - **Local Echo:** "Force on". This setting ensures that your typing is shown on the session window.
 - **Send line ends with line feeds (CR+LF):** Selected. This setting ensures that all text lines remain visible on the session window.

6. Select **Open** to open the connection window and start using the serial line.



If PuTTY is unable to open the serial port you selected, it will show you an error message instead. If this happens, restart PuTTY and check the settings.

7.2 Serial commands summary

The notation **<cr>** refers to the carriage return control character, which you can send in a terminal application by pressing Enter on your keyboard. Before entering commands, send a **<cr>** to clear the command buffer.

You can enter the commands in uppercase or lowercase. In the command examples, the keyboard input by the user is in **bold** type.

Table 6 Serial commands

Command	Description	More information
Device information and status:		
?	Show device information.	Table 7 (page 46)
??	Show device information (will respond in poll mode).	
alarm	Show or set H ₂ alarm level.	Table 8 (page 47)
errlog	Show error log records.	Table 9 (page 48)
errs	Show active errors.	Table 10 (page 49)
help	Show list of serial commands.	Table 11 (page 50)
system	Show firmware information.	Table 12 (page 50)
time	Show transmitter uptime (time since last reset).	Table 13 (page 51)
vers	Show the software version information.	Table 14 (page 51)
Serial line output and communication:		
addr	Show or set device address used in Modbus communication and in Vaisala Industrial Protocol when the device is in POLL mode.	Table 23 (page 59)

Command	Description	More information
close	Close connection to device in POLL mode. This command cannot be used via the Service Port.	Table 24 (page 60)
form	Set output format of measurement messages.	Table 19 (page 56)
intv	Set measurement output interval.	Table 15 (page 52)
log	Show measurement log records and configure logging settings.	Table 16 (page 52)
open	Open connection to device in POLL mode. This command cannot be used via the Service Port.	Table 25 (page 60)
r	Start continuous output of measurement messages.	Table 17 (page 55)
sdelay	Show or set serial line transmission delay.	Table 26 (page 60)
send	Output one measurement message.	Table 18 (page 55)
seri	Set serial line settings for the RS-485 line of the screw terminals. Default is 19200 N 8 1. This command does not affect the service port settings.	Table 27 (page 61)
smode	Set serial line operation mode for the RS-485 line of the screw terminals. This command does not affect the service port settings. The service port is always in stop mode.	Table 28 (page 62)
unit	Set temperature unit to metric (°C) or non-metric (°F).	Table 22 (page 59)
Analog output:		
aerr	Show or set error level for analog output.	Table 29 (page 63)
aover	Enable or disable analog output 10 % over range.	Table 30 (page 63)
asel	Show or set analog output parameters and scaling.	Table 31 (page 64)
atest	Test analog outputs by forcing them to a given value.	Table 32 (page 66)
Calibration and adjustment:		
cdate	Show or set adjustment date.	Table 33 (page 67)

Command	Description	More information
ctext	Show or set adjustment information text.	Table 34 (page 67)
h2 da h2 db	Start or continue hydrogen calibration and adjustment sequence.	Table 35 (page 68)
h2 x	Clear hydrogen calibration and adjustment data.	Table 36 (page 68)
Other commands:		
dnp3 addr	Change the data link address of the transmitter in DNP3 communication.	Table 37 (page 68)
filt	Show or set measurement filtering.	Table 38 (page 69)
frestore	Restore factory settings. Clears all user settings, factory calibration remains.	Table 39 (page 69)
oil	Show or set oil-specific coefficients for moisture ppm _w calculation.	Table 41 (page 70)
reset	Reset the device.	Table 40 (page 70)
h2 is	Initialize the device after it has been re-installed in a new location.	Table 42 (page 70)

7.3 Device information and status commands

Table 7 [?](#) command

Syntax	Description
?<cr>	Show listing of device information.
??<cr>	Show listing of device information when device is in poll mode and connection has not been opened using the open command.



Syntax	Description
Example:	
<pre> ? MHT410 / 0.1.20 Serial number : L2110001 Batch number : L1940010 Sensor number : L102 Sensor model : Humicap L2 Order code : MHT410 1CXEO Cal. date : 20150414 Cal. info : Vaisala Uptime : 0000d 04:04:41 Total time : 0000d 04:04:41 Serial mode : STOP Baud P D S : 19200 N 8 1 Output interval : 1 S Serial delay : 25 Address : 0 Filter : 1.000 Ch1 output : 4 ... 20 mA Ch2 output : 4 ... 20 mA Ch3 output : 4 ... 20 mA Ch1 RS lo : 0.00 % Ch1 RS hi : 100.00 % Ch2 T lo : -40.00 'C Ch2 T hi : 100.00 'C Ch3 H2 lo : 0.00 ppm Ch3 H2 hi : 5000.00 ppm </pre>	

Table 8 **alarm** command

Syntax	Description
alarm <cr>	Check the status and setpoint (ppm _v) of the hydrogen alarm. The alarm is activated when the 1-hour average for hydrogen exceeds the setpoint.
alarm [on off] [setpoint] <cr>	Set the hydrogen alarm status. on = Alarm indication is on. off = Alarm indication is off. setpoint = Hydrogen level above which the alarm is activated.
Example (check the hydrogen alarm status, alarm is off):	
<pre> alarm Alarm display : OFF ? Setpoint (ppm) : 300 ? </pre>	

Syntax	Description
Example (enable the hydrogen alarm and set the alarm limit to 200 ppm, hydrogen):	
<pre>alarm on 200 Alarm display : ON Setpoint (ppm) : 200</pre>	

Table 9 **errlog** command

Syntax	Description
errlog print<cr>	<p>Show the error log with max. 25 last log entries.</p> <p>The error log stores the error status each time the status changes.</p> <div style="background-color: #f0f0f0; padding: 10px; border: 1px solid #ccc;"> <p> You can save the error log as a file from PuTTY by configuring the following settings in PuTTY before opening the connection:</p> <p>In the Session > Logging window:</p> <ul style="list-style-type: none"> • Session logging: Select "Printable output". • Log file name: Type a name for the log file (use extension .txt) and browse for the location where to save the file. </div>
errlog print [n] [i]<cr>	<p>Show the error log with a chosen number of entries.</p> <p>n = Number of entries to show (max. 9999).</p> <p>i = Optional: Index number of the first shown entry. If this parameter is not used, the list will show the last n number of entries.</p>
errlog save<cr>	<p>Save the current error status for troubleshooting purposes.</p>
errlog clear<cr>	<p>Remove all entries from the error log.</p> <div style="background-color: #f0f0f0; padding: 10px; border: 1px solid #ccc;"> <p> Clearing the error log may make troubleshooting more difficult later if a problem occurs.</p> </div>

Syntax	Description																																																																																
<p>Example (show error log):</p> <pre>errlog print</pre> <table border="1"> <thead> <tr> <th>index</th> <th>RecNum</th> <th>Reset</th> <th>Days</th> <th>Time</th> <th>ERRS</th> <th>H2err</th> <th>Y(T)</th> <th>Y(RH)</th> <th>fm_cnt</th> </tr> </thead> <tbody> <tr><td>1</td><td>1</td><td>1</td><td>0</td><td>00:00:00</td><td>8</td><td>0</td><td>1.0947</td><td>4.7467</td><td>0</td></tr> <tr><td>2</td><td>2</td><td>2</td><td>0</td><td>00:37:29</td><td>8</td><td>0</td><td>1.0984</td><td>0.5565</td><td>6</td></tr> <tr><td>3</td><td>3</td><td>2</td><td>0</td><td>00:37:14</td><td>8</td><td>0</td><td>1.1004</td><td>2.4597</td><td>0</td></tr> <tr><td>4</td><td>4</td><td>2</td><td>0</td><td>00:38:46</td><td>8</td><td>0</td><td>1.1027</td><td>0.5147</td><td>7</td></tr> <tr><td>5</td><td>5</td><td>2</td><td>0</td><td>01:10:02</td><td>8</td><td>0</td><td>1.1146</td><td>2.5202</td><td>0</td></tr> <tr><td>6</td><td>6</td><td>2</td><td>0</td><td>01:15:57</td><td>8</td><td>0</td><td>1.1156</td><td>0.5876</td><td>6</td></tr> <tr><td>7</td><td>7</td><td>3</td><td>0</td><td>00:36:21</td><td>8</td><td>0</td><td>1.1160</td><td>-3.9274</td><td>1</td></tr> </tbody> </table>	index	RecNum	Reset	Days	Time	ERRS	H2err	Y(T)	Y(RH)	fm_cnt	1	1	1	0	00:00:00	8	0	1.0947	4.7467	0	2	2	2	0	00:37:29	8	0	1.0984	0.5565	6	3	3	2	0	00:37:14	8	0	1.1004	2.4597	0	4	4	2	0	00:38:46	8	0	1.1027	0.5147	7	5	5	2	0	01:10:02	8	0	1.1146	2.5202	0	6	6	2	0	01:15:57	8	0	1.1156	0.5876	6	7	7	3	0	00:36:21	8	0	1.1160	-3.9274	1	
index	RecNum	Reset	Days	Time	ERRS	H2err	Y(T)	Y(RH)	fm_cnt																																																																								
1	1	1	0	00:00:00	8	0	1.0947	4.7467	0																																																																								
2	2	2	0	00:37:29	8	0	1.0984	0.5565	6																																																																								
3	3	2	0	00:37:14	8	0	1.1004	2.4597	0																																																																								
4	4	2	0	00:38:46	8	0	1.1027	0.5147	7																																																																								
5	5	2	0	01:10:02	8	0	1.1146	2.5202	0																																																																								
6	6	2	0	01:15:57	8	0	1.1156	0.5876	6																																																																								
7	7	3	0	00:36:21	8	0	1.1160	-3.9274	1																																																																								
<p>Example (show the last 5 entries):</p> <pre>errlog print 5</pre> <table border="1"> <thead> <tr> <th>index</th> <th>RecNum</th> <th>Reset</th> <th>Days</th> <th>Time</th> <th>ERRS</th> <th>H2err</th> <th>Y(T)</th> <th>Y(RH)</th> <th>fm_cnt</th> </tr> </thead> <tbody> <tr><td>27</td><td>27</td><td>19</td><td>0</td><td>04:59:27</td><td>8</td><td>0</td><td>1.1160</td><td>-3.9274</td><td>1</td></tr> <tr><td>28</td><td>28</td><td>19</td><td>0</td><td>05:11:40</td><td>0</td><td>0</td><td>1.1167</td><td>0.5479</td><td>6</td></tr> <tr><td>29</td><td>29</td><td>19</td><td>0</td><td>05:18:53</td><td>8</td><td>0</td><td>0.7497</td><td>0.3019</td><td>6</td></tr> <tr><td>30</td><td>30</td><td>19</td><td>0</td><td>05:21:12</td><td>0</td><td>0</td><td>0.2000</td><td>-0.1030</td><td>6</td></tr> <tr><td>31</td><td>31</td><td>19</td><td>0</td><td>05:22:36</td><td>8</td><td>0</td><td>1.1187</td><td>0.5538</td><td>7</td></tr> </tbody> </table>	index	RecNum	Reset	Days	Time	ERRS	H2err	Y(T)	Y(RH)	fm_cnt	27	27	19	0	04:59:27	8	0	1.1160	-3.9274	1	28	28	19	0	05:11:40	0	0	1.1167	0.5479	6	29	29	19	0	05:18:53	8	0	0.7497	0.3019	6	30	30	19	0	05:21:12	0	0	0.2000	-0.1030	6	31	31	19	0	05:22:36	8	0	1.1187	0.5538	7																					
index	RecNum	Reset	Days	Time	ERRS	H2err	Y(T)	Y(RH)	fm_cnt																																																																								
27	27	19	0	04:59:27	8	0	1.1160	-3.9274	1																																																																								
28	28	19	0	05:11:40	0	0	1.1167	0.5479	6																																																																								
29	29	19	0	05:18:53	8	0	0.7497	0.3019	6																																																																								
30	30	19	0	05:21:12	0	0	0.2000	-0.1030	6																																																																								
31	31	19	0	05:22:36	8	0	1.1187	0.5538	7																																																																								
<p>Example (save the current error status):</p> <pre>errlog save</pre> <p>New value stored.</p>																																																																																	
<p>Example (remove all entries from the error log):</p> <pre>errlog clear</pre> <p>Erase all Error Log data? (Y/N) y Erasing... Error Log cleared.</p>																																																																																	

Table 10 **errs** command

Syntax	Description
errs<cr>	Show currently active errors. The possible errors and their remedies are listed in Table 46 (page 91) .

Syntax	Description
Example (no errors active):	
<pre>errs No errors</pre>	
Example (active error):	
<pre>errs 0008 H2 module communication error H2scan message: wait</pre>	

Table 11 **help** command

Syntax	Description
help<cr>	Show a list of available commands.
Example:	
<pre>help Stop mode commands: ADDR AERR ALARM AOVER ASEL ATEST CDATE CLOSE CTEXT DNP3 ERRLOG ERRS FILT FORM FRESTORE H2 HELP INTV LOG R RESET SDELAY SEND SERI SMODE SYSTEM TIME UNIT VERS ? Poll mode commands: OPEN SEND ??</pre>	

Table 12 **system** command

Syntax	Description
system<cr>	Show firmware information.
Example:	
<pre>system Device Name : MHT410 Copyright : Copyright (c) Vaisala Oyj 2015. All rights reserved. SW Name : MHP410 SW date : 2015-05-05 SW version : 1.0.0 OS version : TSF 1.0</pre>	

Table 13 **time** command

Syntax	Description
time [mode]<cr>	Show transmitter uptime (time since last reset). Default output: hh:mm:ss. mode = alternative output option (optional) <ul style="list-style-type: none">• 1 = include days (dddd hh:mm:ss)• 2 = include decimals of seconds (hh:mm:ss.sss)• 3 = include days and decimals of seconds• 4 = include total operating time
Example (show transmitter uptime in hh:mm:ss):	
<pre>time Uptime : 00:50:04</pre>	
Example (show transmitter uptime with days):	
<pre>time 1 Uptime : 2d 01:50:39</pre>	

Table 14 **vers** command

Syntax	Description
vers<cr>	Show the software version information.
Example:	
<pre>vers MHT410 / 1.0.0</pre>	


7.4 Serial line output and communication commands

7.4.1 Measurement output commands

Table 15 **intv** command

Syntax	Description
intv <cr>	Show the output interval of the automatically repeating measurement messages (r command and run mode). This command has no effect on the operation of the analog output.
intv [iii uuu]<cr>	Set the output interval. iii = interval, range 1 ... 255 uuu = unit for interval setting: <ul style="list-style-type: none"> • s = seconds • min = minutes • h = hours
Example (set the output interval to 1 second):	
<pre>intv 1 s Output interval: 1 S</pre>	

Table 16 **log** command

Syntax	Description
log print <cr>	Show the measurement log with max. 100 last log entries. <div style="background-color: #f0f0f0; padding: 10px; margin-top: 10px;">  You can save the log as a file from PuTTY by configuring the following settings in PuTTY before opening the connection: In the Session > Logging window: <ul style="list-style-type: none"> • Session logging: Select "Printable output". • Log file name: Type a name for the log file (use extension .txt) and browse for the location where to save the file. To prevent the log from getting very long, consider saving and then clearing the log every few years. </div>

Syntax	Description
log print [n] [i]<cr>	Show the measurement log with a chosen number of entries. n = Number of entries to show (max. 32767). i = Optional: Index number of the first shown entry. If this parameter is not used, the list will show the last n number of entries.
log alarm [on off]<cr>	Enable or disable storing a log item when the H ₂ concentration (1 hour average) exceeds the alarm level. Logging continues once an hour until the H ₂ level returns below the alarm limit or until alarm logging is disabled. The log entries contain the additional tag "H2alarm". You set the H ₂ alarm level using the alarm command (see Table 8 (page 47)).
log filt [on off]<cr>	Enable or disable the filtering of measurement values in the log. on = For each parameter, the 24 h average value is stored. The log entries contain the additional tag "F". off = For H ₂ , 1 h average is stored. For RS and T, instant values are stored.
log save<cr>	Save the current measurement values in the log. The log entry contains the additional tag "Tst".
log clear<cr>	Remove all entries from the measurement log.
log intv [interval]<cr>	Set the logging interval in minutes (range: 15 ... 1440). The default interval is 720 minutes (12 hours).
Example (show up to 100 last entries in the log):	
<pre> log print index Reset Days Uptime Total Time RS(%) H2O(ppm) Temp('C) H2(ppm) Flags 1 2 0 00:08:23 0 00:17 10.000 13.900 45.406 18.0 N Tst 2 2 0 00:13:02 0 00:22 10.000 13.900 45.467 18.0 N Tst 3 5 0 00:37:17 0 00:59 10.000 13.900 45.303 18.0 N Tst 4 5 0 00:52:54 0 01:14 10.000 13.900 45.278 18.0 N Tst 5 7 0 12:00:43 0 13:14 10.000 13.900 45.887 18.0 N 6 11 0 00:04:31 0 13:18 10.000 13.900 45.495 18.0 N 7 11 0 00:12:08 0 13:26 10.000 12.900 45.716 18.1 N 8 12 0 00:03:15 0 13:29 10.000 13.900 45.531 18.2 N </pre>	
Example (show the last 5 entries):	
<pre> log print 5 index Reset Days Uptime Total Time RS(%) H2O(ppm) Temp('C) H2(ppm) Flags 4 5 0 00:52:05 0 01:14 10.000 13.900 45.278 18.0 N Tst 5 7 0 12:00:24 0 13:14 10.000 13.900 45.887 18.0 N 6 11 0 00:04:41 0 13:18 10.000 13.900 45.495 18.0 N 7 11 0 00:12:16 0 13:26 10.000 12.900 45.716 18.1 N 8 12 0 00:03:43 0 13:29 10.000 13.900 45.531 18.2 N </pre>	

Syntax	Description
Example (show 5 entries starting from the 3rd entry):	
<pre>log print 5 3 index Reset Days Uptime Total Time RS(%) H2O(ppm) Temp('C) H2(ppm) Flags 3 5 0 00:37:23 0 00:59 10.000 13.900 45.303 18.0 N Tst 4 5 0 00:52:31 0 01:14 10.000 13.900 45.278 18.0 N Tst 5 7 0 12:00:12 0 13:14 10.000 13.900 45.887 18.0 N 6 11 0 00:04:57 0 13:18 10.000 13.900 45.495 18.0 N 7 11 0 00:12:48 0 13:26 10.000 12.900 45.716 18.1 N</pre>	
Example (enable storing a log item when H ₂ alarm level is exceeded):	
<pre>log alarm on Alarm loggings: OFF -> ON</pre>	
Example (disable filtering the measurement values in the log):	
<pre>log filt off 24h rolling average filter: ON -> OFF</pre>	
Measurement log column information	
Column	Description
index	Log record number (1 to 32767)
Reset	Reset count
Days	Number of days since last reset (uptime)
Uptime	Hours, minutes, and seconds of uptime
Total Time	Total operating time (days, hours, minutes)
RS (%)	H ₂ O relative saturation in oil
H2O (ppm)	H ₂ O concentration, absolute (ppm by weight)
Temp (°C)	Oil temperature
H2 (ppm)	Hydrogen concentration in oil (ppm by volume)
Flags	See flag descriptions below.
Log entry type indicators in Flags column	
ID	Description
N	Log item stored every 12 hours (or at selected rate)
H2alarm	H ₂ value (1 hour average) has exceeded alarm limit

Syntax	Description
RESET	Power-on or reset has occurred. In a RESET log entry, the H2 (ppm) column shows the reset cause, and measurement columns show dashes (-.---) instead of measurement information.
UPS	Power down detected, UPS is running
Tst	The log item was saved using log save command
F	Filter was on when the log record was saved
ERR	Error was active when the log record was saved
CRC ERR	Checksum error in the log record

Table 17 **r** command

Syntax	Description
r<cr>	Start the continuous outputting of measurement values as an ASCII text string to the serial line. The transmitter keeps outputting measurement messages at the interval that has been set with the intv command until stopped with the s command.
Example:	
<pre> r T= 45.1 'C RS= 10.0 % H20= 13.9 ppm aw= 0.100 H2= 17 ppm T= 45.0 'C RS= 10.0 % H20= 13.9 ppm aw= 0.100 H2= 17 ppm T= 45.0 'C RS= 10.0 % H20= 13.9 ppm aw= 0.100 H2= 17 ppm T= 45.1 'C RS= 10.0 % H20= 13.9 ppm aw= 0.100 H2= 17 ppm T= 45.1 'C RS= 10.0 % H20= 13.9 ppm aw= 0.100 H2= 18 ppm T= 45.1 'C RS= 10.0 % H20= 13.9 ppm aw= 0.100 H2= 18 ppm T= 45.1 'C RS= 10.0 % H20= 13.9 ppm aw= 0.100 H2= 18 ppm T= 45.2 'C RS= 10.0 % H20= 13.9 ppm aw= 0.100 H2= 18 ppm ... </pre>	

Table 18 **send** command

Syntax	Description
send<cr>	Output a single measurement message. The output uses the format defined with the form command.
send [yyy]<cr>	Output a single measurement message when the transmitter is in poll mode and connection has not been opened using the open command. yyy = Address of the transmitter, range 0 ... 255. The address is set with the addr command.

Syntax	Description
send ROC<cr>	Output the rate-of-change readings for H ₂ and H ₂ O (daily, weekly and monthly ROC for each parameter).
send a<cr>	Output a single measurement message with the following parameters: <ul style="list-style-type: none"> • T • RS • aw • H₂O • H₂
Example (transmitter in stop mode, no address needed):	
<pre>send T= 45.1 'C RS= 10.0 % H2O= 13.9 ppm aw= 0.100 H2= 17 ppm</pre>	
Example (transmitter in poll mode, with address 10):	
<pre>send 10 T= 45.1 'C RS= 10.0 % H2O= 13.9 ppm aw= 0.100 H2= 17 ppm</pre>	
Example (transmitter in stop mode, output rate-of-change readings):	
<pre>> send roc ROCs: 61 H2: 0.7 1.6 3.7 H2O: -0.362 1.262 2.458 ></pre>	

7.4.2 Measurement output format commands

Table 19 **form** command

Syntax	Description
form<cr>	Show the currently used measurement format.
form /<cr>	Reset measurement format to default.
form [sss]<cr>	Set a new measurement format. sss = String consisting of modifiers and abbreviations for measured parameters. See Table 20 (page 57) and Table 21 (page 58) . Maximum length is 150 characters. Maximum length may be shorter when text strings are used.

Syntax	Description
	<p>Example (show currently used measurement format, default format shown here):</p> <pre>form 3.1 "T=" t " " U3 3.1 "RS=" rs " " U4 6.1 "H2O=" h2o " " U5 4.3 "aw=" aw " " 6.0 "H2=" h2 " " U5 \r \n</pre> <p>Output example (continuous output in RUN mode):</p> <pre>T= 45.0 'C RS= 10.0 % H2O= 13.9 ppm aw= 0.100 H2= 18 ppm</pre>
	<p>Example (change the order of the output to show H₂ first, with Modulus-65536 checksum at the end):</p> <pre>form 6.0 "H2=" h2 " " U5 3.1 "T=" t " " U3 3.1 "RS=" rs " " U4 6.1 "H2O=" h2o " " U5 4.3 "aw=" aw " " cs4 #r #n OK</pre> <p>Output example (continuous output in RUN mode):</p> <pre>H2= 18 ppm T= 45.0 'C RS= 10.0 % H2O= 13.9 ppm aw= 0.1 0E22</pre>
	<p>Example (show H₂O in ppm_w without decimals, with start of text (ASCII character 002) and end of text (003) ASCII codes, and without line feed and carriage return at the end):</p> <pre>form #002 6.0 "H2=" h2 " " U5 3.1 "T=" t " " U3 3.1 "RS=" rs " " U4 6.0 "H2O=" h2o " " U5 4.3 "aw=" aw " " #003 OK</pre> <p>Output example (continuous output in RUN mode):</p> <pre>H2= 18 ppm T= 45.0 'C RS= 10.0 % H2O= 14 ppm aw= 0.100</pre>

Table 20 Output parameters for **form** command

Measurement parameter	Abbreviation in form command
Relative saturation of water in oil, %RS	rs
Water activity in oil, aw (range 0.0 ... 1.0)	aw
Water content in oil, ppm _w	h2o
Water content in oil, ppm _w . 24 hour average.	h2oa
H ₂ O daily ROC, ppm _w .	h2od
H ₂ O weekly ROC, ppm _w .	h2ow
H ₂ O monthly ROC, ppm _w .	h2om

Measurement parameter	Abbreviation in form command
Hydrogen content in oil, ppm _v . One hour average.	h2
Hydrogen content in oil, ppm _v . 24 hour average.	h2a
H ₂ daily ROC, ppm _v .	h2d
H ₂ weekly ROC, ppm _v .	h2w
H ₂ monthly ROC, ppm _v .	h2m
Oil temperature, °C or °F	t

Table 21 Modifiers for **form** command

Modifier	Description
x.y	Length modifier (number of digits and decimal places).
#t	Tabulator.
#r	Carriage-return.
#n	Line feed.
" "	String constant, length 1 ... 15 characters.
#xxx	ASCII code value (decimal) of a special character; for example, #027 for ESC.
addr	Transmitter address (0 ... 254).
date	Uptime in days.
err	Error code, ASCII encoded hexadecimal notation.
sn	Transmitter serial number.
time	Uptime (hh:mm:ss).
ux	Name of the measurement unit using x number of characters (1 ... 9). For example, u3 shows the name of the measurement unit with three characters.
cs2	Modulus-256 checksum of message sent so far, ASCII encoded hexadecimal notation.
cs4	Modulus-65536 checksum of message sent so far, ASCII encoded hexadecimal notation.
csx	NMEA xor-checksum of message sent so far, ASCII encoded hexadecimal notation.



You can also use the backslash character \ instead of the hash character #.

Table 22 unit command

Syntax	Description
unit<cr>	Show the current temperature unit system (metric °C or non-metric °F).
unit [m n]<cr>	Change the temperature unit. m = Metric unit, °C n = Non-metric unit, °F
Example (show current unit and check the output):	
<pre>unit Units : Metric send T= 45.0 'C RS= 10.0 % H2O= 13.9 ppm aw= 0.100 H2= 18 ppm</pre>	
Example (change temperature unit from °C to °F and check the output):	
<pre>unit n Units : Non metric send T=113.0 'F RS= 10.0 % H2O= 13.9 ppm aw= 0.100 H2= 18 ppm</pre>	

7.4.3 Serial line communication commands

Table 23 addr command

Syntax	Description
addr<cr>	Show current device address and prompt for a new address. This device address is used in Modbus communication, and in Vaisala Industrial Protocol communication in POLL mode. <div style="border: 1px solid gray; padding: 5px; margin-top: 10px;"> The transmitter's data link address for DNP3 communication is configured with the dnp addr3 command, see Table 37 (page 68). </div>
addr [aaa]<cr>	Set new device address. aaa = address, 0 ... 255

Syntax	Description
Example (shows 0 as current address, enter 5 as the new address):	
<pre>addr Address : 0 ? 5</pre>	

Table 24 **c**lose command

Syntax	Description
close <cr>	Close the connection that was opened with the open command. This command cannot be used via the service port.
Example:	
<pre>close line closed</pre>	

Table 25 **o**pen command

Syntax	Description
open [aaa]	Connect to a transmitter that is in poll mode. aaa = transmitter address, 0 ... 255 If you do not know the address of the transmitter, use the ?? command to view the transmitter information. This command cannot be used via the service port.
Example (target transmitter in poll mode, with address 5):	
<pre>open 5 MHT410 5 line opened for operator commands</pre>	

Table 26 **s**delay command

Syntax	Description
sdelay <cr>	Show serial line transmission delay.
sdelay [delay]<cr>	Set a new serial line transmission delay. delay = 0 ... 255. Value corresponds to four milliseconds (for example, 5 = 0.020 second transmission delay) Note that setting a too short delay may result in missing characters at the beginning of the transmission (requirements vary depending on use case).

Syntax	Description
Example (set serial delay to 0.1 seconds using the delay value 25):	
<pre>sdelay 25 Serial delay : 25</pre>	

Table 27 seri command

Syntax	Description
seri<cr>	Show current serial line settings for the RS-485 line of the screw terminals. This command does not affect the service port settings.
seri [p b d s] <cr>	Set new serial line settings. The new settings will be taken into use when the transmitter is reset or powered up. b = baud rate (300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600) p = parity <ul style="list-style-type: none"> • n = none • e = even • o = odd d = data bits (7 or 8) s = stop bits (1 or 2) For Modbus, baud rate must be 9600 ... 57600 and parity must be none.
Example (show current settings):	
<pre>seri Baud P D S : 19200 N 8 1</pre>	
Example (set baud rate to 9600, and reset the transmitter take the new baud rate in use):	
<pre>seri 9600 N 8 1 Baud P D S : 9600 N 8 1 reset MHT410 / 1.2.0</pre>	

Table 28 **smode** command

Syntax	Description
smode <cr>	<p>Show current start-up operating mode for the RS-485 line of the screw terminals, and prompt to enter new mode.</p> <p>This command does not affect the service port settings. The service port is always in stop mode.</p>
smode [mode] <cr>	<p>Set the start-up operating mode for the RS-485 line of the screw terminals. The new mode is taken into use when the transmitter is reset or powered up.</p> <p>This command does not affect the service port settings. The service port is always in stop mode.</p> <p>Available modes:</p> <p>modbus = Default mode. Modbus protocol is used for communication on the RS-485 line of the screw terminals, including measurement output. See Overview of Modbus protocol support (page 39).</p> <p>dnp3 = DNP3 protocol. See DNP3 protocol (page 71).</p> <p>stop = Vaisala Industrial Protocol: no automatic output. All commands available.</p> <p>run = Vaisala Industrial Protocol: automatic output of measurement messages. You can stop the output with the s command, and recontinue with the r command.</p> <p>poll = Vaisala Industrial Protocol: no automatic output. Will respond to addressed send [aaa] command and ?? command. You can use other commands after opening a connection using an addressed open [aaa] command. Use the poll mode with RS-485 buses where multiple transmitters can share the same line.</p>
<p>Example (check current serial operating mode (default setting with Modbus mode in use)):</p> <pre>smode Serial mode : MODBUS</pre>	
<p>Example (set serial operating mode to poll, and reset the transmitter to start up in that mode):</p> <pre>smode poll Serial mode : POLL reset MHT410 / 1.2.0</pre>	

7.5 Analog output commands

Table 29 **aerr** command

Syntax	Description
aerr <cr>	Show error levels for the analog outputs channel by channel and prompt to enter a new value.
aerr [ch1 ch2 ch3]<cr>	Set new error levels for analog outputs. ch1 = Error level of the analog output for channel 1. ch2 = Error level of the analog output for channel 2. ch3 = Error level of the analog output for channel 3. When you set new error levels, make sure they are outside the scaled output range 4 ... 20 mA (or 4.0 ... 21.6 mA if aover extension is on, see Table 30 (page 63)).
Example (show current error levels, default levels shown here):	
<pre>aerr Ch1 error out : 3.500 mA ? Ch2 error out : 3.500 mA ? Ch3 error out : 3.500 mA ?</pre>	
Example (set the error level to 21 mA on all channels):	
<pre>aerr 21 21 21 Ch1 error out : 21.000 mA Ch2 error out : 21.000 mA Ch3 error out : 21.000 mA</pre>	

Table 30 **aover** command

Syntax	Description
aover <cr>	Check whether the high end of the analog outputs is extended by 10 percent of the range (from 20 mA to 21.6 mA).
aover [off on]<cr>	Enable or disable the analog output overrange extension. off = The range of the analog outputs is 4 ... 20 mA. on = The range of the analog outputs is 4 ... 21.6 mA. The scaling of the outputs is not affected.

Syntax	Description
<p>Example (check whether the analog output range is extended (extension is off), and enable the extension):</p> <pre> aover AOVER : OFF aover on AOVER : ON </pre>	
<p>For example, channel 3 outputs temperature with output 4 ... 20 mA (-40 ... 100 °C). After giving the aover on command, the range is 4 ... 21.6 mA (-40 ... 124 °C). Note that the 100 °C point is still at 20 mA.</p>	
<p>Figure 5 Analog output overrange behavior</p>	

Table 31 **asel** command

Syntax	Description
asel <cr>	Show analog output parameters and scaling and prompt to enter new scaling.
asel ? <cr>	Show analog output parameters and scaling without prompting to enter new scaling.

Syntax	Description
<pre> asel [ch1 ch2 ch3] [ch1low ch1high ch2low ch2high ch3low ch3high]<cr> </pre>	<p>Set analog output parameters and scaling.</p> <p>ch1 = Output parameter for channel 1.</p> <ul style="list-style-type: none"> • rs = relative saturation of water, %RS • aw = water activity (range 0.0 ... 1.0) • h2o = H₂O concentration in oil, ppm_w • h2 = H₂ concentration in oil, ppm_v • t = temperature, °C • h2oa = H₂O concentration in oil (24 h average), ppm_w • h2od = H₂O daily ROC, ppm_w • h2ow = H₂O weekly ROC, ppm_w • h2om = H₂O monthly ROC, ppm_w • h2a = H₂ concentration in oil (24 h average), ppm_v • h2d = H₂ daily ROC, ppm_v • h2w = H₂ weekly ROC, ppm_v • h2m = H₂ monthly, ppm_v <p>ch2 = Output parameter for channel 2. The options are the same as for channel 1.</p> <p>ch3 = Output parameter for channel 3. The options are the same as for channel 1.</p> <p>Optional:</p> <p>ch1low = Low limit for channel 1 output scaling.</p> <p>ch1high = High limit for channel 1 output scaling.</p> <p>ch2low = Low limit for channel 2 output scaling.</p> <p>ch2high = High limit for channel 2 output scaling.</p> <p>ch3low = Low limit for channel 3 output scaling.</p> <p>ch3high = High limit for channel 3 output scaling.</p> <p>The default scaling of H₂O and H₂ ROC readings is as follows:</p> <ul style="list-style-type: none"> • H₂O daily, weekly, and monthly ROC: -50 ... 50 ppm_w • H₂ daily, weekly, and monthly ROC: -500 ... 500 ppm_w
<p>Example (show current parameters and scaling for each channel and prompt to enter new scaling):</p>	
<pre> asel Ch1 RS lo : 0.00 % ? Ch1 RS hi : 100.00 % ? Ch2 T lo : -40.00 'C ? Ch2 T hi : 100.00 'C ? Ch3 H2 lo : 0.00 ppm ? Ch3 H2 hi : 5000.00 ppm ? </pre>	


Syntax	Description
Example (show current parameters and scaling for each channel without prompting to enter new scaling):	
<pre>> aSEL ? Ch1 RS lo : 0.00 % Ch1 RS hi : 100.00 % Ch2 T lo : -40.00 'C Ch2 T hi : 100.00 'C Ch3 H2 lo : 0.00 ppm Ch3 H2 hi : 5000.00 ppm</pre>	
Example (change channel 1 to output water activity, adjust scaling to 0 ... 1 for channel 1, and to 0 ... 2000 ppm _v for channel 3):	
<pre>aSEL aw t h2 0 1 -40 100 0 2000 Ch1 aw lo : 0.00 Ch1 aw hi : 1.00 Ch2 T lo : -40.00 'C Ch2 T hi : 100.00 'C Ch3 H2 lo : 0.00 ppm Ch3 H2 hi : 2000.00 ppm</pre>	
Example (change channel 3 to output H ₂ weekly ROC):	
<pre>aSEL aw t h2w Ch1 aw lo : 0.00 ? Ch1 aw hi : 1.00 ? Ch2 T lo : -40.00 'C ? Ch2 T hi : 100.00 'C ? Ch3 H2W lo : -500.00 ppm ? Ch3 H2W hi : 500.00 ppm ?</pre>	
	<p>If you change the output parameters, the scaling for each channel is set to default and you are prompted to enter new low and high limits for each channel. If you do not want to change one of more of the default limits, press Enter at those prompts.</p>

Table 32 **atest** command

Syntax	Description
atest [ch1 ch2 ch3]	<p>Set analog channel to defined output value (in mA). You can then measure the output with a calibrated multimeter.</p> <p>ch1 = Output level for channel 1 in mA. ch2 = Output level for channel 2 in mA. ch3 = Output level for channel 3 in mA.</p>

Syntax	Description
Example (enable analog output test mode, set level to 20 mA on all channels):	
<pre>atest 20 20 20 Analog output test mode: ON CH1: 20.000 mA CH2: 20.000 mA CH3: 20.000 mA</pre>	
Example (disable analog output test mode, resume normal output):	
<pre>atest Analog output test mode: OFF CH1: 7.568 mA CH2: 13.714 mA CH3: 4.038 mA</pre>	

7.6 Calibration and adjustment commands

Table 33 **cdate** command

Syntax	Description
cdate <cr>	Show the date of the last adjustment.
cdate [yyyymmdd]<cr>	Set a new calibration and adjustment date (format "yyyymmdd").
Example (show current calibration date):	
<pre>cdate Cal. date : 20150201</pre>	
Example (set new calibration date):	
<pre>cdate 20150630 Cal. date : 20150630</pre>	

Table 34 **ctext** command

Syntax	Description
ctext <cr>	Show adjustment information text.
ctext [text]<cr>	Set a new calibration and adjustment information text.

Syntax	Description
Example (show current calibration text):	
<pre>ctext Cal. info : Vaisala</pre>	
Example (set new calibration text):	
<pre>ctext H2 cal DGA lab sample Cal. info : H2 cal DGA lab sample</pre>	

Table 35 **h2 da** and **h2 db** commands

Syntax	Description
See H 2 calibration and adjustment (page 85) .	<p>Calibrate and adjust H₂ measurement. When you start the adjustment, normal measurement stops temporarily and the transmitter goes into error state. Measurement returns to normal when you exit the H₂ adjustment mode.</p> <p>After the adjustment, set the adjustment date and information using the cdate and ctext commands.</p>

Table 36 **h2 x** command

Syntax	Description
See Clearing H 2 calibration and adjustment (page 88)	<p>Clears the H₂ calibration and adjustment data. Removes the adjustment applied with the h2 da and h2 db commands and restores the factory calibration. This adjustment will take effect immediately and is applied to all future H₂ readings.</p>

7.7 Other commands

Table 37 **dnp3 addr** command

Syntax	Description
dnp3 addr [aaa]<cr>	<p>Change the data link address of the transmitter in DNP3 communication.</p> <p>aaa = Data link address of the transmitter</p>
See DNP3 protocol (page 71) and Taking DNP3 protocol into use (page 71) .	

Table 38 **filt** command

Syntax	Description
filt [f.fff]<cr>	<p>Set the speed at which the latest moisture and temperature measurement (approximately one measurement per second) is integrated into readings.</p> <p>The command affects both analog output and serial line output. This command does not affect the H₂ reading.</p> <p>f.fff = Measurement filtering factor setting, range 0.001 ... 1.0. The default value is 1.0 (no filtering).</p> <p>When filtering is used, the output is calculated based on the following formula: $\text{output} = [(\text{new (unfiltered) measurement} \times \text{filtering factor}) + (\text{previous output} \times (1.0 - \text{filtering factor}))]$</p> <p>With filtering factor value 1 the transmitter takes only the latest measurement into account, but with filtering factor value 0.1 the new output is a combination of previous measurements (90%) and the latest measurement (10%).</p> <p>Filtering factor value examples:</p> <ul style="list-style-type: none"> • 1.0 = No filtering, the latest measurement is output directly without integrating previous measurements. • 0.5 = The reading output shows ~75% of the measurement change after two one-second measurement cycles and ~93% after four cycles. • 0.1 = The reading output shows ~90% of the measurement change after 22 measurements.
filt<cr>	Shows the current setting and prompts for a new value.
<p>Example (view the current value and set filtering factor value to 0.5):</p> <pre> filt Filter : 1.000 ? 0.5 </pre>	

Table 39 **frestore** command

Syntax	Description
frestore<cr>	<p>Restore factory settings. Clears all user settings, including serial communication settings, transmitter address, and analog output configurations.</p> <p>H₂ calibration remains.</p>
<p>Example:</p> <pre> frestore Factory settings restored </pre>	

Table 40 **reset** command

Syntax	Description
reset <cr>	Reset the transmitter. The transmitter will restart as if it had just been powered on.
Example:	
<pre>reset MHT410 / 1.0.0</pre>	

Table 41 **oil** command

Syntax	Description
oil <cr>	View oil-specific parameters (oil coefficients A and B) for moisture ppm _w calculation. Leave current values in place by pressing <cr> at the prompt. See Moisture ppm w calculation for transformer oils (page 113) .
oil <cr>	Set oil-specific parameters for moisture ppm _w calculation by entering oil coefficients A (Oil[0]) and B (Oil[1]) when prompted.
Example:	
<pre>oil oil[0] : -1662.6999 ? oil[1] : 7.3694 ?</pre>	

Table 42 **h2 is** command

Syntax	Description
See Re-installing the transmitter in new location (page 35) .	Initialize the device after it has been re-installed in a new location.

8. DNP3 protocol

MHT410 can be used as a DNP3 outstation (starting from software version 1.2.0). It supports serial communication only. Serial communication is based on RS-485 hardware, and therefore MHT410 can be used in multidrop topology.

The MHT410 device profile files for DNP3 are available for download at www.vaisala.com/mht410.

DNP3 protocol is available from the RS-485 line of the MHT410 screw terminals, which can support only one protocol at a time (DNP3, Modbus, or Vaisala Industrial Protocol). The factory default protocol is Modbus. To take DNP3 to use, you must change the communication protocol and other DNP3-related settings via the MHT410 service port, using Vaisala Industrial Protocol commands.

Table 43 Default communication settings

Setting	Factory default	Options
Communication protocol	Modbus	DNP3, Modbus, Vaisala Industrial Protocol
Communication parameters	Baud rate: 19200 Parity: None Number of data bits: 8 Number of stop bits: 1	Baud rate: 300, 600, 1200, 4800, 9600, 19200, 38400, 57600 Parity: None Number of data bits: 8 Number of stop bits: 1, 2
Data link address	4	0 ... 32767
Host address	3	0 ... 32767

More information

- [Connecting to MHT410 via service port \(page 41\)](#)

8.1 Taking DNP3 protocol into use

1. To active the DNP3 communication mode, type `smode dnp3` in the terminal window and press Enter.
Example:

```
smode dnp3
Serial mode : DNP3
```

- Optional: To change the baud rate or number of stop bits, type `seri [baud rate] N 8 [number or stop bits]` and press Enter.
 - Baud rate options: 300, 600, 1200, 4800, 9600, 19200 (default), 38400, 57600
 - Stop bit number options: 1 (default), 2

Example (set baud rate to "38400" and number of stop bits to "2"):

```
seri 38400 N 8 2
Baud P D S      :    38400 N 8 2
```



Do not change the other communication parameters: parity ("N") or number of data bits ("8"). If you change these settings, DNP3 communication will not work on MHT410.

- Optional: To change the data link address (default: 4), type `dnp3 addr [data link address]` and press Enter.

Data link address range: 0 ... 32767

Example (change data link address to "10"):

```
dnp3 addr 10
DNP3 ADDR      :          4 -> 10
DNP3 HOST      :           3
```



The DNP HOST setting is currently not used. The current implementation of the DNP3 protocol on MHT410 only sends responses to the host that sends a request.

- To save the settings, reset the transmitter by typing `reset` and pressing Enter.

```
reset
MHT410 / 1.2.0
```

- Close the PuTTY terminal application.
- Disconnect the USB cable from the service port, and close the transmitter cover.

9. Vaisala MI70 Handheld Indicator

You can use the MI70 handheld indicator as a temporary display for the transmitter.

MI70 shows the readings for all the parameters measured by the transmitter. You can also view the trend of the measurement on the graphical display, and compare the moisture and temperature readings of MHT410 to a Vaisala MM70 reference probe.



The MI70 indicator is intended to be used as display only. You cannot use MI70 to configure and calibrate MHT410.

To configure the transmitter, use Vaisala Industrial Protocol (see [Vaisala Industrial Protocol \(page 40\)](#)). For H₂ calibration instructions, see [H 2 calibration and adjustment \(page 85\)](#).

9.1 MI70 indicator overview

9.1.1 MI70 indicator parts









Figure 6 MI70 indicator parts

- 1 Charger socket
- 2 Function key shortcut buttons . The functions change according to what you are doing with the indicator.
- 3 Arrow buttons:
 -  Move up in a menu
 -  Move down in a menu
 -  Enter a sub-menu
 -  Return to previous menu level
- 4 Power On/Off button
- 5 Battery compartment at the back of the indicator
- 6 2 ports (labeled I and II) for connecting probes and instruments.

To open menus, press an arrow button and then press the shortcut buttons. To activate a function shown above the shortcut button, press the shortcut button. To navigate in the menus, press the arrow buttons.

9.1.2 Basic display




Figure 7 MI70 basic display

- 1 Measured parameter and compensations (up to three items on display simultaneously). You can change the shown items in **Main menu > Display > Quantities and units**.
- 2 Battery indicator. Shows current status (charge) of the battery.
- 3 Function key **Graphic** shows the readings as a curve.
- 4 Function key **Hold/Save** freezes the display and you can save the reading in the MI70 memory.
- 5 Function key **Record** is a quick access to the **Recording/Viewing** menu.

You can change the default function key shortcuts (**Graphic**, **Hold/Save**, **Record**) to other menus or functions in **Main menu > Settings > User interface > Program shortcut keys**.

9.1.3 Graphical display

The graphical display shows you the measurements as a curve (the curve of the uppermost parameter shown in the basic display). From the curve you can examine the data trend and history of the last minutes.

To open the graphical display, select **Graphic** in the basic display or select **Main menu > Display > Graphic history > Show**.

To get the statistical info on the graph area (minimum, maximum, and average values), press **Info**.

To get the curve of the other selected parameters, press **Next**. To get the curves of all the parameters, press **Next** until the text **All** appears, and then select **All**.

To zoom in and out, press the up/down arrow buttons.

To move back and forward in the timeline, use the left/right arrow buttons.

9.1.4 Main menu

To open the main menu:

- ▶ 1. Go to the basic display.
- 2. Press any arrow key, then select **OPEN**.

In the main menu, you can configure the MI70 settings and basic display. You can also perform certain operations with the transmitter.

More information

- [Holding and saving the display \(page 76\)](#)
- [Recording data \(page 77\)](#)
- [Comparing readings with MM70 probe \(page 78\)](#)

9.2 Installing and recharging MI70 batteries

If you are using **alkaline** batteries, unscrew the back plate of the indicator and insert the batteries. Do not attempt to recharge standard alkaline batteries.

If you ordered MI70 with a **rechargeable** battery, it is already in place as shipped from the factory. The delivered batteries have been pre-charged.

To recharge the rechargeable battery:

- ▶ 1. Plug in the charger connector to the MI70 indicator. The socket is located at the top of the indicator, covered by a rubber seal.
- 2. Connect the charger to a wall socket. An animated battery icon in the left corner of the display indicates that the battery is charging. The recharge duration (typically 4 ... 5 h) depends on the charge level of the battery.



A new battery takes approximately 3 charging cycles to reach its maximum capacity.



Do not store the batteries empty. Empty batteries may not charge after an extended storage period.

9.3 Connecting MI70 to service port



- MI70 indicator or MM70 meter (includes MI70 indicator, a moisture-in-oil probe, and a ball valve)
- Connection cable (Vaisala item code 219980)
- Power supply for MHT410

- ▶ 1. Open the screws on the transmitter cover, and open the cover.
2. Connect cable 219980 to the service port connector on the transmitter and to port I or II of the MI70 indicator.
3. Switch the MI70 indicator on.

9.4 Holding and saving the display

With the **Hold/Save** function, you can freeze a certain display reading. This reading can be saved in the MI70 memory and it will be available even after MI70 is disconnected from the transmitter.

- ▶ 1. In the basic display, select **Hold/Save**. Alternatively, select **Main menu > Display > Hold/Save display > Hold**.
2. Press **Save**.
3. To view the saved display, go to basic display and select **Record > View recorded data**. Alternatively, select **Main menu > Recording/Viewing > View recorded data**.

A list of saved displays and data recordings appears. The icons on the left of the date and time indicate whether the file is a saved display or a longer recording of data:




Saved display



Data recording

4. Select the saved display based on date and time by pressing the right arrow button.



9.5 Recording data

With MI70, you can record transmitter measurement data over a certain period at chosen intervals. These recordings are saved in the MI70 memory and are available even after MI70 is disconnected from the transmitter. To start recording, select the **Record** function key in the basic display, or navigate to the recording menu: **Main menu > Recording/Viewing > Record data**.

9.5.1 Starting and stopping the recording

You can record the measurement of the parameters that are currently shown on the MI70 basic display. You can change the shown parameters in **Main menu > Display > Quantities and units**.

- ▶ 1. In the basic display, select **Record > Record data**. Alternatively, select **Main menu > Recording/Viewing > Record data**.
- 2. If needed, change the interval and duration of the recording in the **RECORD DATA** view. The measurement intervals and maximum recording times are shown in the following table.


Recording interval	Maximum recording time (= memory full)		
	1 parameter	2 parameters	3 parameters
1 s	45 min	22 min	15 min
5 s	3 h	113 min	75 min
15 s	11 h	5 h	3 h
30 s	22 h	11 h	7 h
1 min	45 h	22 h	15 h
5 min	9 days	4 days	3 days
15 min	28 days	14 days	9 days
30 min	56 days	28 days	18 days
1 h	113 days	56 days	37 days
3 h	339 days	169 days	112 days
12 h	1359 days	678 days	451 days



If you set the duration to "Memory full", the recording continues until the MI70 memory is full or until you stop the recording manually. The maximum recording time is shown when you start the recording.

3. Select **Start/Stop recording > Start**.

The recording continues until the duration has passed or until you stop the recording manually.










You can switch the MI70 off during recording to save battery. A progress bar  is shown on the display every 10 seconds (or all the time, if a charger is connected). The progress bar shows the amount of recorded data.









CAUTION! Do not disconnect the probe when the data recording is on, even if the indicator is off. This may cause loss of recorded data.

4. To stop the recording manually, in the basic display select **Record > Record data > Start/stop recording > Stop**. To view the recorded file, select **Show**.

9.5.2 Viewing recorded data

- ▶ 1. Open the menu by pressing   **Open**.
2. Select **Recording/Viewing** and press .
3. Select **View recorded data** and press .
4. Select the file you want to view and press . The files are identified according to the starting date and time of recording.
5. To go to the graphical view, press  **Graph**. To view the recording time stamps, press  **Times**. To return to the recording values, press  **Values**.
6. To return to the basic display, press  **Exit**.

9.5.3 Clearing data memory

- ▶ 1. Open the menu by pressing   **Open**.
2. Select **Recording/Viewing** and press .
3. Select **Clear data memory** and press  **Clear**. To confirm the deletion, press  **Yes**.
4. To return to the basic display, press  **Exit**.

9.6 Comparing readings with MM70 probe



- Vaisala HUMICAP® Handheld Moisture Meter for Oil MM70

You can use MI70 to compare the measurement readings of MHT410 to an MM70 reference probe.

The indicator shows the readings from both devices at the same time. You can also show the difference in reading for water activity (Δa_w) and temperature (ΔT).

- ▶ 1. Install the MM70 probe in the same transformer as MHT410. For instructions, see the MM70 User's Guide (available at www.vaisala.com/mm70).
2. Turn off the MI70 indicator.
3. If MHT410 is not connected to MI70, connect it to one of the MI70 ports (I or II).
4. Connect the MM70 probe to the other MI70 port.
5. Turn on MI70.

The basic display now shows the readings from both devices. The port of the device is indicated next to the measured parameter. You can change the shown parameters in **Main menu > Display > Quantities and units**.




Figure 8 Example of MI70 display with MHT410 in port I and MM70 probe in port II. Shown parameters: a_w (I), a_w (II), Δa_w .

9.7 Changing the rechargeable battery pack




- New rechargeable battery pack
- Medium-sized flat head screwdriver

In case you are installing a rechargeable battery pack in the MI70 indicator and you have a device with alkaline batteries, remove the metal contact from the probe port end of the battery compartment before installing the battery pack.

- ▶ 1. Open the back plate of the indicator by opening the screw of the back plate.
2. Remove the old battery pack. Detach the black connector by carefully pulling it up from the wires.

3. Connect the black connector of the new battery pack. Make sure the position of the connector is as shown in the following figure (red and black wires are on the upper edge of the connector). Do not push the connector with conducting material.



4. Place the battery pack in the compartment.
5. Close the back plate and tighten the screw.
6. Recharge the indicator before use.

10. Vaisala Indigo520 Transmitter

Starting from MHT410 software version 1.3.0, the MHT410 transmitter can be connected to an Indigo520 transmitter for powering and communication. The Indigo520 transmitter can act as a local display for MHT410, and also provide its measurements as analog output signals or as Modbus protocol messages.

The Indigo520 connection is available from the RS-485 line of the MHT410 screw terminals. The connection through the screw terminals can support only one protocol at a time (DNP3, Modbus, or Vaisala Industrial Protocol). An MHT410 connected to Indigo520 cannot be connected to another host system via its own serial line. However, the analog signals in the MHT410 remain available.

For instructions on connecting a computer to MHT410 to change the MHT410 communication settings, see [Connecting to MHT410 via service port \(page 41\)](#).

Table 44 MHT410 communication settings for Indigo520

Setting	Factory default	Valid for Indigo520 use
Communication protocol	Modbus	Modbus
Communication parameters	Baud rate: 19200 Parity: None Number of data bits: 8 Number of stop bits: 1	Baud rate: 19200 Parity: None Number of data bits: 8 Number of stop bits: 2

10.1 Taking Indigo520 Modbus settings into use in MHT410

1. To activate the Modbus communication mode, type `smode modbus` in the terminal window and press Enter.
Example:

```
smode modbus
Serial mode : MODBUS
```

2. To change the baud rate or number of stop bits, type `seri 19200 N 8 2` and press Enter.
Example:

```
seri 19200 N 8 2
Baud P D S : 19200 N 8 2
```


- 3. To save the settings, reset the transmitter by typing `reset` and pressing Enter.

```
reset
MHT410 / 1.x.x
```

- 4. Close the PuTTY terminal application.
- 5. Disconnect the USB cable from the service port, and close the transmitter cover.

10.2 Cabling and cable gland

Vaisala offers a 10-meter (33-feet) cable for connecting MHT410 to Indigo520 (Vaisala item code CBL210968-10MSP). In Indigo520, the cable is designed to be inserted through the default M16×1.5 cable gland of probe 1. The recommended maximum length of the probe cable is 30 m (98 ft).



1 Indigo520 probe 1 lead-through, M16×1.5

In MHT410, the correct M20×1.5 cable gland must be used for a secure connection. You can check the size of the factory-installed cable gland from the 5th character of the order code in the MHT410 product label.



1 MHT410 order code example. The 5th character indicates the size of the cable gland.

If the 5th character is **4**, this means that MHT410 has the M20×1.5 cable gland compatible with cable CBL210968-10MSP. If not, the right cable gland is available as a spare part (Vaisala item code ASM213670SP).

If you are using a custom cable between MHT410 and Indigo520, make sure that:

- The cable is maximum 30 m (98 ft) in length
- The cable has enough free wires to fulfill the wiring diagram as per [Figure 9 \(page 83\)](#). Any excess wires should be properly isolated.
- The cable diameter is compatible with the cable glands installed in both MHT410 and Indigo520
- The cable is shielded.

Whether you are using the Vaisala cable CBL210968-10MSP or a custom cable, see [Electrical installation \(page 28\)](#) on how to install the cable and connect shielding in MHT410.

10.3 Indigo520 and MHT410 wiring diagram




Figure 9 Wiring between Indigo520 and MHT410 screw terminals

Indigo520 screw terminal	MHT410 screw terminal	Wire color in Vaisala cable CBL210968-10MSP
Probe 1, 24 VOUT+	VS+	Pink
Probe 1, 24 VOUT-	VS-	Brown
Probe 1, RS-485+	D+	Green
Probe 1, RS-485-	D-	Yellow
Probe 1, 24 VOUT-	RS GND	White ¹⁾
Not connected	Not connected	Gray

1) Shown in the figure above with a dashed line.

10.4 MHT410 status messages shown in Indigo520

Table 45 MHT410 status messages shown in Indigo520

Error	Description	Recommended action
Firmware checksum mismatch	Firmware is corrupted	Reboot MHT410. Wait for the status LED to turn solid green, and check the operation of the transmitter. Contact Vaisala technical support.
Ambient temperature out of range	Measured temperature is outside the error limits (below -45 or above +125 °C (below -49 or above +257 °F)).	Ensure that the operating temperature is within the valid range -40 ... +120 °C (-40 ... +248 °F). Contact Vaisala technical support.
Humidity measurement error	Readings from the humidity sensor are missing or out of range.	Reboot MHT410. Wait for the status LED to turn solid green, and check the operation of the transmitter. Contact Vaisala technical support.
Temperature measurement error	Temperature measurement raw value is outside the allowed range.	
Hydrogen measurement error	H ₂ module has reported an error.	

In case of constant error, please contact Vaisala. For contact information, see [Technical support \(page 115\)](#).

10.5 Settings in Indigo520

The available interfaces in the Indigo520 transmitter depend on the configuration of the device. For changing the Indigo520 settings, see *Indigo520 User Guide* (M212287EN).

11. Calibration and adjustment

MHT410 is fully calibrated and adjusted as shipped from the factory.

11.1 H₂ calibration and adjustment

You can calibrate MHT410 for H₂ by comparing the H₂ reading on the MHT410 to the H₂ concentration of a laboratory-analyzed DGA oil sample. There is no need to remove the transmitter from the transformer to perform calibration and adjustment.

In the calibration procedure, you take a DGA oil sample from the transformer and save the H₂ concentration measured by the transmitter at that time. When you have analyzed the H₂ concentration of the sample, you enter the analyzed H₂ reading to MHT410. The transmitter then implements the adjustment to the H₂ measurement.

More information

- [Calibration and adjustment commands \(page 67\)](#)
- [Taking DGA sample and saving current H2 reading \(page 85\)](#)
- [Entering DGA H2 reading to transmitter \(page 87\)](#)
- [Clearing H2 calibration and adjustment \(page 88\)](#)

11.1.1 Taking DGA sample and saving current H₂ reading



- Tools for taking a DGA oil sample
- Connection to the transmitter using Vaisala Industrial Protocol in one of the following ways:
 - Service port (see [Connecting to MHT410 via service port \(page 41\)](#))
 - RS-485 line of the screw terminals (User Port is configured for Modbus by default: to enable command entry, connect to the transmitter via Service Port and switch the operating mode of the screw terminals (see [Table 28 \(page 62\)](#)))



In the following instructions, the keyboard input by the user is in **bold** type.



When you start the H₂ adjustment mode with the **h2** command, normal measurement stops temporarily and the transmitter goes into error state. Measurement returns to normal when you exit the H₂ adjustment mode.

- ▶ 1. Take the DGA oil sample from the transformer.

- Open the connection on Vaisala Industrial Protocol (see [Connecting to MHT410 via service port \(page 41\)](#)).
- Start the adjustment mode with the command **h2**. The transmitter starts outputting H₂ measurement data.

```
h2
SSN=b11.04rt.10432tn1x, FW=3.85F , MDN=104400-FF02-P1, DF=0xB4B4v,
L.
..
```

- Stop the output by pressing the **Esc** key:

```
...
7997.00 34.0852 50.11176 186.69 2654140 2652818 23
0.0 0 22.2649 0 0 wait
<"ESC key">
H2scan:
```

- Save the H₂ reading with the **da** command:

```
H2scan: da
Current H2 value is 14.4 ppm...wait...
```

- When the H₂ measurement output resumes, exit the adjustment mode by pressing the **+ key**:

```
...
79842.00 33.8725 50.11766 186.97 2654214 2652858 359
14.4 0 28.5654 200 200 wait <"+" key">
Quit hydrogen measurement module command line operation
```



Do not exit the adjustment mode before the H₂ measurement output has resumed.
If the H₂ output does not resume automatically, issue the command **g** and the command **v** to start the H₂ output, and then exit the adjustment mode.

11.1.2 Entering DGA H₂ reading to transmitter



- Connection to the transmitter using Vaisala Industrial Protocol in one of the following ways:
 - Service port (see [Connecting to MHT410 via service port \(page 41\)](#))
 - RS-485 line of the screw terminals (User Port is configured for Modbus by default: to enable command entry, connect to the transmitter via Service Port and switch the operating mode of the screw terminals (see [Table 28 \(page 62\)](#)))



When you start the H₂ adjustment mode with the **h2** command, normal measurement stops temporarily and the transmitter goes into error state. Measurement returns to normal when you exit the H₂ adjustment mode.

- ▶ 1. Open the connection on Vaisala Industrial Protocol (see [Connecting to MHT410 via service port \(page 41\)](#)).
2. Start the adjustment mode with the command **h2**. The transmitter starts outputting H₂ measurement data.

```
h2
SSN=b11.04rt.10432tn1x, FW=3.85F , MDN=104400-FF02-P1, DF=0xB4B4v,
L
...
```

3. Stop the output by pressing the **Esc** key:

```
...
7997.00 34.0852 50.11176 186.69 2654140 2652818 23
0.0 0 22.2649 0 0 wait
<"ESC key">
H2scan:
```

4. Enter the DGA H₂ reading with the **db** command:

```
H2scan: db
Enter actual hydrogen in ppm: 10
Set hydrogen to 10.0ppm (Y/N)? y
Enter Today's Date:
Month: 4
Day: 14
Year: 2015
...wait...
```

5. When the H₂ measurement output resumes, exit the adjustment mode by pressing the **+** key:

```
...
79842.00 33.8725 50.11766 186.97 2654214 2652858 359
10.0 10 28.5654 200 200 wait <" + key">
Quit hydrogen measurement module command line operation
```



Do not exit the adjustment mode before the H₂ measurement output has resumed.

If the H₂ output does not resume automatically, issue the command **g** and the command **v** to start the H₂ output, and then exit the adjustment mode.

6. Enter the calibration date and information using the **cdate** and **ctext** commands. For example:

```
cdate 20150630
Cal. date : 20150630
ctext H2 cal DGA lab sample
Cal. info : H2 cal DGA lab sample
```

11.1.3 Clearing H₂ calibration and adjustment



- Connection to the transmitter using Vaisala Industrial Protocol in one of the following ways:
 - Service port (see [Connecting to MHT410 via service port \(page 41\)](#))
 - RS-485 line of the screw terminals (User Port is configured for Modbus by default: to enable command entry, connect to the transmitter via Service Port and switch the operating mode of the screw terminals (see [Table 28 \(page 62\)](#)))



When you start the H₂ adjustment mode with the **h2** command, normal measurement stops temporarily and the transmitter goes into error state. Measurement returns to normal when you exit the H₂ adjustment mode.

- ▶ 1. Open the connection on Vaisala Industrial Protocol (see [Connecting to MHT410 via service port \(page 41\)](#)).

2. Start the adjustment mode with the command **h2**. The transmitter starts outputting H₂ measurement data.

```
h2
SSN=b11.04rt.10432tn1x, FW=3.85F , MDN=104400-FF02-P1, DF=0xB4B4v,
L
...
```

3. Stop the output by pressing the **Esc** key:

```
...
7997.00 34.0852 50.11176 186.69 2654140 2652818 23
0.0 0 22.2649 0 0 wait
<"ESC key">
H2scan:
```

4. Clear the hydrogen calibration data and adjustments with the **x** command. The command removes the adjustment applied with the **h2 da** and **h2 db** commands and restores the factory calibration. This adjustment will take effect immediately and is applied to all future hydrogen readings.

```
H2scan: x
Clear dissolved gas offset values (Y/N)? y
...wait...Done.
```

5. When the H₂ measurement output resumes, exit the adjustment mode by pressing the **+** key:

```
...
79842.00 33.8725 50.11766 186.97 2654214 2652858 359
10.0 10 28.5654 200 200 wait <"+" key">
Quit hydrogen measurement module command line operation
```



Do not exit the adjustment mode before the H₂ measurement output has resumed.
If the H₂ output does not resume automatically, issue the command **g** and the command **v** to start the H₂ output, and then exit the adjustment mode.

11.2 RS & T calibration and adjustment

MHT410 is calibrated at the factory for RS and T. In normal transformer conditions, the moisture in oil sensor is very stable and regular RS and T calibration is not needed. Moisture in oil can be checked, for example, when taking an oil laboratory sample, or when checking with a handheld indicator.

The reference oil sample should be taken near the MHT410 in order to get a sample that matches the measurement conditions of the MHT410 sensor. The same also applies to handheld reference checks. If changes are suspected, MHT410 can be sent to Vaisala for RS and T calibration.

For more information on the calibration and adjustment services provided by Vaisala, visit the Vaisala calibration website at www.vaisala.com/calibration.



When installing the handheld reference probe inside the transformer, it may take up to 24 hours for the moisture readings to stabilize. An insufficient stabilization time may lead to incorrect results. To get the best results with handheld measurements, always make them under flowing conditions when possible.

12. Troubleshooting

12.1 Error states

MHT410 has the following states that indicate a problem with the transmitter:

- Error indication on analog outputs at 3.5 mA (default):
 - With hydrogen measurement errors, the hydrogen channel is in error state.
 - With moisture in oil measurement errors, the moisture in oil channel is in error state.
 - With temperature measurement errors, the temperature and moisture in oil channels are in error state.
 - With general errors, all three channels are in error state.
- Error messages on the serial line:
 - Modbus statuses (see [Table 63 \(page 111\)](#))
 - Vaisala Industrial Protocol error list

In case of constant error, please contact Vaisala. For contact information, see [Technical support \(page 115\)](#).

Table 46 Possible error messages via Vaisala Industrial Protocol

Error number and text	Description	Action
0001 Temperature measurement error	Temperature measurement raw value is outside the allowed range.	Reboot MHT410. Wait for the status LED to turn solid green, and check the operation of the transmitter.
0002 Frequency measurement error	Moisture measurement raw value is outside the allowed range.	Contact Vaisala technical support.
0004 H2 measurement error	H ₂ module has reported an error.	
0008 H2 module communication error	No message was received from H ₂ module in the last 5 seconds.	
0010 RH sensor failure	Readings from the humidity sensor are missing or out of range.	
0020 Temperature too high/low	Measured temperature is outside the error limits (below -45 or above +125 °C (below -49 or above +257 °F)).	
		Ensure that the operating temperature is within the valid range -40 ... +120 °C (-40 ... +248 °F). Contact Vaisala technical support.

Error number and text	Description	Action
0040 Program flash CRC error	Internal transmitter failure.	Contact Vaisala technical support.
0080 Parameter flash check sum error		
0100 INFOA check sum error		
0200 SCOEF5 check sum error		
0400 CURRENT check sum error		
0800 DEFAULT (factory) check sum error		
1000 General flash failure W/R		

12.2 Changing bleed screw

If oil starts flowing out from the bleed screw on the mounting nut, tighten the bleed screw. If oil still flows out, change the bleed screw.



- New bleed screw (provided in the MHT410 installation kit)
- Medium wrench (36 mm)
- Large wrench (50 mm)
- Allen key (3 mm, provided in the MHT410 installation kit)

- ▶ 1. Remove the transmitter. See [Removing the transmitter \(page 34\)](#).
2. Remove the bleed screw from the mounting nut.
3. Clean the mounting nut of any oil.
4. Install a new bleed screw and tighten it firmly.
5. Remove the old PTFE tape from the mounting nut.
6. Re-install the transmitter. See [Mechanical installation \(page 21\)](#).

13. Technical data

13.1 MHT410 specifications

Table 47 MHT410 measurement performance

Property	Description/Value
Hydrogen	
Measurement range (in oil)	0 ... 5000 ppm _v
Accuracy ^{1) 2)}	±10 % of reading or ±15 ppm _v (whichever is greater)
Repeatability	±10 % of reading or ±15 ppm _v (whichever is greater)
Minimum detection limit	15 ppm _v
Typical long-term stability	3 % of reading / year
Cross sensitivity to other gases	< 2 % (CO ₂ , C ₂ H ₂ , C ₂ H ₄ , CO)
Response time	63 % of full response: 2 h (when sensor is not in reference cycle)
Warm-up time	2 h, 12 h for full specification
Sensor	Catalytic palladium-nickel alloy film solid-state sensor
Moisture in oil	
Measurement range (in oil)	0 ... 100 %RS / a _w 0 ... 1
Response time (90 % of full response at +20 °C (+68 °F) in still oil)	10 min
Sensor	HUMICAP® 180L2
Accuracy (including non-linearity, hysteresis, and repeatability):	
0 ... 90 %RS	±2 %RS (a _w ± 0.02)
90 ... 100 %RS	±3 %RS (a _w ± 0.03)
Temperature	
Measurement range	-40 ... +120 °C (-40 ... +248 °F)
Accuracy at +20 °C (+68 °F)	±0.2 °C (0.36 °F)

Property	Description/Value
Sensor	Pt1000 RTD Class F0.1 IEC 60751

- 1) *The accuracy specified is the accuracy during calibration against gas in oil standard. Field performance may be affected, for example, by variation in hydrogen solubility (partition coefficients) between different mineral oils.*
- 2) *The accuracy specified is applicable in the oil temperature specified (-20 ... +75 °C (-4 ... +167 °F)).*

Table 48 MHT410 operating environment

Property	Description/Value
Oil type	Selected when ordering, available options: ¹⁾ <ul style="list-style-type: none"> • Mineral oil • Natural ester oil • Synthetic ester oil • Silicone oil
Oil temperature	-20 ... +75 °C (-4 ... +167 °F)
Operating temperature (electronics)	-40 ... +60 °C (-40 ... +140 °F)
Storage temperature	-40 ... +60 °C (-40 ... +140 °F)
Operating humidity	0 ... 100 %RH, condensing
Pressure tolerance (probe, short-term)	Max. 10 bara
Pressure tolerance (probe, continuous)	Max. 4 bara
Temperature tolerance, sensor head	-40 ... +120 °C (-40 ... +248 °F)
Integrated protection for short power outages	> 3 s

- 1) *Changing the oil type that MHT410 measures requires reconfiguration at Vaisala.*

Table 49 MHT410 inputs and outputs

Property	Description/Value
Operating voltage	15 ... 30 V DC, 24 V AC (±15 %) (power supply input is galvanically isolated) ¹⁾
Power consumption	Typical 4 W, maximum 12 W
Recommended external power supply	24 V DC / 0.5 A minimum
Analog output (current) ¹⁾	
Channels	3 isolated 4 ... 20 mA (loop-powering required)
External load	Max. 500 Ω

Property	Description/Value
Error status indication in case of device error	3.5 mA default, user-configurable for each channel
mA output accuracy at +20 °C (+68 F)	±0.125 % full scale
Temperature dependence of the analog outputs	±0.006 % / °C full scale
Digital outputs ¹⁾	
Interfaces	Isolated RS-485 half-duplex RS-485 (Service Port)
Protocols	Modbus RTU, DNP3, serial ASCII commands
Screw terminals	Wire size AWG 22-14 Single wire (solid) 1.5 mm ² Stranded wire (flex.) 1.0 mm ² Recommended wire torque 0.4 Nm

1) Max. isolation voltage 1.5 kV DC.

Table 50 MHT410 mechanical specifications

Property	Description/Value
Mechanical connection on transmitter	1.5" NPT (male)
Cable gland (optional, for use with Indigo520)	M20×1.5 for cable diameter 5 ... 9 mm (0.20 ... 0.35 in)
Cable gland (optional)	M20×1.5 for cable diameter 8 ... 11 mm (0.31 ... 0.43 in)
Cable gland (optional)	M20×1.5 for cable diameter 11 ... 14.5 mm (0.43 ... 0.57 in)
Conduit fitting (optional)	1/2" NPT
Interface cable (optional, pre-assembled)	5 m (16 ft 5 in), 9.2 mm (0.36 in) outer diameter
Interface cable (optional)	10 m (33 ft), 9.2 mm (0.36 in) outer diameter
Interface cable (optional, for use with Indigo520)	10 m (33 ft), 6.2 mm (0.24 in) outer diameter
Housing material	AlSi 10 Mg
IP rating	IP66: Dust-tight. Protected from powerful water jets from any direction.
Transmitter weight without cables	4.1 kg (9.04 lb)
Self-diagnostics indication	Status LEDs, analog output, Modbus

Property	Description/Value
Integrated data logging capabilities	Non-volatile memory, up to 44 years' storage with default logging
Individual functional test reports	Calibration test reports for moisture, hydrogen, and temperature; probe leak test report (5 bara nominal)
Factory warranty	5 years

Table 51 MHT410 compliance

Property	Description/Value
EU directives	EMC Directive (2014/30/EU) RoHS Directive (2011/65/EU)
EMC compatibility	EN 61326-1, industrial environment CISPR 32 / EN 55032, Class B (when DC powered)
Compliance marks	CE, EAC, RCM, WEEE

Table 52 Display with relays (external option)

Property	Description/Value
Pre-configured range for hydrogen	0 ... 5000 ppm _v
Pre-configured alarm relays (user-reconfigurable)	Relay 1 trigger limit 200 ppm _v (hi) Relay 2 trigger limit 1500 ppm _v (hihi)
Input	4 ... 20 mA, loop-powered
Accuracy	0.05 % of span (-10 ... +60 °C (-14 ... +140 °F))
Relays	2 × solid state (SSR) Max. 250 V AC, 150 mA
Display	4-digit red LED, 14.5 mm
Dimensions (H × W × D)	100 × 100 × 57 mm (3.94 × 3.94 × 2.24 in)
Case protection	IP65: Dust-tight. Protected from water jets from any direction.
Case material and color	ABS plastic, grey
Cable glands	2 × M16×1.5

13.2 Spare parts and accessories

Table 53 MHT410 spare parts and accessories

Item	Item code
USB cable for PC connection	219690
External DIN rail power 100 ... 240 V AC / 95 ... 220 V DC to 24 V DC	242422
5 m shielded PUR cable	CBL210392-5MSP
10 m shielded PUR cable	CBL210392-10MSP
Cable gland	214728SP
Detachable screw terminal block	236620SP
Loop-powered external display, Nokeval 302 (with alarm relays)	242003
M170 connection cable	219980
Conduit fitting	214780SP
1.5-inch NPT ball valve with welding fitting	BALLVALVE-3SET

13.3 Dimensions




Figure 10 MHT410 transmitter dimensions

13.4 Wiring diagrams




Figure 11 Wiring Option 1: Wiring with four power supplies. Separate loop-powering and galvanic isolation for analog outputs. In transmitters ordered with Vaisala cable CBL210392-5M, the cable is pre-wired according to this option.

Table 54 Vaisala cable CBL210392-5M wire colors (when pre-wired)

Terminal	Wire color
+CH3	Green
-CH3	White-Green
+CH2	White
-CH2	Gray-White
+CH1	Yellow
-CH1	White-Yellow
RSGND	Purple
D-	Black
D+	Yellow-Brown
+V _s	Red




Figure 12 Wiring Option 2: Wiring with two power supplies. Common loop-powering and galvanic isolation for analog outputs.




Figure 13 Wiring Option 3: Wiring with one power supply. Non-isolated configuration for analog outputs sharing transmitter power supply.




Figure 14 Wiring Option 4: Wiring with one power supply. Alternative wiring to option 3, providing reduced current loop area for analog outputs.

13.5 Recycling



Recycle all applicable material.



Disposal of Vaisala products is to be done according to local laws and regulations. We encourage end-users to segregate the products from other waste at end-of-life and use best available recycling practices to minimize related environmental impacts.

Almost all of the parts in our products can be recovered as material or energy. If applicable, Vaisala recommends removing the battery unit before recycling the rest of the device as typical electronic waste. The battery unit can be recycled separately in accordance with local waste management practices and regulations. Integrated small sized batteries are typically left in place and removed by professionals at the recycling facilities.




Figure 15 Materials for recycling

Table 55 Materials for recycling

Part		Materials
Packaging		
Product package		Cardboard
Padding foam		Polyethylene
Device parts		
1	Electronics housing and front cover	AlSi 10Mg
2	Product label	Polyester
3	Circuit board mounting plate	EN 1.4404
4	Flange gasket	Silicone
5	Probe shaft	Outer shaft: EN 1.4404 Inner plastic: Polyphenylene sulfide, glass-fiber reinforced
6	Ventilation valve	Polyester
7	Sealing ring	PTFE
8	Tightening nut	EN 1.4404
9	Mounting nut	EN 1.4404
10	Filter	EN 1.4404
11	Circuit board cover	Polypropylene
12	Terminal blocks	Polyamide PA66
13	Grounding cable	Copper wire
14	Plug for cable lead-through	Polyamide
15	Cable gland	Nickel-plated brass
16	Weather shield	EN 1.4404
17	Sorbent packet	Silica
18	Thread cap	LDPE
Screws		A4

Appendix A. Operating principle

Power transformers are critical components in the electric grid. Age, increased load levels and network failures all take a toll on transformers, increasing the risk of unpredicted faults and outages.

- Hydrogen levels and their rate of change indicate the severity of a fault situation.
- Moisture has a direct impact on the lifetime of a transformer. Oil moisture has a significant effect on transformer cellulose condition and the oil's ability to insulate. These changes in moisture levels can occur rapidly.

Continuously monitoring hydrogen and moisture levels with an in-situ transmitter is the first step in extending the life of a transformer through implementation of predictive maintenance practices leading to lower total cost of ownership.





Figure 16 Measuring hydrogen and moisture in oil with MHT410

The optimal locations for the MHT410 hydrogen, moisture and temperature sensors are presented in the following table.

Table 56 Optimal sensor positions

Installation location	Optimal sensor position
Valve in radiator pipe	<ul style="list-style-type: none"> • Moisture and temperature sensors are directly in the oil flow. This position is optimal because water molecule diffusion rate in oil is slow, and therefore moisture must be measured in moving oil. • Hydrogen sensor is in the valve area. This position is optimal because the hydrogen sensor needs an accurate temperature control, and therefore hydrogen must be measured in still oil.

Installation location	Optimal sensor position
Valve in transformer wall	<p>Tip of the probe is level with transformer inner wall. No part of the probe must enter the transformer chamber. All sensors remain within the valve area.</p> <div style="border: 1px solid black; padding: 10px; margin-top: 10px;">  <p>DANGER! Severe risk of death and of damage to transformer:</p> <p>Pay attention to transmitter installation depth and possible energized parts inside the power transformer to minimize electric shock hazard and equipment damage.</p> </div>

A.1 Method used for measuring moisture in oil

MHT410 measures water in oil in terms of relative saturation (%RS) which can be determined as follows: relative saturation indicates the amount of water in oil in the scale of 0 ... 100 %RS. In this scale, 0 %RS is an indication of completely water free oil and 100 %RS an indication of oil fully saturated with water. Water is present in free form.

The most advanced feature which distinguishes the measurement of relative saturation (%RS) from the traditional measurement of absolute water content (in ppm_w) is that the saturation point remains stable regardless of the oil type, aging of oil or additives used. As relative saturation exceeds 90 %RS in any system, there is a risk for segregation (especially if the temperature decreases). The relative saturation is used for alarming at the point of > 90 %RS that the risk for free water in the system is obvious.

The most important advantages of this system are the fact that relative saturation is immune to the aging of oil and to additives, and that the MHT410 transmitter can be used for continuous on-line measurements.

A.2 Transformer oil

The determination of moisture in oil is an essential part of a comprehensive transformer maintenance program. Aging and deterioration increase the capacity of oil to absorb water. The primary interest in transformers is to measure the water not in oil but in the cellulosic insulation around the transformer windings. The MHT410 method provides for a reliable detection of the aging of oil and possible leakages.

Moisture level in oil is a true indicator of moisture present in the paper insulation. Heating and cooling have a considerable effect on moisture levels in oil. The paper insulation around the transformer windings tends to lose moisture as temperature rises. This moisture is absorbed by the oil surrounding it.

Oil-immersed transformers rely on the oil for cooling, protection from corrosion and as an important component of their insulation. Excessive moisture content in oil causes accelerated aging of the insulation materials and reduces their dielectric strength. In extreme cases, this can result in arcing and short circuits within the windings. Accurate moisture measurements can also warn about leaks in the oil system, as water is absorbed from the surrounding air.

The water solubility of oil is also temperature dependent. In general, water solubility increases as temperature rises, see [Figure 17 \(page 106\)](#).




Figure 17 Water solubility of transformer oils versus temperature. The margins show the range of variation of water solubility found in mineral oils.

In addition, it must be noted that the capacity of oil to absorb water depends both on the chemical structure of the oil and the additives.

Appendix B. Modbus reference

B.1 Default Modbus communication settings

Table 57 Default Modbus RTU communication settings

Property	Specification
Serial bit rate	19200
Parity	None
Number of data bits	8 (read-only)
Number of stop bits	1
Modbus device address	240

B.2 Function codes

Conformance class 0 function codes are enough to access the measurement data and configuration settings of MHT410.

Device identification data can be read out only with the function code dedicated for that purpose (43 / 14).

Table 58 Supported Modbus function codes

Function code (decimal)	Function code (hexadecimal)	Name	Notes
03	03 _{hex}	Read Holding Registers	Class 0
43 / 14	2B _{hex} / 0E _{hex}	Read Device Identification	

B.3 Data encoding

In the data registers, the numeric values are available in one or two formats with separate register addresses: 32-bit IEEE floating point format and/or 16-bit signed integer format.



For values that have both 32-bit and 16-bit register available, use of the 32-bit register is recommended. Some values may exceed the signed 16-bit range even in normal operation.

B.3.1 32-bit floating point or 32-bit integer format

Registers using **32-bit float** data format are encoded using the **binary32** encoding defined in IEEE 754. The format is also known as "single-precision floating point format".

The least significant 16 bits of a floating point number are placed at the Modbus register listed in the table, while the most significant 16 bits are placed in the register with number/address + 1, as specified in Open Modbus TCP Specification, Release 1.0. This is also known as "little-endian" or "Modicon" word order.

Despite the specification, some Modbus masters may expect a "big-endian" word order (most significant word first). In such case, you must select "word-swapped" floating point format in your Modbus master for the Modbus registers of the device.

A complete 32-bit floating point or 32-bit integer value should be read and written in a single Modbus transaction.



CAUTION! Reading the measurement data registers with incorrect floating point format setting may occasionally result in correct-looking, but nevertheless incorrect values.



It is highly recommended to verify that you have configured the floating point format correctly on your Modbus host system by reading a floating point value from a test value register.

B.3.2 16-bit integer format

Some 16-bit integer values in the data registers are scaled to include the necessary decimals. The scaling factors for those values are shown in the register tables.

Table 59 Interpretation of 16-bit signed integer values

Value (decimal)	Value (hexadecimal)	Description
0 ... 32766	0000 _{hex} ... 7FFE _{hex}	Value in range 0 ... 32766
32767	7FFF _{hex}	Value is 32767 or larger
32768	8000 _{hex}	Value is not available
32769	8001 _{hex}	Value is -32767 or smaller
32770 ... 65535	8002 _{hex} ... FFFF _{hex}	Value in range -32766 ... -1 (2's complement)

B.4 Register map

All data available via the Modbus interface is grouped in three contiguous blocks of registers.

Table 60 Modbus register blocks

Register numbers	Data format	Description
1 ... 54	32-bit IEEE float	Measurement data (read only)
257 ... 271	16-bit signed integer	
513 ... 513	16-bit signed integer	Status registers (read-only)

B.5 Modbus registers

Registers are numbered in decimal, starting from 1. Register addresses in actual Modbus messages (Modbus Protocol Data Unit (PDU)) are in hexadecimal and start from zero. Register number 1 corresponds to address 0_{hex} in the actual Modbus message.



CAUTION! Reading the wrong register(s) may result in correct-looking values. Check the reference documentation of your Modbus host (PLC) to verify which notation it uses for Modbus register addresses.

B.5.1 Measurement data registers

Table 61 Modbus measurement data registers (read-only)

Register number	Address	Register description		Data format	Unit
1	0000 _{hex}	H ₂ , 1 hour average	LSW	32-bit float	ppm _v (in oil)
2	0001 _{hex}		MSW		
3	0002 _{hex}	H ₂ , 24 hour average	LSW	32-bit float	ppm _v (in oil)
4	0003 _{hex}		MSW		
5	0004 _{hex}	H ₂ , Daily ROC	LSW	32-bit float	ppm _v (in oil)
6	0005 _{hex}		MSW		
7	0006 _{hex}	H ₂ , Weekly ROC	LSW	32-bit float	ppm _v (in oil)
8	0007 _{hex}		MSW		
9	0008 _{hex}	H ₂ , Monthly ROC	LSW	32-bit float	ppm _v (in oil)
10	0009 _{hex}		MSW		
15	000E _{hex}	Oil moisture, relative saturation	LSW	32-bit float	%RS
16	000F _{hex}		MSW		

Register number	Address	Register description		Data format	Unit
17	0010 _{hex}	Oil moisture, current	LSW	32-bit float	ppm _w
18	0011 _{hex}		MSW		
19	0012 _{hex}	Oil moisture, 24 h average	LSW	32-bit float	ppm _w
20	0013 _{hex}		MSW		
21	0014 _{hex}	Oil moisture, Daily ROC	LSW	32-bit float	ppm _w
22	0015 _{hex}		MSW		
23	0016 _{hex}	Oil moisture, Weekly ROC	LSW	32-bit float	ppm _w
24	0017 _{hex}		MSW		
25	0018 _{hex}	Oil moisture, Monthly ROC	LSW	32-bit float	ppm _w
26	0019 _{hex}		MSW		
27	001A _{hex}	Oil temperature	LSW	32-bit float	°C
28	001B _{hex}		MSW		
257	0100 _{hex}	H ₂ , 1 h average		16-bit integer	ppm _v (in oil)
258	0101 _{hex}	H ₂ , 24 h average		16-bit integer	ppm _v (in oil)
259	0102 _{hex}	H ₂ , Daily ROC		16-bit integer	ppm _v (in oil)
260	0103 _{hex}	H ₂ , Weekly ROC		16-bit integer	ppm _v (in oil)
261	0104 _{hex}	H ₂ , Monthly ROC		16-bit integer	ppm _v (in oil)
264	0107 _{hex}	Oil moisture, relative saturation		16-bit integer	%RS*10
265	0108 _{hex}	Oil moisture, current		16-bit integer	ppm _w *10
266	0109 _{hex}	Oil moisture, 24h average		16-bit integer	ppm _w *10
267	010A _{hex}	Oil moisture, Daily ROC		16-bit integer	ppm _w *10
268	010B _{hex}	Oil moisture, Weekly ROC		16-bit integer	ppm _w *10
269	010C _{hex}	Oil moisture, Monthly ROC		16-bit integer	ppm _w *10
270	010D _{hex}	Oil temperature		16-bit integer	°C *10

PDU address	Actual address bytes used in a Modbus Protocol Data Unit
LSW	Least Significant Word (bits 15...0)
MSW	Most Significant Word (bits 31...16)
16-bit integer	Numeric value in range -32768...32767
32-bit float	Floating point number encoded according to IEEE 754

B.5.2 Status registers

Table 62 Modbus status registers (read-only)

Register number	Address	Register description	Data format
513	02 00 _{hex}	Device status bits	16-bit integer

Table 63 Modbus device status bits

Output (bit mask)	Output name	Notes
0	Status OK	
1	Critical Error active	Maintenance needed. Contact Vaisala technical support.
2	Error active	Device may recover automatically.
4	RH measurement error	Reboot MHT410. Wait for the status LED to turn solid green, and check the operation of the transmitter.
8	T measurement error	Contact Vaisala technical support.
16	H ₂ measurement error	
32	Other error	Contact Vaisala technical support.
64	H ₂ alarm level exceeded	



Multiple device statuses can be present simultaneously. In those cases, the value of the device status register is the sum of the applicable numbers, for example, 5 if a critical error (1) and an RH measurement error (4) are present simultaneously.

B.6 Device identification objects

Table 64 Device identification objects

Object ID	Object ID (hexadecimal)	Object name	Example contents
0	00 _{hex}	VendorName	"Vaisala"
1	01 _{hex}	ProductCode	"MHT410"
2	02 _{hex}	MajorMinorVersion	"1.2.3" Software version of the device.
3	03 _{hex}	VendorUrl	" http://www.vaisala.com/ "
4	04 _{hex}	ProductName	"Vaisala Moisture, Hydrogen and Temperature Transmitter MHT410 for Transformer Oil"
128	80 _{hex}	SerialNumber ¹⁾	"K0710040"
129	81 _{hex}	CalibrationDate ¹⁾	"2020-01-31" Calibration date in YYYY-MM-DD format. Empty string if not set/valid.
130	82 _{hex}	CalibrationText ¹⁾	"Vaisala/HEL" Calibration information text. Empty string if not set/valid.

1) *Vaisala-specific device information.*

B.7 Exception responses

Table 65 Modbus exception responses

Code	Name	Reason
01	ILLEGAL FUNCTION	Unsupported function code
02	ILLEGAL DATA ADDRESS	Register address or Object ID out of valid ranges
03	ILLEGAL DATA VALUE	Otherwise invalid request

Accessing unavailable (temporarily missing) measurement data does not generate a Modbus exception. "Unavailable" value (a quiet NaN for floating point data or 8000_{hex} for integer data) is returned instead. An exception is generated only for any access outside the applicable register ranges.

Appendix C. Moisture ppm_w calculation for transformer oils

Traditionally, moisture in transformer oil is measured in ppm_w units. The ppm_w output shows the average mass concentration of water in oil.

MHT410 has an option for ppm_w output.

C.1 Calculation model with average coefficients

The calculation model of MHT410 is based on the average water solubility behavior of transformer oils. The ppm_w output is calculated as follows:

$$ppm_w = a_w \times 10^{(A/(T+273.15)+B)}$$

a_w water activity

A, B coefficients (average or oil specific)

T temperature (°C)

Generally, moisture in oil measurement with MHT410 has an accuracy of ±2 ... 3 % of the reading. If additional accuracy is needed, see [Calculation model with oil-specific coefficients \(page 113\)](#).

C.2 Calculation model with oil-specific coefficients

For additional accuracy, an oil-specific calculation model can be used. An oil sample has to be sent to Vaisala for modeling. As a result, the specific coefficients (A and B: see formula in [Calculation model with average coefficients \(page 113\)](#)) for the transformer oil are determined by Vaisala. Using these coefficients increases measurement accuracy.

You can program the determined coefficients of the transformer oil to MHT410 using Vaisala Industrial Protocol (see [Table 41 \(page 70\)](#)), or contact Vaisala about setting the coefficients.

Maintenance and calibration services



Vaisala offers comprehensive customer care throughout the life cycle of our measurement instruments and systems. Our factory services are provided worldwide with fast deliveries. For more information, see www.vaisala.com/calibration.

- Vaisala Online Store at store.vaisala.com is available for most countries. You can browse the offering by product model and order the right accessories, spare parts, or maintenance and calibration services.
- To contact your local maintenance and calibration expert, see www.vaisala.com/contactus.

Technical support



Contact Vaisala technical support at helpdesk@vaisala.com. Provide at least the following supporting information as applicable:

- Product name, model, and serial number
- Software/Firmware version
- Name and location of the installation site
- Name and contact information of a technical person who can provide further information on the problem

For more information, see www.vaisala.com/support.

Warranty

For standard warranty terms and conditions, see www.vaisala.com/warranty.

Please observe that any such warranty may not be valid in case of damage due to normal wear and tear, exceptional operating conditions, negligent handling or installation, or unauthorized modifications. Please see the applicable supply contract or Conditions of Sale for details of the warranty for each product.

VAISALA

www.vaisala.com

