


User Guide

Vaisala Optimus™ DGA Monitor for
power transformers

OPT100



VAISALA

PUBLISHED BY

Vaisala Oyj
Vanha Nurmijärventie 21, FI-01670 Vantaa, Finland
P.O. Box 26, FI-00421 Helsinki, Finland
+358 9 8949 1
www.vaisala.com
docs.vaisala.com

© Vaisala 2022

No part of this document may be reproduced, published or publicly displayed in any form or by any means, electronic or mechanical (including photocopying), nor may its contents be modified, translated, adapted, sold or disclosed to a third party without prior written permission of the copyright holder. Translated documents and translated portions of multilingual documents are based on the original English versions. In ambiguous cases, the English versions are applicable, not the translations.

The contents of this document are subject to change without prior notice.

Local rules and regulations may vary and they shall take precedence over the information contained in this document. Vaisala makes no representations on this document's compliance with the local rules and regulations applicable at any given time, and hereby disclaims any and all responsibilities related thereto.

This document does not create any legally binding obligations for Vaisala towards customers or end users. All legally binding

obligations and agreements are included exclusively in the applicable supply contract or the General Conditions of Sale and General Conditions of Service of Vaisala.

This product contains software developed by Vaisala or third parties. Use of the software is governed by license terms and conditions included in the applicable supply contract or, in the absence of separate license terms and conditions, by the General License Conditions of Vaisala Group.

This product may contain open source software (OSS) components. In the event this product contains OSS components, then such OSS is governed by the terms and conditions of the applicable OSS licenses, and you are bound by the terms and conditions of such licenses in connection with your use and distribution of the OSS in this product. Applicable OSS licenses are included in the product itself or provided to you on any other applicable media, depending on each individual product and the product items delivered to you.

Table of contents

1.	About this document.....	9
1.1	Version information.....	9
1.2	Related manuals.....	10
1.3	Documentation conventions.....	10
1.4	Trademarks.....	11
1.5	Patent notice.....	11
2.	Product overview.....	12
2.1	Overview of OPT100 Optimus DGA Monitor.....	12
2.2	Basic features and options.....	12
2.3	Measured parameters.....	13
2.3.1	Total gas pressure measurement.....	14
2.3.2	Calculating relative moisture saturation inside transformer.....	14
2.4	Notes for normal operation.....	15
2.5	Parts with Ground Mounting Set.....	16
2.6	Parts with Wall Mounting Set.....	18
2.7	OPT100 cable glands and connectors.....	20
2.8	OPTPSU cable glands and connectors.....	21
2.9	Interior parts.....	22
2.10	Status LEDs.....	23
2.11	Gas level alerts.....	24
2.12	Modbus protocol.....	25
2.13	DNP3 protocol.....	25
2.14	IEC 61850 protocol.....	26
2.15	Protocol test mode.....	27
2.16	Autocalibration.....	28
3.	User interface.....	30
3.1	Overview of user interface.....	30
3.1.1	Connecting to user interface.....	30
3.1.2	User interface basics.....	32
3.1.3	Measurements page.....	35
3.1.4	DGA diagnostics page.....	38
3.1.5	Alerts page.....	41
3.1.6	Control pages.....	43
3.1.7	Service pages.....	44
3.1.8	Settings pages.....	46
3.1.9	About page.....	46
3.2	Changing administrator password.....	47
3.3	Starting measurement.....	49
3.4	Setting device name.....	49
3.5	Setting date and time.....	50
3.6	Configuring unit settings.....	52
3.7	Configuring autocalibration.....	53
3.8	Configuring gas level alerts.....	54
3.9	Muting gas level alerts.....	55

3.10	Configuring network connection.....	56
3.11	Configuring user interface security.....	57
3.12	Configuring Modbus protocol.....	59
3.13	Configuring DNP3 protocol.....	60
3.14	Configuring IEC 61850 protocol.....	61
3.15	Using protocol test mode.....	62
3.16	Configuring relays.....	64
3.17	Configuring offsets.....	65
3.18	Configuring custom averages.....	67
3.19	Deleting data.....	68
4.	Maintenance.....	70
4.1	Maintenance safety.....	70
4.2	Cleaning DGA monitor.....	70
4.3	Maintenance.....	71
4.4	Updating DGA monitor software.....	71
4.5	Starting autocalibration manually.....	73
4.6	Repair.....	73
4.6.1	Stopping measurement.....	74
4.6.2	Turning off the DGA monitor for maintenance.....	74
4.6.3	Verifying safety after repair.....	74
4.6.4	Turning on DGA monitor after maintenance.....	75
4.6.5	Starting measurement.....	75
4.7	Uninstalling DGA monitor.....	76
5.	Troubleshooting.....	81
5.1	Problem situations.....	81
5.2	System statuses.....	82
5.3	Device alerts.....	83
5.4	Resolving a measurement cycle fault.....	86
5.5	Generating a diagnostics package.....	88
5.6	Bleeding the DGA monitor.....	88
5.7	Installing the configuration package.....	90
6.	Technical specification.....	92
6.1	OPT100 technical specification.....	92
6.2	OPT100 accessories and spare parts.....	97
6.3	Dimensions with Ground Mounting Set.....	99
6.4	Dimensions with Wall Mounting Set.....	100
Appendix A:	Modbus reference.....	102
A.1	Default Modbus communication settings.....	102
A.2	Function codes.....	102
A.3	32-bit floating point or 32-bit integer format.....	102

A.4	Modbus registers.....	103
A.4.1	Measurement data registers.....	103
A.4.2	Alert registers.....	108
A.4.3	Status registers.....	112
A.4.4	Test value registers.....	112
A.5	Exception responses.....	113
A.6	Modbus communication examples.....	114
Index.....		117
Maintenance and calibration services.....		119
Technical support.....		119
Warranty.....		119
Recycling.....		119

List of figures

Figure 1	OPT100 front parts with Ground Mounting Set.....	16
Figure 2	OPT100 rear parts with Ground Mounting Set.....	17
Figure 3	OPT100 front parts with Wall Mounting Set.....	18
Figure 4	OPT100 rear parts with Wall Mounting Set.....	19
Figure 5	Cable glands and connectors on OPT100 cabinet.....	20
Figure 6	Cable glands and connectors on OPTPSU power supply unit.....	21
Figure 7	Inside DGA monitor cabinet.....	22
Figure 8	Inside Power Supply Unit cabinet (OPTPSU1 and OPTPSU2).....	23
Figure 9	Status LEDs.....	23
Figure 10	Protocol test mode enabled.....	27
Figure 11	Elements of the DGA monitor user interface.....	32
Figure 12	Alert summary message being shown.....	34
Figure 13	Measurement graph.....	35
Figure 14	Measurement graph for 1 day rate of change values.....	36
Figure 15	Total gas pressure graph.....	37
Figure 16	Table of latest values.....	38
Figure 17	Duval triangles on the DGA diagnostics page.....	39
Figure 18	Alerts page with active gas caution alert.....	41
Figure 19	Event details for a gas caution alert.....	42
Figure 20	DGA monitor Control page.....	43
Figure 21	Autocalibration page.....	44
Figure 22	Service tools page.....	45
Figure 23	Settings page.....	46
Figure 24	About page.....	47
Figure 25	Changing administrator password.....	48
Figure 26	General settings page.....	49
Figure 27	Date and time settings page.....	50
Figure 28	Unit settings page.....	52
Figure 29	Autocalibration page.....	53
Figure 30	Alert limits settings page.....	54
Figure 31	Alert page with methane caution alert visible.....	56
Figure 32	IP address settings page.....	56
Figure 33	Network security settings page.....	57
Figure 34	Modbus settings page.....	59
Figure 35	DNP3 settings page.....	60
Figure 36	IEC 61850 settings page.....	61
Figure 37	Protocol test mode enabled.....	62
Figure 38	Relay settings page.....	64
Figure 39	Configuring offsets in measurement settings.....	65
Figure 40	Offsets in Measurements.....	66
Figure 41	Configuring custom averages in measurement settings.....	67
Figure 42	Custom averages in Measurements.....	68
Figure 43	Deleting measurement data in settings.....	69

Figure 44	Measurement cycle fault active.....	86
Figure 45	OPT100 dimensions with Ground Mounting Set.....	99
Figure 46	OPT100 dimensions with Wall Mounting Set.....	100
Figure 47	Mounting dimensions of installation beams.....	101

List of tables

Table 1	Document versions (English).....	9
Table 2	Related manuals.....	10
Table 3	Applicable patents or applications.....	11
Table 4	Measured parameters.....	13
Table 5	Calculated parameters.....	13
Table 6	Status LEDs.....	24
Table 7	Modbus TCP communication settings.....	25
Table 8	Default Modbus RTU communication settings.....	25
Table 9	Types of autocalibration.....	28
Table 10	Data point selection criteria.....	40
Table 11	Troubleshooting table.....	81
Table 12	System statuses.....	83
Table 13	Device alerts.....	84
Table 14	OPT100 measurement specification.....	92
Table 15	OPT100 measurement operation.....	92
Table 16	OPT100 field performance.....	93
Table 17	OPT100 calculated parameters.....	93
Table 18	OPT100 operating environment.....	94
Table 19	OPT100 power supply.....	94
Table 20	OPT100 outputs.....	94
Table 21	OPT100 mechanical specifications.....	96
Table 22	OPT100 compliance.....	97
Table 23	OPT100 accessories.....	97
Table 24	OPT100 spare parts.....	97
Table 25	Modbus TCP communication settings.....	102
Table 26	Default Modbus RTU communication settings.....	102
Table 27	Supported function codes.....	102
Table 28	Measurement data registers (read-only).....	103
Table 29	Alert registers (read-only).....	109
Table 30	Status registers (read-only).....	112
Table 31	Test value registers (read-only).....	112
Table 32	Modbus exception responses.....	113

1. About this document

1.1 Version information

This document provides instructions for using, maintaining, and troubleshooting the Vaisala Optimus™ DGA Monitor OPT100.

Table 1 Document versions (English)

Document code	Date	Description
<i>M211858EN-T</i>	October 2022	Applicable from software version 1.17.0 onward. Updated sections: <ul style="list-style-type: none"> • Overview of OPT100 Optimus DGA Monitor (page 12) • Notes for normal operation (page 15) • OPTPSU cable glands and connectors (page 21) • Interior parts (page 22) • OPT100 technical specification (page 92)
<i>M211858EN-R</i>	June 2022	Applicable from software version 1.17.0 onward. Updated sections: <ul style="list-style-type: none"> • OPTPSU cable glands and connectors (page 21) • Service pages (page 44) Added sections: <ul style="list-style-type: none"> • Installing the configuration package (page 90)
<i>M211858EN-N</i>	April 2022	Applicable from software version 1.16.0 onward. Updated sections: <ul style="list-style-type: none"> • Measurement data registers (page 103) • Uninstalling DGA monitor (page 76) • OPT100 accessories and spare parts (page 97) Added sections: <ul style="list-style-type: none"> • Configuring custom averages (page 67) • Configuring offsets (page 65) • Deleting data (page 68)
<i>M211858EN-M</i>	November 2021	Applicable from software version 1.15.0 onwards. Updated sections: <ul style="list-style-type: none"> • About page (page 46) • System statuses (page 82) • Device alerts (page 83) • OPT100 technical specification (page 92) Added sections: <ul style="list-style-type: none"> • Service pages (page 44) • Bleeding the DGA monitor (page 88) • Generating a diagnostics package (page 88)

1.2 Related manuals



For the latest versions of these documents, see docs.vaisala.com.

Table 2 Related manuals

Document code	Name
M211857EN	OPT100 Installation Guide
M212595EN	Spare part instruction: Replacing MHT411 internal multigas transmitter
M212759EN	Spare part instruction: Replacing OPT100 solenoid valves

1.3 Documentation conventions



WARNING! Warning alerts you to a serious hazard. If you do not read and follow instructions carefully at this point, there is a risk of injury or even death.



CAUTION! Caution warns you of a potential hazard. If you do not read and follow instructions carefully at this point, the product could be damaged or important data could be lost.



Note highlights important information on using the product.



Tip gives information for using the product more efficiently.



Lists tools needed to perform the task.



Indicates that you need to take some notes during the task.

1.4 Trademarks

Vaisala® is a registered trademark of Vaisala Oyj.

OPTIMUS™ is a trademark of Vaisala Oyj.

Modbus® is a registered trademark of Schneider Automation Inc.

Chrome™ is a trademark of Google Inc.

Firefox® is a registered trademark of Mozilla Foundation.

Microsoft® and Edge® are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

All other product or company names that may be mentioned in this publication are trade names, trademarks, or registered trademarks of their respective owners.

1.5 Patent notice

This product is protected by the following patents and patent applications and their corresponding national rights:

Table 3 Applicable patents or applications

Issuing office	Patent number
Chinese Patent Office	ZL 201480064015.2
United States Patent and Trademark Office	US 10429371
	US 10101266
Finnish Patent Office	125907
	127084

2. Product overview

2.1 Overview of OPT100 Optimus DGA Monitor

Optimus DGA Monitor OPT100 is a device for monitoring the internal condition of an electrical transformer using dissolved gas analysis (DGA), also known as fault gas analysis. The device is intended to be installed next to the transformer, and connected to it by two oil lines. The device is suitable for outdoor or indoor use. The device draws oil from a transformer, measures the concentrations of hydrogen, moisture, and several hydrocarbons in the oil, and returns the oil back to the transformer.

Measurement results can be transferred via communication interfaces to the substation's SCADA (Supervisory Control And Data Acquisition) system. The data is also available for viewing by human operators through the browser-based user interface.

The OPT100 Optimus DGA Monitor consists of two separate units; the DGA monitor and the power supply unit. The DGA monitor contains the entire oil monitoring system and all control systems and is powered by 24 V DC. The power supply unit houses all mains parts and delivers 24 V DC operating voltage to the DGA monitor. Power supply unit is available for AC supply voltage and DC supply voltage.

More information

- [OPT100 technical specification \(page 92\)](#)

2.2 Basic features and options

- Measurement of seven fault gases, moisture in oil, and total gas pressure
- Several calculated parameters and gas ratios available
- Ethernet and RS-485 interfaces for SCADA integration
- Modbus protocol (RTU and TCP)
- Protocol test mode for verifying SCADA integration
- Three configurable relay outputs
- Gas level alerts for measured values and rate of change (ROC)
- IP66 rated cabinet
- Optional software features:
 - DGA diagnostics using Duval triangles
 - DNP3 (Distributed Network Protocol) over Ethernet or RS-485
 - IEC 61850 protocol over Ethernet
- Installation options:
 - Ground mounting set
 - Wall mounting set
 - Weather shield

2.3 Measured parameters

Table 4 Measured parameters

Parameter	Output unit(s)	Description
Methane (CH ₄)	ppm _v	Measured from extracted gas
Ethane (C ₂ H ₆)	ppm _v	Measured from extracted gas
Ethylene (C ₂ H ₄)	ppm _v	Measured from extracted gas
Acetylene (C ₂ H ₂)	ppm _v	Measured from extracted gas
Carbon monoxide (CO)	ppm _v	Measured from extracted gas
Carbon dioxide (CO ₂)	ppm _v	Measured from extracted gas
Hydrogen (H ₂)	ppm _v	Measured in-oil
Moisture (H ₂ O)	ppm _w and %RS	Measured in-oil as relative saturation (%RS). See Calculating relative moisture saturation inside transformer (page 14) .
Total gas pressure	hPa and psi	Measured from the sampled oil volume

Table 5 Calculated parameters

Property	Output unit(s)	Description
Total dissolved combustible gases (TDCG)	ppm _v	Combined total of H ₂ , CO, CH ₄ , C ₂ H ₆ , C ₂ H ₄ , and C ₂ H ₂ .
24 h average	ppm _v for gases ppm _w for moisture hPa and psi for total gas pressure	Available for single gases, moisture, TDCG, and total gas pressure
Rate of change (ROC)	ppm _v	Available for single gases and TDCG for 24 h, 7 d, and 30 d periods

Property	Output unit(s)	Description
Gas ratios for: <ul style="list-style-type: none"> • CH₄/H₂ • C₂H₂/C₂H₄ • C₂H₂/CH₄ • C₂H₆/C₂H₂ • C₂H₄/C₂H₆ • CO₂/CO 	Ratio	Ratio is calculated from 24 h average values of the gases

2.3.1 Total gas pressure measurement

Total gas pressure (TGP) is measurement parameter introduced in software version 1.12.0. Total gas pressure is the total dissolved gas pressure of the sampled oil volume, measured by the DGA monitor as part of its normal measurement cycle. The primary use of the TGP parameter is to determine if there is an air leak into a sealed transformer. In case of a leak, majority of the dissolved gases are nitrogen and oxygen, and the proportion of fault gases in the pressure value is negligible. The pressure trend of the dissolved gasses gives reliable indication of leak, as nitrogen is the dominant component, and it is not formed or consumed in reactions inside the transformer.

From software version 1.13.0 onward TGP measurement results (current value and 24 hour average) are available through output protocols, and TGP measurement can be used for gas alerts. TGP has its own separate graph view on page **Measurements > Total gas pressure**.

2.3.2 Calculating relative moisture saturation inside transformer



CAUTION! DGA monitor measures relative oil moisture (%RS) inside its cabinet. The temperature of the moisture sensor location does not represent the temperature inside the transformer tank or inside the oil circulation pipes. Additionally, oil sampling through the steel pipes changes the oil temperature. As relative moisture saturation is strongly **temperature dependent**, the %RS measured and output by DGA monitor is not equal to %RS inside the transformer tank.

However, DGA monitor does output both the measured %RS and the temperature where it was measured. To calculate the %RS in the true temperature inside the transformer, use the following equation.

$$\%RS_{T2} = \%RS_{T1} \times 10 \left(\frac{A(T2 - T1)}{(T1 + 273.15) \times (T2 + 273.15)} \right)$$

%RS_(T1) Relative moisture saturation output by DGA monitor

T1 Temperature of the in-oil measurement chamber inside DGA monitor

T2 Temperature at location where new relative moisture saturation is needed at

A -1662.70



A is a water solubility coefficient. Vaisala uses this standard value in all of its oil moisture transmitters. You can also use this equation with an oil-specific coefficient if it has been determined for your oil.

2.4 Notes for normal operation

In normal operation, the DGA monitor performs measurement cycles automatically without any operator involvement. Integration with a SCADA system is recommended for convenient monitoring of measurement results and system status. Status LEDs on the cabinet door indicate system status on a general level, and detailed status is available from the browser-based user interface.

For successful operation:

- Keep the doors of the DGA monitor cabinets closed and locked during normal operation. This keeps the inside of the DGA monitor clean and the measurement environment stable.
- Keep the measurement running continuously to achieve the best measurement performance.
- If the DGA monitor will be unpowered for a long time (due to a transformer maintenance, for example), set the system to **Standby**.
- Check that the power supply unit (OPTPSU) is on and that it is installed as instructed in [OPT100 Installation Guide \(M211857EN\)](#).

More information

- [Stopping measurement \(page 74\)](#)

2.5 Parts with Ground Mounting Set




Figure 1 OPT100 front parts with Ground Mounting Set

- 1 Status LEDs
- 2 OPT100 DGA Monitor
- 3 Door lock (3 pcs)
- 4 Power supply unit (OPTPSU)
- 5 Door lock
- 6 Mounting stand
- 7 Wedge anchors (6 pcs)




Figure 2 OPT100 rear parts with Ground Mounting Set

- 1 Weather shield
- 2 Cable glands and oil connections for DGA Monitor
- 3 Cable glands for power supply unit

More information

- [Dimensions with Ground Mounting Set \(page 99\)](#)

2.6 Parts with Wall Mounting Set




Figure 3 OPT100 front parts with Wall Mounting Set

- 1 Status LEDs
- 2 OPT100 DGA Monitor
- 3 Door lock (3 pcs)
- 4 Power supply unit
- 5 Door lock




Figure 4 OPT100 rear parts with Wall Mounting Set

- 1 Installation beam (upper)
- 2 Weather shield
- 3 Installation beam (lower)
- 4 Cable glands for DGA Monitor
- 5 Cradle for power supply unit
- 6 Cable glands for power supply unit

More information

- [Dimensions with Wall Mounting Set \(page 100\)](#)

2.7 OPT100 cable glands and connectors





Figure 5 Cable glands and connectors on OPT100 cabinet

#	Label	Description	Cable/pipe diameter	Wrench size
1	Oil Out	Oil return to transformer.	10 mm (0.39 in)	19 mm
2	Oil In	Oil intake from transformer.	10 mm (0.39 in)	19 mm
3		Ground connection.	4 ... 16 mm ² (12 ... 5 AWG) conductor	13 mm
4	RS-485	RS-485 connection.	5 ... 10 mm (0.20 ... 0.39 in)	20 mm
5	Relay control out	Relay control to OPTPSU. Use Vaisala cable CBL210539.	7 ... 12 mm (0.28 ... 0.47 in)	24 mm
6	DC in	DC input from OPTPSU. Use Vaisala cable CBL210544.	9 ... 16 mm (0.35 ... 0.63 in)	30 mm
7	Ethernet	Ethernet connection. Use shielded outdoor Ethernet cable. Assemble the included protection shell on the RJ45 connector.	-	-
8	Spare	Not reserved.	5 ... 10 mm (0.20 ... 0.39 in)	20 mm
9	Spare	Not reserved.	7 ... 12 mm (0.28 ... 0.47 in)	24 mm

2.8 OPTPSU cable glands and connectors





Figure 6 Cable glands and connectors on OPTPSU power supply unit

#	Label	Description	Cable diameter	Wrench size
1		Ground connection.	4 ... 16 mm ² (12 ... 5 AWG) conductor	13 mm
2	AC in (OPTPSU1)	Mains power input. 100 ... 240 V AC, 50 ... 60 Hz, 10 A.	9 ... 16 mm (0.35 ... 0.63 in) 0.5 ... 10mm ² (24 ... 6 AWG) conductor	30 mm
	DC in (OPTPSU2)	Mains power input. 110 ... 220 V DC, 6.3 ... 2.5 A.	9 ... 16 mm (0.35 ... 0.63 in) 0.5 ... 10mm ² (24 ... 6 AWG) conductor	30 mm
3	Spare	Not reserved.	5 ... 10 mm (0.20 ... 0.39 in)	20 mm
4	Spare	Not reserved.	5 ... 10 mm (0.20 ... 0.39 in)	20 mm
5	Relay out	Relay output, max 250 V AC, 10 A.	7 ... 12 mm (0.28 ... 0.47 in)	24 mm

#	Label	Description	Cable diameter	Wrench size
6	Relay control in	Relay control from DGA monitor. Use Vaisala cable CBL210539.	7 ... 12 mm (0.28 ... 0.47 in)	24 mm
7	DC out	DC output to DGA monitor, 24 V DC, 20 A. Use Vaisala cable CBL210544.	9 ... 16 mm (0.35 ... 0.63 in)	30 mm

2.9 Interior parts




Figure 7 Inside DGA monitor cabinet

- 1 Valve 5 (bleed valve). Must be manually accessed during initialization and uninstallation.
- 2 Valve 4
- 3 Oil block
- 4 Valve 2
- 5 Valve 3
- 6 Valve 1
- 7 In-oil measurement of hydrogen and moisture
- 8 Oil out
- 9 Oil in
- 10 Terminal blocks for RS-485 output (Y1) and relay control (Y2)
- 11 Circuit breakers: main breaker (F2) and breaker for heating power (F1)
- 12 Terminal block for DC in (Y3)
- 13 Surge arresters
- 14 Circuit breaker for auxiliary device (F3) (Y4)
- 15 Processing unit
- 16 Ethernet connectors:
 - ETH0** Connection for SCADA, wired to external Ethernet connector
 - ETH1** Service port for temporary local use, with IP address 192.168.28.2
- 17 Auxiliary device and terminal blocks (Y5)
- 18 Control unit
- 19 Optical measurement module for extracted gases




Figure 8 Inside Power Supply Unit cabinet (OPTPSU1 and OPTPSU2)

- 1 Circuit breaker for AC or DC power (F1)
- 2 Surge arresters
- 3 Power switch (S1)
- 4 Power supply
- 5 Relays (3 pcs). Each relay has a LED that is lit when the relay is active.
- 6 DC OK LED. If flashing, check DC output wiring.
- 7 DC out terminal block (X5)
- 8 Relay control terminal block (X4)
- 9 Relay output terminal block (X3)
- 10 Mains power in terminal block (X1)

2.10 Status LEDs




Figure 9 Status LEDs

Table 6 Status LEDs

Color	Meaning
Green	DGA monitor operates normally and performs measurement cycles.
Green (flashing)	DGA monitor is in standby mode, or running a service tool. Requires user interaction to begin measurement.
Yellow	DGA monitor requires user interaction. For example, a device warning is active, a service tool requires user input, or the DGA monitor is being initialized or uninstalled.
Yellow (flashing)	Gas level alert is active, caution limit exceeded.
Red	Device error is active. User interaction is required.
Red (flashing)	Gas level alert is active, alarm limit exceeded.

2.11 Gas level alerts

DGA monitor has a comprehensive selection of individual gas level alerts:

- 4 possible alerts for each measured gas and the total dissolved combustible gases (TDCG) parameter: latest measured value, ROC 1 day, ROC 7 days, and ROC 30 days.
- Total gas pressure (TGP) and moisture alerts (ppm and %RS) can be configured for the latest measured value.

Each alert has two separate limits, **caution** and **alarm**. The limits are maximum limits, and the alert is activated when the gas level is above the limit. As an exception, the TGP alert limits can also be defined as a **minimum limit**, which activates the alert when total gas pressure is below the limit value.

Active gas level alerts are seen in the user interface, status LEDs, and output protocols. They also control relay activation.

In addition to alert limits, DGA monitor implements additional rules to prevent unnecessary alerts:

- Only reliable measurement results can activate alerts. If the DGA monitor has been in the standby state, it must complete 3 measurement cycles before alarms can be activated.
- Alerts will not be activated during the initial autocalibration after installation.
- A single large jump in the measured value that exceeds the alert limit will not activate an alert. The previous measurement must be at least 75% of the latest measurement to activate an alert. If the measured value remains over the limit when the next measurement cycle is completed, the alert is activated.

Alerts are deactivated as follows:

- Alerts for gas concentration values are deactivated after 20 consecutive results have been below the alert limit.
- Alerts for rate of change (ROC) values are deactivated after the latest result is below 90% of the alert limit.

Gas level alerts can also be temporarily muted by the **Admin** user.

More information

- [Muting gas level alerts \(page 55\)](#)

2.12 Modbus protocol

Data measured by DGA monitor can be read using Modbus protocol. Supported Modbus variants are:

- Modbus TCP over the Ethernet interface
- Modbus RTU (serial Modbus) over the RS-485 interface

Table 7 Modbus TCP communication settings

Property	Specification
IP address of Modbus server	IP address of DGA monitor on interface ETH0
Modbus server port	502

Table 8 Default Modbus RTU communication settings

Property	Specification
Baud rate	19200
Parity	Even
Data bits	8
Stop bits	1
Modbus RTU slave address	240

More information

- [Modbus registers \(page 103\)](#)

2.13 DNP3 protocol



DNP3 protocol is an optional feature and requires a license. If a license is not installed on the DGA monitor, you cannot enable the protocol. Contact Vaisala for acquiring the license.

OPT100 DGA monitor provides the following functionality over DNP3 (Distributed Network Protocol):

- Latest measured values of measurement parameters and latest calculated rate of change (ROC) and gas ratio values are available as analog input points.
- Gas level alerts are available as binary input points.

- Time synchronization using DNP3 is supported. Note that time synchronization using DNP3 must be separately enabled, it is not automatically used.

DNP3 is supported over the Ethernet interface and the RS-485 interface, but DNP3 cannot be enabled for both interfaces at the same time.

You can download the DNP3 device profile in XML format from the **Settings > Network > DNP3** page of the user interface. It is needed to configure your DNP3 master system. A description of the interface is also available as a separate PDF document.

More information

- [Setting date and time \(page 50\)](#)

2.14 IEC 61850 protocol



IEC 61850 protocol is an optional feature and requires a license. If a license is not installed on the DGA monitor, you cannot enable the protocol. Contact Vaisala for acquiring the license.

Data measured by DGA monitor can be read using IEC 61850 protocol over the external Ethernet connection. IEC 61850 protocol can also be disabled if it is not needed.

The following supporting documents describe the data and functionality available through IEC 61850 protocol:

- IED Capability Description (ICD) file
- Protocol Implementation Conformance Statement (PICS)
- Model Implementation Conformance Statement (MICS)

You can download the documents from the OPT100 user interface at **Settings > Network > IEC 61850**.

2.15 Protocol test mode




Figure 10 Protocol test mode enabled

Protocol test mode overrides the data that is available to communication protocols with arbitrary test data. The mode is useful for verifying proper handling of data and alarms when integrating the DGA monitor with a SCADA system. The recommendation is to use the protocol test mode during commissioning, after the required output protocols have been configured and enabled.

Protocol test mode can only be used by the **Admin** user. When the mode is activated, the user is presented with a page that shows default test values for each output parameter, and allows values and alert statuses to be changed as desired.

Clicking **Close** on the page ends the protocol test mode immediately. The user can also select to end the test mode after a timeout. The available timeout values are:

- 1 h
- 3 h
- 6 h
- 12 h
- 24 h
- No timeout

Be careful if you use the **No timeout** option, as DGA monitor will remain in the test mode indefinitely until it is manually closed.



When the test mode is enabled, normal measurement operation of the DGA monitor continues in the background. Only the data available through the digital output protocols is affected. When the mode ends, real measurement data and alert status are again available through the protocols.

More information

- [Using protocol test mode \(page 62\)](#)

2.16 Autocalibration

The autocalibration feature of the DGA monitor improves measurement performance by adapting the measurement to the individual oil conditions of the transformer. Autocalibration is implemented as special type of measurement cycles that vary the parameters of the vacuum gas extraction. The process typically completes in two days, but may take longer if ambient temperature is high. After autocalibration is completed, the measurement algorithm is adjusted according to the analysis results, and normal measurement cycles are automatically resumed.

DGA monitor makes use of autocalibration in the following ways:

Table 9 Types of autocalibration

Autocalibration type	Description	Notes
Initial autocalibration	Initial autocalibration runs automatically after a DGA monitor has been initialized and measurement started. Initial autocalibration cannot be skipped, and it must complete successfully for DGA monitor to operate normally.	Measurement results generated during the initial autocalibration may not be accurate. Gas level alerts are not indicated during initial autocalibration via any means, including relays.
Manually started autocalibration	One-time autocalibration that is started manually by the Admin user.	Recommended after: <ul style="list-style-type: none"> • Transformer degassing or oil change • DGA monitor software update • DGA monitor repair if components of measurement electronics have been replaced

Autocalibration type	Description	Notes
Automatically started autocalibration	DGA monitor performs autocalibration when needed and when environmental conditions are suitable.	Ensures the long term accuracy of measurement results as measurement conditions change and transformer oil ages. Typical interval between autocalibrations is one month. If automatically started autocalibration is not desired, the feature can be disabled by the administrator user.



Measurement results generated during autocalibration cycles are indicated with a light blue background in measurement graphs. They are also marked in the CSV data that is exported using the **Download Data** function.

More information

- [Configuring autocalibration \(page 53\)](#)

3. User interface

3.1 Overview of user interface

DGA monitor runs a web server on its processing unit. The web server provides the user interface of the DGA monitor. Access the user interface through Ethernet and a web browser; no special software is needed.

Access rights are based on 2 fixed user accounts:

- **Admin:** full access for commissioning, configuration, and maintenance tasks. Requires password to log in. Browser session expires after 3 hours of inactivity.
- **User:** limited access for viewing data and system settings. Cannot configure or control the DGA monitor. Does not require a password. Browser session expires after one year of inactivity.

The same Ethernet network that connects to the SCADA system is used to access the user interface. Additionally, local access to the interface is provided by direct access to **ETH1** port of the processing unit.

3.1.1 Connecting to user interface




- Laptop computer with:
 - RJ45 Ethernet connector
 - Web browser (Google Chrome, Microsoft Edge, or Mozilla Firefox)
- Ethernet cable with RJ45 connectors for temporary use
- Administration password for this DGA Monitor

- ▶ 1. Connect your computer to the same network as the DGA monitor. If you are connecting locally, connect the network cable between your computer and the port marked **ETH1** on the processing unit inside the DGA monitor.
2. Open a web browser, and enter the IP address of the DGA monitor in the address bar:
 - If you connect locally through the ETH1 port, use the following IP address:
192.168.28.2
 - If you connect through the network meant for SCADA integration, use the IP address that has been assigned to the DGA monitor.
3. You will get a warning that your connection is not secure. This is expected and happens when connecting with a new device. The user interface of the DGA monitor is secured with a self-signed certificate by default. Continue despite the warning. HTTPS traffic is always encrypted even if the certificate is not trusted.

4. Choose the appropriate user level:

- Select **Admin** to perform installation and maintenance tasks.
- Select **User** to view data without making changes to the system.



VAISALA

Optimus™ OPT100 DGA Monitor

Log in to Optimus

User name
Admin

Password

Log in

© Vaisala - All rights reserved

5. If logging in as **Admin**, enter the password. The unique administration password of the DGA monitor is included in the delivery documentation but note that it can be changed by the **Admin** after a successful login.

No password is required for the **User** account.

6. Select **Log in**.

3.1.2 User interface basics





Figure 11 Elements of the DGA monitor user interface

- 1 Current time of the DGA monitor, adjusted to the browser's time zone. DGA monitor keeps UTC time (Coordinated Universal Time) internally.
- 2 Name of the currently selected user interface page
- 3 Navigation for subpages (if any)
- 4 Status indicator
- 5 Alert indicator
- 6 Access to locally stored online help system
- 7 Name of currently user account, and controls for password change (admin only) and logging out
- 8 Navigation menu
- 9 Content area for user interface pages
- 10 If device name has been set, it is shown here

3.1.2.1 Status indicator

Status indicator shows the current status of the DGA monitor. It is placed in the header at the top of the user interface.


For a DGA monitor that is operating normally and performing measurement, the status is  **Measuring**.

More information

- [System statuses \(page 82\)](#)

3.1.2.2 Alert indicator

Alert indicator shows the presence of active alerts. The colors of the indicator change according to the severity of the most severe currently active alert:



Light gray background:
no active alerts.



Orange background:
gas caution or device warning active.



Red background:
gas alarm or device error active.

Select the alert indicator to open the **Alerts** page.

3.1.2.3 Messages

User interface of the DGA monitor will display important information as messages at the top of the user interface.

- **Alert summary:** A summary of currently active alerts is shown when a user logs in to the user interface. If any alerts are active, proceed to the **Alerts** page to look up detailed information about the alert(s).
- **Changes to DGA monitor settings:** Success or failure of a settings change is indicated with a message.
- **Other notifications:** Any other messages from the DGA monitor. For example, a message will be shown when a new measurement cycle has been completed.




Figure 12 Alert summary message being shown

3.1.3 Measurements page

Measurements page provides views into the measurement data in graphical and tabular formats. **Gas measurements** tab shows the primary graph view.



Figure 13 Measurement graph

- 1 Graph area. Measurement data created during autocalibration is marked with a light blue background.
- 2 Zoom factor controls for y-axes. You can also use the mouse wheel to adjust the zoom level.
- 3 Pop-up that shows the values at the point below the cursor.
- 4 Quick selection buttons for preset time windows.
- 5 Drop-down menu for selecting the parameter set that is shown.
- 6 Control for selecting the behavior of the graph when you click and drag over the graph area. **Pan** moves the graph while keeping the same zoom level, **Box zoom** zooms in to the highlighted area when you release the mouse button.
- 7 Parameters that are shown on the left y-axis. Select the color tab to show or hide a parameter.
- 8 Time slider for selecting the time window shown in the graph area. To adjust the size of the time window, drag the edges of the slider. To move the time window, drag the slider.
- 9 Measurement parameters on the right y-axis. Drag individual parameters to this area to show them on the right y-axis. This is useful when one of the parameters has a different range of values than the rest.

Graph lines show empty gaps if data is missing from 2 consecutive measurement cycles or for more than 3 hours. Data may be missing for several reasons. For example, DGA monitor may have been turned off, in standby mode, or measurement cycles have not produced reliable results for some or all measurement parameters.




Figure 14 Measurement graph for 1 day rate of change values

Total gas pressure tab shows the total gas pressure measurement graph. Pressure measurement data is not provided during autocalibration cycles.

You can change the pressure unit that is used to display the graph on page **Settings > Units**.




Figure 15 Total gas pressure graph

Latest values tab shows the latest measured and calculated values as a single table. To download all of the measured data into a file, select **Download Data** at the bottom of the page. The format of the file is CSV (comma separated value), and you can easily import it into common spreadsheet programs.

Parameter	Measured	Avg 1 day	ROC 1 day	ROC 7 days	ROC 30 days
Gas measurements					
Methane CH ₄	12.3 ppm	9.2 ppm	+5.8 ppm	-3.3 ppm	-13.2 ppm
Acetylene C ₂ H ₂	0.4 ppm	0.2 ppm	0.0 ppm	-0.6 ppm	-1.4 ppm
Ethylene C ₂ H ₄	7.6 ppm	7.2 ppm	+2.3 ppm	-3.1 ppm	-5.5 ppm
Ethane C ₂ H ₆	60.6 ppm	57.5 ppm	+4.5 ppm	-35.1 ppm	-57.5 ppm
Carbon monoxide CO	5.1 ppm	6.2 ppm	+0.6 ppm	-4.1 ppm	+0.6 ppm
Carbon dioxide CO ₂	533 ppm	539 ppm	+1.9 ppm	-7.3 ppm	+15.1 ppm
Hydrogen H ₂	0.0 ppm	0.0 ppm	0.0 ppm	0.0 ppm	0.0 ppm
TDCG	86.0 ppm	80.2 ppm	+13.2 ppm	-47.4 ppm	-74.9 ppm
Moisture H ₂ O	22.9 ppm	20.6 ppm			
Moisture H ₂ O	20.5 %RS				
Temperature of in-oil measurement chamber	39.3 °C				
Gas pressure					
Total gas pressure	1104 hPa	1106 hPa			
Ratios					
CH ₄ / H ₂					
C ₂ H ₂ / C ₂ H ₄	0.03				
C ₂ H ₂ / CH ₄	0.02				
C ₂ H ₆ / C ₂ H ₂	287.50				
C ₂ H ₄ / C ₂ H ₆	0.13				
CO ₂ / CO	86.94				

Figure 16 Table of latest values

3.1.4 DGA diagnostics page



CAUTION! This software utilizes publicly available and commonly used dissolved gas analysis (DGA) method for transformer fault diagnostics purposes, Duval Triangles (IEC 60599, Annex B). Customer acknowledges and agrees that Vaisala shall not assume any risk or liability in connection with the use or application of the diagnostics data by the Customer or any other user of such data. The use and/or application of any such data shall be at the sole risk and liability of the Customer or the user.



DGA Diagnostics is an optional feature and requires a license. Contact Vaisala for acquiring the license.




Figure 17 Duval triangles on the DGA diagnostics page

DGA Diagnostics page shows the progression of selected data points from the past year overlaid on top of Duval triangles:

- **Triangle 1:** Classic Duval triangle for DGA in oil-filled transformers using methane, ethylene, and acetylene
- **Triangle 4:** Diagnosis of low-temperature faults in oil-filled transformers using hydrogen, methane, and ethane
- **Triangle 5:** Diagnosis of low-temperature faults in oil-filled transformers using methane, ethylene, and ethane

DGA monitor automatically selects the data points according to criteria described in section [Criteria for data points in DGA diagnostics \(page 40\)](#). The data points are listed in a table below the triangles. Clicking a table row highlights the data point in the overlay and displays the gas ratios as percentages.

3.1.4.1 Criteria for data points in DGA diagnostics

DGA Diagnostics view shows up to 26 data points from the past year. A data point that meets selection criteria is automatically selected at roughly two week intervals. If less than one year of data is available, all of the data is used.

The data points are 24 hour average values for the included gases and must meet the following criteria for each point:

- At least 5 reliable measurement points must exist in the previous 24 hours. Reliability criteria are the same as for gas alert functionality.
- At least one of the following conditions is true:
 - Concentration of all triangle 1 gases is higher than OPT100 accuracy as listed in [Table 10 \(page 40\)](#)
 - At least one of the triangle 1 gases is above the limit based on IEC 60599 as listed in [Table 10 \(page 40\)](#)

Table 10 Data point selection criteria

Gas	OPT100 accuracy specification in ppm	Limits based on IEC 60599
Acetylene(C ₂ H ₂)	2	4
Methane (CH ₄)	10	30
Ethane (C ₂ H ₆)	10	30
Ethylene (C ₂ H ₄)	10	30
Hydrogen (H ₂)	25	50



Data points are original measurements, not offset values.

3.1.5 Alerts page




Figure 18 Alerts page with active gas caution alert

Alerts page shows the current alert status of the DGA monitor.

1. View number of currently active gas level alerts and device alerts by severity.
2. See **Events** section for more information on the individual alerts. By default, only active alerts are listed.
 - a. To control what is shown, select the desired options for **Status**, **Type**, and **Severity**.
 - b. To temporarily suppress gas level alerts, press **Mute gas alerts**.
 - c. To view detailed information on a listed event, select **Details**. Details depend on the type of alert being viewed. Details for device alerts include information on resolving the alert.

You can also configure custom gas level alerts.

The screenshot shows the Vaisala OPTIMUS Alerts interface. The top navigation bar includes 'Measuring', 'Alerts', 'Help', and 'Admin'. The main content area displays a summary of alerts: 0 Gas alarms, 1 Gas cautions, 0 Device errors, and 0 Device warnings. A modal dialog box is open, displaying the following event details:

Methane value exceeded caution level			
Severity	Caution	Caution limit	20 ppm
Type	Gas	Current value	25.3 ppm
Start time	2020-08-24 07:27		
End time	-		

A 'Close' button is located at the bottom of the dialog box. The background interface is dimmed, showing a 'Mute gas alerts' button and a 'Details' link.

Figure 19 Event details for a gas caution alert

More information

- [Configuring gas level alerts \(page 54\)](#)
- [Muting gas level alerts \(page 55\)](#)

3.1.6 Control pages

DGA Monitor page shows current status of the DGA monitor and contains the controls for initialization, starting and stopping the measurement, and uninstalling the DGA monitor. Only relevant controls are shown, and they can only be used by the **Admin** user.




Figure 20 DGA monitor Control page

Autocalibration page shows current status of autocalibration and a history of autocalibration events. **Admin** user can configure the automatically started autocalibration on this page and also start a manual autocalibration cycle.

The screenshot displays the Vaisala Control interface. The top navigation bar shows the time as 09:36 and the current page as 'Control'. The sidebar on the left lists various menu items, with 'Control' currently selected. The main content area is titled 'Autocalibration' and includes a 'What is autocalibration?' link. Below this, there is a description of autocalibration and a 'Start automatically' toggle switch. A 'Start' button is visible next to the text 'No ongoing autocalibration'. The 'Autocalibration History' section contains a table with the following data:

Status	Type	Start time	End time
Autocalibration was successful	Initial	2021-08-11 13:34	2021-08-13 05:52

The table indicates 1-1 of 1 rows.

Figure 21 Autocalibration page

3.1.7 Service pages

Service pages provide tools for servicing the DGA monitor, troubleshooting problems, and recovering from error states:

- **Diagnostics package** tool generates a diagnostic file package for use by Vaisala. The package can be used by Vaisala support to diagnose any issues you may have with the DGA monitor.
- **Bleeding** tool is used to bleed excess gas out of the DGA monitor. Running this tool is only necessary if a device alert indicates the presence of excess gas in the system.
- **Configuration package** tool is used for installing a customized configuration package that has been sent by Vaisala.

- **Software update** tool is on its own page. To update the software version of the DGA monitor, contact Vaisala helpdesk to get the software update file.





Figure 22 Service tools page

3.1.8 Settings pages

Settings pages provide access to the configuration options of the DGA monitor. Settings can only be changed by the **Admin** user.



The screenshot displays the Vaisala Settings page. The left sidebar contains a navigation menu with the following items: Measurements, DGA Diagnostics, Alerts, Control, Service, Settings (selected), General, Measurements, Network, Alert limits, Relays, Units, and About. The main content area is titled "Settings" and shows the following configuration options:

- Device information**: A text input field for "Name".
- Device date and time**:
 - Set time manually
 - Use NTP
 - Use DNP3
- Date**: A date input field showing "2021-09-08" with a calendar icon.
- Time**: A time input field showing "07:47".
- NTP server**: A text input field.
- Apply**: A blue button to save changes.

Figure 23 Settings page

3.1.9 About page

About page shows the serial number and software version of the DGA monitor.

If you are logged in as **Admin** you can Select **View** to see the software license texts of the open source components used in the DGA monitor software.





Figure 24 About page

3.2 Changing administrator password



CAUTION! If you forget your administrator password, contact Vaisala Support to reset it for you.





Figure 25 Changing administrator password

- ▶ 1. Connect to the user interface as the **Admin** user.
2. In the top right corner, select **Admin > Change password**.



3. Enter the current password in **Current password**.
4. Enter the new password in **New password** and **Confirm new password**.
The new password must be at least 8 characters long.
5. Select **Save**.


More information

- ▶ [Connecting to user interface \(page 30\)](#)

3.3 Starting measurement

In normal operation DGA monitor repeats the measurement cycle continuously. You can only start the measurement if DGA monitor is currently in standby.

- ▶ 1. Connect to the DGA monitor user interface and log in as an **Admin** user.
- 2. Start measurement from **Control > Start Measuring**.

 DGA monitor warms up during the first three measurement cycles. Measurements made during the warm-up cycles are not guaranteed to be within the accuracy specification.

3.4 Setting device name




Figure 26 General settings page

You can give a name to the DGA monitor to help identify it. If the name is set, it is shown in:

- Login page
 - Above the Optimus text in the navigation menu
 - Names of files downloaded from the user interface
- ▶ 1. Connect to the user interface as the **Admin** user.
 - 2. In the user interface, select **Settings > General**.

3. Enter a name for the device into **Name**. Maximum length is 64 characters. You can use alphanumerical characters, space, hyphen "-", and underscore "_".
4. Select **Apply** to save the name.

More information

- [Connecting to user interface \(page 30\)](#)

3.5 Setting date and time

The screenshot shows the Vaisala Settings page. The left sidebar contains a menu with options: Measurements, DGA Diagnostics, Alerts, Control, Service, Settings (selected), General, Measurements, Network, Alert limits, Relays, Units, and About. The main content area is titled 'Settings' and shows the following configuration options:

- Device information**: A text input field for 'Name'.
- Device date and time**:
 - Set time manually:
 - Date: 2021-09-08 (with a calendar icon)
 - Time: 07:47
 - Use NTP:
 - NTP server: [Empty text input field]
 - Use DNP3

An 'Apply' button is located at the bottom right of the settings area.

Figure 27 Date and time settings page



DGA monitor uses UTC (Coordinated Universal Time) internally. Time and time stamps in the user interface are shown according to the time zone of the connecting web browser.

- ▶ 1. Connect to the user interface as the **Admin** user.
2. In the user interface, select **Settings > General**.

3. To set date and time manually:
 - a. Select **Set time manually**.
 - b. Select or enter the current date into **Date**. The format is yyyy-mm-dd.
 - c. Enter the current time into **Time**. The field is in 24-hour clock notation in format hh:mm.
 - d. Select **Apply** to save the set time.
4. To set up time synchronization with a Network Time Protocol (NTP) server:



NTP synchronization requires that the network connection is configured and the IP address of the NTP server is reachable.

- a. Select **Use NTP**.
 - b. Enter the IP address of the NTP server into **NTP server**.
 - c. Select **Apply** to start time synchronization.

Status of time synchronization is shown below the **NTP server** field. If the status shows **Connecting...** and does not progress to **Synchronizing time...** even after waiting for a minute, verify that the network connection is working and configured, and the IP address of the NTP server is correctly entered.
 - d. Wait for the message **Time successfully synchronized** to appear.
5. To set up time synchronization using DNP3 protocol:
 - a. Enable and configure the DN3 protocol.
 - b. Select **Use DNP3**.
 - c. Select **Apply** to start time synchronization.

More information

- [Connecting to user interface \(page 30\)](#)
- [Configuring DNP3 protocol \(page 60\)](#)

3.6 Configuring unit settings




Figure 28 Unit settings page

1. Connect to the user interface as the **Admin** user.
2. In the user interface, select **Settings > Units**.
3. Select the preferred unit to use for total gas pressure (hPa or psi). This selection only affects the viewing of the user interface and the downloading of data from the **Latest values** page.
4. Select **Apply** to save the selection.

More information

- [Connecting to user interface \(page 30\)](#)

3.7 Configuring autocalibration




Figure 29 Autocalibration page

Starting with software version 1.11.0, the DGA monitor performs autocalibration when needed and when environmental conditions are suitable. Vaisala recommends leaving this feature enabled, but **Admin** user can disable it from the **Autocalibration** page.

Even if the automatically started autocalibration is disabled, the initial autocalibration will still run after the DGA monitor has been initialized. Autocalibration can also be manually started.

- ▶ 1. Connect to the user interface as the **Admin** user.
2. In the user interface, select **Control > Autocalibration**.
3. Configure the setting with the switch:
 - Disable automatically started autocalibration by moving the switch to the left.
 - Enable automatically started autocalibration by setting the switch to position **Start automatically**.

More information

- ▶ [Autocalibration \(page 28\)](#)
- ▶ [Connecting to user interface \(page 30\)](#)

3.8 Configuring gas level alerts

The screenshot shows the Vaisala Alert Limits settings page. The left sidebar contains navigation options: Measurements, DGA Diagnostics, Alerts, Control, Service, Settings (selected), General, Measurements, Network, Alert limits (selected), Relays, Units, and About. The main content area is titled 'Alert limits' and includes tabs for 'Measured values', 'ROC 1 day', 'ROC 7 days', and 'ROC 30 days'. Below the tabs is a table with the following columns: Parameter, Activation, Caution Limit, Alarm Limit, and On/Off. The table lists various gas parameters and their corresponding limit values and activation status.

Parameter	Activation	Caution Limit	Alarm Limit	On/Off
Methane CH ₄		<input type="text"/> ppm	<input type="text"/> ppm	<input type="checkbox"/> Off
Acetylene C ₂ H ₂		<input type="text"/> ppm	<input type="text"/> ppm	<input type="checkbox"/> Off
Ethylene C ₂ H ₄		<input type="text"/> ppm	<input type="text"/> ppm	<input type="checkbox"/> Off
Ethane C ₂ H ₆		<input type="text"/> ppm	<input type="text"/> ppm	<input type="checkbox"/> Off
Carbon monoxide CO		<input type="text"/> ppm	<input type="text"/> ppm	<input type="checkbox"/> Off
Carbon dioxide CO ₂		<input type="text"/> ppm	<input type="text"/> ppm	<input type="checkbox"/> Off
Hydrogen H ₂		<input type="text"/> ppm	<input type="text"/> ppm	<input type="checkbox"/> Off
Total dissolved combustible gases TDCG		<input type="text"/> ppm	<input type="text"/> ppm	<input type="checkbox"/> Off
Moisture H ₂ O		<input type="text"/> ppm	<input type="text"/> ppm	<input type="checkbox"/> Off
Moisture H ₂ O		<input type="text"/> %RS	<input type="text"/> %RS	<input type="checkbox"/> Off
Total gas pressure	Maximum limit	<input type="text"/> hPa	<input type="text"/> hPa	<input type="checkbox"/> Off

An 'Apply' button is located at the bottom right of the table.

Figure 30 Alert limits settings page

Configure gas level alerts on the **Alert limits** settings page. There are separate rows for each individual gas level alert. Alerts for rate of change (ROC) values are on their own tabs. By default, all gas level alerts are off.

- ▶ 1. Connect to the user interface as the **Admin** user.
2. In the user interface, select **Settings > Alert limits**.
3. For each alert you want to configure:
 - a. Change to the tab that shows the alert you want to configure.
 - b. Enter the **Caution Limit** in ppm. This is the limit that triggers a gas alert with caution severity.
 - c. Enter the **Alarm Limit**. Alarm limit should be higher than the caution limit, except when configuring a minimum limit alert for total gas pressure (TGP).
 - d. If the alert is for the total gas pressure (TGP) value, select if you want the limit value to be a **maximum limit** (alert active when value is above the limit) or a **minimum limit** (alert active when value is below the limit).
 - e. Set the alert to **On** to enable it.

It is possible to have only caution or alarm severity active. If you leave a limit value empty or enter a zero, the corresponding severity will not be active for that gas level alert.

4. Select **Apply** to take the new alert limit settings into use.



Changing gas alert settings will not immediately activate any new alerts. Gas alert status is updated only when the next measurement cycle results set is ready.

More information

- [Connecting to user interface \(page 30\)](#)

3.9 Muting gas level alerts

Muting gas level alerts temporarily disables any indications that any gas level alerts are active:

- Alert indicator in the user interface is set to non-alerting state (unless any device alerts are active)
- If one or more relays have been activated by gas level alerts, they are inactivated
- Status LEDs do not indicate that a gas level alert is active
- Output protocols do not communicate any gas level alerts as active (but will set appropriate status bits/flags to signal that gas level alarms are muted)

Admin user can mute gas level alerts by selecting **Mute gas alerts** on the **Alerts** page.



Muting of gas level alerts continues until any one of the following occurs:

- Severity of any muted gas level alert rises from caution to alarm
- Any new gas level alert is activated
- **Admin** user selects **Unmute gas alerts** on the **Alerts** page




Figure 31 Alert page with methane caution alert visible

3.10 Configuring network connection




Figure 32 IP address settings page

Configure the network settings of the external Ethernet connection (ETH0).

- ▶ 1. Connect to the user interface as the **Admin** user.
2. In the user interface, select **Settings > Network > IP address**.
3. Select if the external Ethernet connection should be **Enabled** or **Disabled**.
4. If you enabled the external Ethernet connection, select how its IP address is assigned: **DHCP** for automatic assignment, or **Static IP address** to enter the values manually.
5. If you selected **Static IP address**, enter the following values:
 - **IP address**
 - **Subnet mask**
 - **Default gateway**



IP addresses in 192.168.28.0/24 cannot be used for the external network connection (ETH0) since they are reserved for the service port (ETH1).

6. Select **Apply** to save your changes.

More information

- ▶ [Connecting to user interface \(page 30\)](#)

3.11 Configuring user interface security

The screenshot shows the Vaisala user interface. The top bar displays '13:42 Settings' and navigation icons for 'Measuring', 'Alerts', 'Help', and 'Admin'. The left sidebar contains a menu with options: Measurements, DGA Diagnostics, Alerts, Control, Service, Settings (selected), General, Measurements, Network, Alert limits, Relays, Units, and About. The main content area is titled 'Security' and includes the following sections:

- Encryption:** A description states 'DGA monitor uses encrypted connections (HTTPS) to the user interface by default. Unencrypted connections (HTTP) can be enabled if necessary.' Two radio buttons are present: 'HTTP' (unselected) and 'HTTPS (default)' (selected).
- Certificates:** Two radio buttons are present: 'Use default self-signed certificate' (selected) and 'Use custom certificate' (unselected).
- Current certificate:** A section with three input fields: 'Certificate file', 'Private key file', and 'Private key password'. Each field has a 'Choose file...' button and a 'Browse' button.
- Apply:** A blue button at the bottom of the form.

Figure 33 Network security settings page

Configure HTTPS encryption for the user interface connection. By default, DGA monitor only allows encrypted connections to the user interface (HTTPS) using a self-signed certificate. Any connections that request unencrypted communication (HTTP) are redirected to the encrypted interface (HTTPS).



The default self-signed certificate is not trusted by connecting web browsers and will give a warning that the connection is not secure. To remove the notification, install a trusted TLS certificate (TLS 1.1 or 1.2) on the DGA monitor. However, note that HTTPS traffic is always encrypted even if the certificate is not trusted. Vaisala recommends using encrypted connections (HTTPS).

- ▶ 1. Connect to the user interface as the **Admin** user.
2. In the user interface, select **Settings > Network > Security**.
3. Select **HTTP** to use unencrypted user interface connections, or **HTTPS (default)** to secure the interface using encryption.
4. To use your own certificate with HTTPS connections:
 - a. Select **Upload certificate**.
 - b. Select **Certificate file > Browse** and locate the certificate file.
 - c. Select **Private key file > Browse** and locate the private key file.
 - d. Enter the **Private key password** if your private key requires it.
5. Select **Apply** to save your changes.



If you change the security settings, the user interface will restart and you have to log in again.

More information

- ▶ [Connecting to user interface \(page 30\)](#)

3.12 Configuring Modbus protocol




Figure 34 Modbus settings page

- ▶ 1. Connect to the user interface as the **Admin** user.
2. In the user interface, select **Settings > Network > Modbus**.
3. Select the connection type(s) for which Modbus protocol should be enabled. Select **TCP** (Ethernet), **RTU** (serial line), or both.
4. If you enabled Modbus RTU, configure the serial connection:
 - a. Select **Baud rate** for the connection. Available options are:
 - 4800
 - 9600
 - 19200
 - 38400
 - 57600
 - 115200
 - b. Select **Transmission mode**, 8E1 or 8N2.
 - c. Enter the Modbus **Slave ID** for the DGA monitor. Range 1 ... 247.
5. Click **Apply** to save your changes.

More information

- ▶ [Connecting to user interface \(page 30\)](#)

3.13 Configuring DNP3 protocol




Figure 35 DNP3 settings page



DNP3 protocol is an optional feature and requires a license. If a license is not installed on the DGA monitor, you cannot enable the protocol. Contact Vaisala for acquiring the license.

- ▶ 1. Connect to the user interface as the **Admin** user.
2. In the user interface, select **Settings > Network > DNP3**.
3. Select if the DNP3 protocol should be **Enabled** or **Disabled**.
4. If you enabled the DNP3 protocol, configure the following settings:

Connection type

Interface where DNP3 protocol will be available.

Slave link address

Address of this DGA monitor.

Master link address

Address of the DNP3 master.

Default analog input variation

Data format variation for analog input values. Variations 1 ... 6 are available.

5. If you selected **Serial port** as the connection type, configure the following settings:

Baud rate


Baud rate of the serial connection. Available options are 4800, 9600, 19200, 38400, 57600, and 115200.

Transmission mode

Number of data bits, parity, and number of stop bits used in serial communication. Available options are 8E1 and 8N2.

6. Set the classes used for the **Gas alarm**, **Gas caution**, and **Device status** events.

7. Select **Apply** to save your changes.

 Select **Download** to download the DGA monitor device profile in XML format. It is needed to configure your DNP3 master system.

More information

- [Connecting to user interface \(page 30\)](#)

3.14 Configuring IEC 61850 protocol




Figure 36 IEC 61850 settings page



IEC 61850 protocol is an optional feature and requires a license. If a license is not installed on the DGA monitor, you cannot enable the protocol. Contact Vaisala for acquiring the license.

- ▶ 1. Connect to the user interface as the **Admin** user.
2. In the user interface, select **Settings > Network > IEC 61850**.
3. Select if the IEC 61850 protocol should be **Enabled** or **Disabled**.
4. Select **Apply** to save your changes.



Download the following supporting documents from this page:

- IED Capability Description (ICD) file
- Protocol Implementation Conformance Statement (PICS)
- Model Implementation Conformance Statement (MICS)

More information

- ▶ [Connecting to user interface \(page 30\)](#)

3.15 Using protocol test mode

Protocol test mode

Edit the simulated data below and select Update to commit the edit. Select Close to end the test mode.

Gas	Value	Caution	Alarm	Activation
Methane CH ₄	10 ppm	<input type="checkbox"/>	<input type="checkbox"/>	
Acetylene C ₂ H ₂	11 ppm	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
Ethylene C ₂ H ₄	12 ppm	<input type="checkbox"/>	<input type="checkbox"/>	
Ethane C ₂ H ₆	13 ppm	<input type="checkbox"/>	<input type="checkbox"/>	
Carbon monoxide CO	14 ppm	<input type="checkbox"/>	<input type="checkbox"/>	
Carbon dioxide CO ₂	15 ppm	<input type="checkbox"/>	<input type="checkbox"/>	
Total dissolved combustible gases TDCG	16 ppm	<input type="checkbox"/>	<input type="checkbox"/>	
Hydrogen H ₂	17 ppm	<input type="checkbox"/>	<input type="checkbox"/>	
Moisture H ₂ O	18 ppm	<input type="checkbox"/>	<input type="checkbox"/>	
Temperature of in-oil measurement chamber	19 °C			
Moisture H ₂ O	20 %RS	<input type="checkbox"/>	<input type="checkbox"/>	
Total gas pressure	21 hPa	<input type="checkbox"/>	<input type="checkbox"/>	Maximum limit

Test mode timeout in: 00:52:48

Close Update

Figure 37 Protocol test mode enabled

- ▶ 1. Connect to the user interface as the **Admin** user.
2. In the user interface, select **Settings > Network > Protocol Test Mode**.
3. Check the status of the protocols listed under **Protocols**. Make sure the protocols you want are enabled. If they are not, you must enable and configure them first before continuing this procedure.
4. Select **Start** to enable the protocol test mode and open the protocol test mode page.



The page is preconfigured with arbitrary default values for measurement parameters. The values are all different to make it easy to verify on the SCADA side that the correct parameter is being read and displayed. Scroll the page to reveal all of the fields.

5. To set your own test data:
 - a. Edit the values as required.
 - b. Check the checkboxes to enable the desired caution and warning level alerts.
 - c. Select **Update** at the bottom of the page to take the new test data into use.
6. The test mode will end automatically after one hour. You can select a longer timeout from the drop-down menu marked **Test mode timeout in**. Select **Update** to take the new timeout into use.
7. Start testing by reading information from the DGA monitor from the SCADA system side.
8. When you are done testing, select **Close** to end the test mode immediately or wait until the end of the timeout.

More information

- ▶ [Protocol test mode \(page 27\)](#)
- ▶ [Connecting to user interface \(page 30\)](#)

3.16 Configuring relays




Figure 38 Relay settings page

- ▶ 1. Connect to the user interface as the **Admin** user.
 - 2. In the user interface, select **Settings > Relays**.
 - 3. Each of the three relays is configured individually. For each relay:
 - a. Select relay **Mode**:
 - In **Normal** mode, the relay is activated by the selected **Trigger**.
 - In **Test** mode, the relay activation is controlled manually from the **Set test state** buttons.
- If the relay is not used, select the **Test** mode. You can also use it to test that wiring has been connected correctly.
- b. Select relay **Trigger**:
 - **Gas Caution** activates the relay if any gas level alert of **caution** severity is active.
 - **Gas Alarm** activates the relay if any gas level alert of **alarm** severity is active.
 - **Device Error** activates the relay if a device error is active.

Settings are applied immediately.

More information

- ▶ [Connecting to user interface \(page 30\)](#)

3.17 Configuring offsets

Adjust reported values with offsets. Offsets are applied to the measured values as increments or decrements.





Figure 39 Configuring offsets in measurement settings


- **Apply** saves changes.
- **Undo** returns to previously applied offsets.
- **Clear** removes configured offsets.


- ▶ 1. Go to **Settings > Measurements > Offset**.
- 2. Calculate offsets. Offsets can be increments or decrements.

 New offset is applied to the original measured values, not previously offset values.

- 3. Fill values into all **Offset** fields.

4. Select **Apply** to save changes.

 After applying the settings, you cannot return to the previous offsets. The previous offsets can be viewed in the data file.

 To download history data, go to **Measurements > Latest values > Download Data**.

View offset values in **Measurements** page. **Offset** flag in the graphs shows when the newest offset has been applied. Offsets are added to measured values, 1 day averages, gas ratios and custom averages. Offset values are also shown in **DGA Diagnostics**.





Figure 40 Offsets in Measurements

 If you have set gas level alerts, offsets may cause additional alarms.

More information

- [Configuring gas level alerts \(page 54\)](#)

3.18 Configuring custom averages

Configure custom calculation of averages based on measurement points or time intervals. The values will be calculated to the new dataset separately from the default 24h averages.




Figure 41 Configuring custom averages in measurement settings

- ▶ 1. Go to **Settings > Measurements > Averaging**.
- 2. Enable custom averaging.
- 3. Select **Hours** or **Measurement points**.
- 4. Add values into **Averaging** fields as needed.

If a field is left empty, custom average for the particular gas is not calculated.

- 5. Select **Apply**.

View custom averages in **Measurements** page:

- A. Go to **Gas measurements** tab and select **Custom averages** in the dropdown menu. **Avg** flag in the graph shows when the custom average has been set.




Figure 42 Custom averages in Measurements

- B. In **Latest values** tab, you can see custom average values in a separate column.



To download history data, go to **Measurements > Latest values > Download Data**.

3.19 Deleting data

Delete all measurement data up to a selected date and time.





Figure 43 Deleting measurement data in settings

- ▶ 1. Go to **Settings > Measurements > Delete data**.
- 2. Select the date and time up to which you want to delete measurement data.
- 3. Press **Delete**.

 After pressing **Delete**, data cannot be restored.

4. Maintenance

4.1 Maintenance safety



WARNING! Keep away from live circuits. Operating personnel must observe safety regulations at all times.



WARNING! Ground the DGA monitor cabinets as instructed in the wiring instructions. Verify the grounding before and after performing maintenance on the unit.



CAUTION! Do not modify the DGA monitor or use it in ways not described in the documentation. Modifications may lead to safety hazards, equipment damage, failure to perform according to specification, or decreased equipment lifetime.



CAUTION! Surfaces inside DGA monitor that are marked with the symbol below heat up during normal operation. Avoid touching hot surfaces and wear protective gloves when working inside the cabinet. Whenever possible, allow the DGA monitor to cool down before starting the work.



Wear protective eyewear and gloves.

4.2 Cleaning DGA monitor

OPT100 DGA monitor does not need to be cleaned to maintain its normal operation. The enclosures are IP66 rated and measurement system is hermetically sealed. If a significant amount of contamination is present inside the enclosures, verify that:

- All cable glands fit tightly around cables, or are plugged if unused.
- Doors of the enclosures close properly.
- There are no oil leaks inside the DGA monitor.

4.3 Maintenance

OPT100 DGA Monitor does not require visits to the installation site for preventive maintenance. There are no consumables or components that must be replaced according to a fixed schedule. You can check the status of the DGA monitor and update its configuration remotely through the browser-based user interface. Software of the DGA monitor can be updated remotely as well.

Indications of the DGA monitor's status are also available to your SCADA system through the communication interfaces (for example, Modbus). If a problem with the DGA monitor is indicated, check the user interface.

4.4 Updating DGA monitor software



- Software update file for DGA monitor



CAUTION! Software update may change the settings of your DGA monitor. This is necessary as new features are added and settings of previously existing features are updated. After a successful software update, go through the pages in the **Settings** menu. For example, verify that the necessary communication protocols are enabled and their settings are correct.




Updated software may include improvements to the measurement algorithm. These updates are only applied to new measurement cycles after the update, which may cause some discontinuity in the measured gas levels even if the concentration of gases in the measured oil has not changed. Vaisala recommends starting autocalibration manually after a software update.



Software update does not delete the measurement data stored on the DGA monitor.

- ▶ 1. Connect to the user interface as the **Admin** user.
2. Switch the DGA monitor to **Standby** mode by stopping measurement.
3. Verify that date and time on the DGA monitor are set correctly.
4. Wait for DGA monitor to stop and enter the **Standby** mode. Depending on the stage in the measurement cycle, stopping may take up to 60 min.
5. Select **Service > Software update > Update > Browse** and locate the firmware update file.

6. Select **Upload** to send the file to the DGA monitor.



7. DGA monitor verifies that the file was received successfully, and starts the update. The update may take up to 30 min. When the process is complete, a user interface message will show the result of the update.



CAUTION! Do not power off the DGA monitor during the update. Do not attempt to reconfigure the DGA monitor, generate a diagnostic data package, or use any other functions of the user interface until the update is ready.



While waiting for the update to complete you may lose connection to the user interface, or receive a message indicating that the update has failed. This may happen because your browsing session expires or due to a network connectivity problem, and does not necessarily mean that the upgrade has actually failed. To continue from this situation, close the browser window, and reconnect to the user interface as the **Admin** user.

8. Verify that the new software version is displayed as the current software version on the **Software update** page. This means the software update has been successful.
9. Verify the current **Settings** of the DGA monitor. The software update may have added new settings or changed existing ones.
10. Switch the DGA monitor back to **Measuring** mode to continue normal measurement by starting measurement.

- Optional: Start autocalibration manually to make sure any updates to the autocalibration mechanism are applied right away.



Autocalibration takes from 2 to 5 days depending on conditions.

More information

- [Connecting to user interface \(page 30\)](#)
- [Starting measurement \(page 49\)](#)
- [Setting date and time \(page 50\)](#)
- [Starting autocalibration manually \(page 73\)](#)
- [Stopping measurement \(page 74\)](#)

4.5 Starting autocalibration manually

Autocalibration improves measurement performance by adapting the DGA monitor to transformer oil conditions. Autocalibration takes from 2 to 5 days depending on conditions.

It is not normally necessary to start autocalibration manually, and autocalibration always runs automatically after a DGA monitor is initialized. However, it is recommended to start autocalibration in some specific cases, for example after the software of the DGA monitor has been updated.

1. Connect to the user interface as the **Admin** user.
2. Select **Control** and verify that the system is currently measuring. You can only start autocalibration when DGA monitor is in **Measuring** state.
3. Select **Autocalibration** and verify the current autocalibration status. Do not attempt to start autocalibration if it is already ongoing.
4. Select **Start**. DGA monitor will perform autocalibration and continue with normal measurement cycles after it is completed.

More information

- [Connecting to user interface \(page 30\)](#)

4.6 Repair

If your OPT100 DGA monitor needs repair, note the following:

- Make sure you have the latest product documentation before taking any actions. Check the OPT100 product page <http://www.vaisala.com/opt100> for updates.
- If a repair procedure you need is not available in the documentation, contact Vaisala for assistance.

- Some repairs can only be performed by a Vaisala representative.
- If OPT100 DGA Monitor is sent to Vaisala for repairs, use sufficient packing material to ensure safe shipping. Pay special attention to the connections at the bottom of the main cabinet. If both DGA monitor and OPTPSU power supply unit are sent, pack them in separate boxes. Label "fragile".
- For any components included inside the OPT100 DGA Monitor or the OPTPSU power supply unit, use only spare parts supplied by Vaisala.

4.6.1 Stopping measurement

- ▶ 1. Connect to the DGA monitor user interface and log in as an **Admin** user.
2. Stop the measurement mode by selecting **Control > Stop Measuring**.
3. Wait for DGA monitor to enter **Standby** mode. Depending on the stage in the measurement cycle, stopping may take up to 60 min.

4.6.2 Turning off the DGA monitor for maintenance

- ▶ 1. Switch the DGA monitor to standby mode.
2. Turn off OPTPSU power to the DGA monitor:
 - a. Turn off OPTPSU power from the external disconnection device.
 - b. Lock the disconnection device in the off position, if possible.
 - c. Attach a warning label to the disconnection device that clearly states why the power is turned off.
3. Turn off power inside the power supply unit:
 - a. Open the power supply unit cabinet.
 - b. Turn off switch **S1**.
 - c. Turn off circuit breaker **F1**.

4.6.3 Verifying safety after repair

Go through the following verification steps after performing repairs on the DGA monitor.

- ▶ 1. If you have replaced or altered any mechanical parts of the DGA monitor cabinet or mounting accessories, verify that:
 - Cabinet can be opened and closed normally.
 - Cabinet tightness is maintained.
 - All attachment points are intact.

2. If you have replaced any electrical components or wiring, verify that:
 - All components that are secured to a DIN rail are firmly in place.
 - There are no disconnected cables or loose wires.
 - All grounding wires are attached.
 - Wiring is done according to the wiring instructions in the *OPT100 Installation Guide (M211857EN)*, unless intentionally altered by the repair procedure.
3. If you have replaced any of the oil handling components (pipes, valves, pump, oil block, etc.) or opened any of the oil connections, verify that:
 - There are no open oil connections.
 - All oil handling components are securely attached.
 - All oil leaks have been cleaned and wiped clean. No oil is visible on the parts or oil connections.

4.6.4 Turning on DGA monitor after maintenance



CAUTION! If the circuit breakers will not stay in the ON position, turn off Mains power to the DGA monitor immediately and inspect the Mains and OPTPSU power wiring. The circuit breakers may be tripping because of a loose wire or incorrect connection.

- ▶ 1. Verify that the circuit breakers **Main** and **Heat** inside the DGA monitor are turned on.
2. Turn on power inside the power supply unit:
 - a. Open the power supply unit cabinet.
 - b. Turn on circuit breaker **F1**.
 - c. Turn on switch **S1**.
3. Turn on OPTPSU power to the DGA monitor:
 - a. Check if there are any warning labels attached to the disconnection device. If there are, make sure it is safe to turn on the OPTPSU power. Remove any labels that are now unnecessary.
 - b. If the external disconnection device is locked in the off position, unlock it.
 - c. Turn on OPTPSU power from the external disconnection device.

4.6.5 Starting measurement

In normal operation DGA monitor repeats the measurement cycle continuously. You can only start the measurement if DGA monitor is currently in standby.

- ▶ 1. Connect to the DGA monitor user interface and log in as an **Admin** user.
2. Start measurement from **Control > Start Measuring**.



DGA monitor warms up during the first three measurement cycles. Measurements made during the warm-up cycles are not guaranteed to be within the accuracy specification.

4.7 Uninstalling DGA monitor



- Adjustable wrench
- Screwdriver with 3-mm-wide (0.12-in) slotted head
- 5-mm Allen key
- Swagelok® plugs for oil connector fittings (2 pcs, Swagelok part no. SS-10MO-P (316 Stainless Steel Plug for 10-mm Swagelok Tube Fitting))
- Container for waste oil with at least 5 liter (1.3 gallon) capacity
- Oil absorption material for controlling possible leaks
- Rags for wiping off oil



Wear protective eyewear and gloves.

Follow this procedure to uninstall the DGA monitor. Uninstallation empties the DGA monitor of oil and allows it to be safely stored and transported.

The procedure assumes that the DGA monitor is completely installed and currently measuring when the uninstallation is started. The complete procedure may take up to 3 hours. If the DGA monitor is already in **Standby** mode, you can skip [step 4](#) and [step 5](#).





CAUTION! Do not transport the DGA monitor without uninstalling it properly:

- If the oil connections are not properly plugged, oil will drain out from the DGA monitor during transport.
- Oil may contaminate the optical measurement module during transport unless you complete the uninstallation procedure successfully and **lock the bleed valve manually**.

- ▶ 1. Check that the oil lines between DGA monitor and transformer are intact.
2. Check that the oil intake and return valves on the transformer side are open.
3. Connect to the DGA monitor user interface and log in as an **Admin** user.
4. Stop the measurement mode by selecting **Control > Stop Measuring**.
5. Wait for DGA monitor to enter **Standby** mode. Depending on the stage in the measurement cycle, stopping may take up to 60 min.


6. Select **Control > Uninstall > OK**.

 The user interface shows the uninstallation stages and approximate times between the stages. The time required for the preparation stage varies, and it may take up to 60 min before you are prompted to perform the next step.




The screenshot displays the Vaisala Uninstall interface. On the left is a blue sidebar with the following menu items: Measurements, DGA Diagnostics, Alerts, Control (highlighted), Service, Settings, and About. At the bottom of the sidebar is the word 'OPTIMUS'. The main content area is titled '12:22 Uninstall' and includes navigation links for 'Uninstalling', 'Alerts', 'Help', and 'Admin'. A progress bar shows seven stages: 1. Preparing (0-60 min), 2. Lock bleed valve (1 min), 3. Remove pipe plug (2 min), 4. Close transformer valves (15 min), 5. Pump out the oil (40 min), 6. Attach pipe plug (5 min), and 7. Plug oil connections. The first stage is active, and a 'Please wait...' message is displayed below the progress bar.

- 7. Push in the gray knob on the side of the bleed valve, and turn it 90° clockwise to lock the valve manually. Select **Continue** from the user interface when done.




- 8. When instructed to do so, remove the bleed plug from the bleed valve. Select **Continue** when done.



- 9. When instructed to do so, close the oil intake and return valves on the transformer.

10. When instructed to do so, disconnect oil pipes from the **Oil In** and **Oil Out** connections on the outside of the DGA monitor. Place the ends of the pipes in the waste oil container to collect the oil that drains out.
11. Check the checkbox to acknowledge that the oil pipes are now disconnected, and select **Continue**.
12. When instructed to do so, reattach the bleed plug to the bleed valve.



13. Plug the **Oil In** and **Oil Out** connectors of the DGA monitor to prevent the small amount of oil remaining in the system (less than one deciliter, 3.4 fl. oz.) from draining out during transport.
14. Plug the intake and return oil lines.
15. Select **Finish** to end the uninstallation sequence.
16. Turn off OPTPSU power to the DGA monitor:
 - a. Turn off OPTPSU power from the external disconnection device.
 - b. Lock the disconnection device in the off position, if possible.
 - c. Attach a warning label to the disconnection device that clearly states why the power is turned off.
17. Disconnect the cables between the power supply unit and the DGA monitor.
18. Plug and tighten the cable glands to maintain cabinet tightness during storage.
19. Uninstall the equipment in reverse order of installation.

See [OPT100 Installation Guide \(M211857EN\)](#) for details.

20. Place the equipment in the original packaging, if available. Safe lifting and carrying of the DGA monitor requires two people.

If original packaging is not available:

- Use double wall cardboard boxes. If both OPT100 DGA Monitor and OPTPSU power supply unit are sent, pack them in separate boxes.
- Protect the main cabinet fittings at the bottom. Fill the box with enough protective material that the equipment cannot move around in the box.
- Close the box with plastic tape and add bands around the box.

21. Ship right side up with "fragile" markings.

5. Troubleshooting

5.1 Problem situations

Table 11 Troubleshooting table













Problem	Possible cause	Solution
Green status LED is flashing.	DGA monitor is in standby mode.	Start the measurement mode. See Starting measurement (page 49) .
Yellow status LED is lit.	A device warning is active.	Log in to the user interface. Check system status and active alerts. See sections System statuses (page 82) and Device alerts (page 83) .
	DGA monitor has been installed but not initialized.	Perform commissioning and initialization according to the <i>OPT100 Installation Guide (M211857EN)</i> .
	DGA monitor has been uninstalled.	Confirm the cause from the user interface.
Yellow status LED is flashing.	Gas level alert is active, caution limit exceeded.	Log in to the user interface. Check gas levels and active alerts.
Red status LED is lit.	A device error is active.	Log in to the user interface. Check system status and active alerts. See sections System statuses (page 82) and Device alerts (page 83) .
Red status LED is flashing.	Gas level alert is active, alarm limit exceeded.	Log in to the user interface. Check gas levels and active alerts.
Data missing in measurement view (gaps in graphs)	Measurement cycles have not produced reliable results for some or all measurement parameters.	Can be caused by rapid temperature changes. Make sure the DGA monitor doors are closed and locked. See Notes for normal operation (page 15) .
	DGA monitor has been in standby mode or turned off.	Keep the DGA monitor powered on and in measurement mode.

Problem	Possible cause	Solution
My web browser warns me that the connection is not secure when connecting to the user interface.	User interface is secured using a self-signed certificate that is not trusted by your web browser, because the certificate is not publicly distributed.	To get rid of the warning permanently, create a trusted certificate and key and configure the user interface security to use them (recommended) or disable HTTPS security (not recommended). See Configuring user interface security (page 57) . Alternatively, you can ignore the warning and proceed to the user interface. HTTPS traffic is always encrypted even if the certificate is not trusted.
I am unable to log in to the user interface as Admin user.	Forgotten password.	Contact Vaisala. See Technical support (page 119) .
DGA monitor LED lights are off.	Issue with the power supply.	Check power input from the power supply unit (switches F1 and S1).
Oil is leaking from inside the DGA monitor or the connecting pipes.	Loose connection or faulty piping.	Tighten any loose connections. If there is still leakage, stop measurement and complete uninstallation procedure before maintenance. If maintenance work cannot be started immediately, close transformer valves to prevent more oil leaking into the system.

5.2 System statuses

System status is shown in the header at the top of the user interface. Note that the presence of alerts (gas level alerts or device alerts) is indicated by a separate alert indicator.

Table 12 System statuses

Symbol and text	Meaning
 Autocalibrating	DGA monitor is performing autocalibration cycles. Autocalibration improves measurement performance by adapting the DGA monitor to transformer oil conditions. Autocalibration takes from 2 to 5 days depending on the conditions. After autocalibration has been completed successfully, DGA monitor automatically starts normal measurement operation.
 Connecting	System state is being determined. This state is shown after a software update has been performed.
 Measuring	Normal operation; DGA monitor is performing measurement cycles.
 Not initialized	DGA monitor has not been initialized. Initialization is part of the installation and requires physical access inside the DGA monitor cabinet.
 Initializing	DGA monitor is being initialized.
 In service	DGA monitor is performing a service action, for example, running a service tool.
 Standby	DGA monitor is idle and waiting for commands from the administrator. Measurement cycles are not being performed.
 Stopping	Normal measurement is being stopped. When complete, the DGA monitor will remain in the standby state.
 Stopped	DGA monitor has stopped measurement due to an error.
 System error	System status of the DGA monitor could not be determined.
 Uninstalling	DGA monitor is being uninstalled. Uninstallation empties the DGA monitor of oil and prepares the measurement system for transportation.
 Updating	Software update is in progress.

More information

- [Status indicator \(page 32\)](#)

5.3 Device alerts

Device alerts are warnings and errors that communicate potential problems with the DGA monitor device. Device alert status is shown in the header at the top of the user interface. A message that describes the alert is also shown.

Device alerts come in two severities:

- **Warnings** are less serious and may not require any action to be taken.
- **Errors** typically prevent normal measurement and require user intervention to recover from.

Contact Vaisala for support if you are unable to resolve a device alert yourself. From the **Service** page of the user interface you can create a diagnostic data file that can help Vaisala diagnose the device alert. It is recommended that you do this if your DGA monitor stops due to an error, regardless of if the error was successfully resolved.

Table 13 Device alerts

Code	Alert text	Severity	Description
1098	Measurement cycle started after an error	Warning	The measurement cycle has been started after an error. It is yet unclear if the error has been resolved and the measurement cycle can be completed successfully. Please wait. This warning is inactivated once the measurement cycle has been completed successfully.
1401	Unable to measure due to unstable temperature	Warning	Results of the latest measurement cycle have been rejected due to unstable temperature. This is typically caused by the cabinet door being left open. <ol style="list-style-type: none"> 1. Close the cabinet door of the DGA monitor. 2. Wait for the next measurement cycle to complete to see if the problem has been solved. 3. Contact Vaisala support if the problem remains.
1402	Unable to measure due to unstable light intensity level	Warning	Results of the latest measurement cycle have been rejected due to unstable intensity level of the optical measurement module. Contact Vaisala support if this warning repeats for many measurement cycles.

Code	Alert text	Severity	Description
1501	Hardware clock time lost	Warning	<p>Hardware clock of the DGA monitor has incorrect time. Set new time or enable time sync in the Settings > General page.</p> <p>If this error reoccurs, consider changing the backup battery of the real-time clock. Contact Vaisala support for help with changing the backup battery.</p>
1502	Unable to read measurement module calibration file	Warning	<p>The system is unable to read the calibration file of the optical measurement module. DGA monitor continues measuring without the optical measurements. Contact Vaisala support.</p>
2099	Measurement cycle fault	Error	<p>If the DGA monitor has a serious hardware problem or cannot measure due to some external cause, it will automatically stop trying to run the measurement cycles. See Resolving a measurement cycle fault (page 86)</p>
2102	Oil inside cabinet	Error	<p>The float sensor inside DGA monitor cabinet is activated, indicating a possible oil leak. It is recommended to check the device right away. Inspect inside the DGA monitor and oil lines to determine the cause of the error, and remove it if possible.</p>
2112	Excess gas in the system	Error	<p>There is excess gas in the measurement system, and the DGA monitor is unable to safely dissolve the gases back into the oil.</p> <p>You must bleed the excess gas from the system to resume normal operation. See Bleeding the DGA monitor (page 88).</p>

Code	Alert text	Severity	Description
2200	Valve 2 failure	Error	<ol style="list-style-type: none">1. Open the DGA monitor cabinet and locate valve 2. See Interior parts (page 22).2. Check the position of the manual lock on valve 2. If the grey knob is pushed down, the valve is locked and that is causing the error.3. Turn the knob counter-clockwise 90 degrees to open the lock and resolve the error. <p>If the lock is open the valve must be replaced to resolve the error. Contact Vaisala support.</p>

More information

- [Generating a diagnostics package \(page 88\)](#)

5.4 Resolving a measurement cycle fault




Figure 44 Measurement cycle fault active

Measurement cycle fault (code 2099) device alert is activated when DGA monitor has detected a problem that prevents measurement, and has automatically stopped running measurement cycles. Possible causes include hardware failure and problems with the oil connection. For example, someone may have closed the oil valve(s) on the transformer and prevented the DGA monitor from pumping oil.

To resolve the problem:

- ▶ 1. Connect to the user interface as the **Admin** user.
- 2. Read any active messages in the user interface.
- 3. Check currently active alerts on the **Alerts** page.
- 4. Check status of DGA monitor on the **Control** page.
- 5. Inspect the DGA monitor and oil lines to determine the cause of the error, and remove it if possible. For example, open the oil valves on the transformer if they are closed.
- 6. If you have resolved the likely problem or there does not seem to be an apparent cause, select **Control > Start Measuring** to restart measurement.
- 7. Wait to see if the DGA monitor is able to complete a measurement cycle and keep running normally.

The device alert will change to **Measurement cycle started after an error** (code 1098), which will be inactivated when the first cycle after the restart is successfully completed.

- 8. If the DGA monitor stops measuring again and the measurement cycle fault returns, try to restart measurement once more.
- 9. If the problem is not resolved after a couple of attempts:
 - a. Perform the uninstallation procedure according to instructions but stop uninstalling at [step 15](#). Do not disconnect any cabling.
 - b. Reconnect the oil lines.
 - c. Perform the initialization procedure according to *OPT100 Installation Guide (M211857EN)*.
 - d. After a successful initialization, select **Control > Start Measuring** to restart measurement.
- 10. If uninstalling and re-initialization did not remove the problem:
 - a. Generate a new diagnostic data file from the DGA monitor.
 - b. Contact Vaisala support and provide the diagnostic data file to help diagnose the error.


More information

- ▶ [Connecting to user interface \(page 30\)](#)
- ▶ [Uninstalling DGA monitor \(page 76\)](#)
- ▶ [Generating a diagnostics package \(page 88\)](#)

5.5 Generating a diagnostics package

The diagnostic package can be used by Vaisala support to diagnose any issues you may have with the DGA monitor. The diagnostic data in the file is intended for use only by Vaisala.

1. Connect to the user interface as the **Admin** user.
2. Select **Service** to open the **Service tools** page, and locate the **Diagnostics package** tool.



3. If a data package has been previously generated, a file name and the generation date are shown. Select the file name to download the package.
4. To generate a new package, select **Generate new**. Any existing package will be overwritten. Generating the package may take up to 20 min.

More information

- [Connecting to user interface \(page 30\)](#)

5.6 Bleeding the DGA monitor



- Cabinet key
- 5-mm Allen key


It is possible for the DGA monitor to accumulate excess gases in the measurement system. This can happen, for example, because of an air leak in the oil lines. The DGA monitor will detect this situation and enable device alert code 2112, **Excess gas in the system**.

To restore normal operation, you must perform the procedure below to bleed the excess gas, and restart measurement after successfully bleeding the system. You must be on site with access to the DGA monitor cabinet, as you have to remove and reattach the bleed plug as instructed.


1. Connect to the DGA monitor user interface and log in as an **Admin** user.
2. Select **Service** to open the **Service tools** page, and locate the **Bleeding** tool.

3. Select **Bleed > Start** to start the bleeding sequence.


The user interface will change to show the bleeding stages and approximate times between the stages.



4. Follow the progress and instructions on screen. While waiting, open the door of the DGA monitor cabinet and locate the bleed plug.
5. When instructed to do so, remove the bleed plug from the bleed valve. Select **Continue** when done.



- When instructed to do so, reattach the bleed plug to the bleed valve. Select **Continue** when done.



- When the bleeding sequence is completed, select **Continue** to exit the tool.
- Close and lock the door of the DGA monitor cabinet.



Even if the bleeding tool does not complete successfully, you must reattach the bleed plug in any case before closing the door of the cabinet.

More information

- [Connecting to user interface \(page 30\)](#)

5.7 Installing the configuration package



- Configuration package file from Vaisala



Installing the configuration package is not possible when the device is measuring.

Installing the configuration package is only needed if requested by Vaisala.

1. If the device is measuring, stop measurement.
2. In the user interface go to **Service > Configuration package**.

3. Select **Install**.
4. Select **Browse** and locate the configuration package file that you received from Vaisala.
5. Select **Upload**.

The user interface informs you when the installation is completed.



If the installation fails, contact Vaisala helpdesk. You can download the diagnostics package and send it with your help request.

6. Technical specification

6.1 OPT100 technical specification

Table 14 OPT100 measurement specification

Parameter	Range	Accuracy ^{1) 2)}	Repeatability ²⁾
Methane (CH ₄)	0 ... 10 000 ppm _v	±4 ppm or ±5 % of reading	10 ppm or 5 % of reading
Ethane (C ₂ H ₆)	0 ... 10 000 ppm _v	±10 ppm or ±5 % of reading	10 ppm or 5 % of reading ³⁾
Ethylene (C ₂ H ₄)	0 ... 10 000 ppm _v	±4 ppm or ±5 % of reading	10 ppm or 5 % of reading
Acetylene (C ₂ H ₂)	0 ... 5000 ppm _v	±0.5 ppm or ±5 % of reading	1 ppm or 5 % of reading
Carbon monoxide (CO)	0 ... 10 000 ppm _v	±4 ppm or ±5 % of reading	10 ppm or 5 % of reading
Carbon dioxide (CO ₂)	0 ... 10 000 ppm _v	±4 ppm or ±5 % of reading	10 ppm or 5 % of reading
Hydrogen (H ₂)	0 ... 5000 ppm _v	±15 ppm or ±10 % of reading	15 ppm or 10 % of reading
Moisture ⁴⁾ (H ₂ O)	0 ... 100 ppm _w ⁵⁾	±2 ppm ⁶⁾ or ±10 % of reading	Included in accuracy
Total gas pressure	0 ... 2000 hPa	±10 hPa or ±2 % of reading	10 hPa or 5 % of reading

1) Accuracy specified is the accuracy of the sensors during calibration gas measurements.

2) Whichever is greater.

3) Repeatability of ethane measurement is specified with averaging of five measurements.

4) Measured as relative saturation (%RS).

5) Upper range limited to saturation.

6) Calculated ppm value is based on average solubility of mineral oils.

Table 15 OPT100 measurement operation

Property	Description/Value
Measurement cycle duration	1 ... 1.5 h (typical)
Response time (T63)	One measurement cycle ¹⁾
Warm-up time until first measurement data available	Two measurement cycles

Property	Description/Value
Initialization time to full accuracy	Two days
Data storage	At least 10 years
Expected operating life	> 15 years

1) Three cycles for ethane and hydrogen.

Table 16 OPTI00 field performance

Parameter	Typical variance to laboratory DGA ¹⁾
Acetylene (C ₂ H ₂)	±1 ppm or ±10 % of reading
Hydrogen (H ₂)	±15 ppm or ±15 % of reading
Other measured gases	±10 ppm or ±10 % of reading
Moisture (H ₂ O)	±2 ppm or ±10 % of reading

1) Compared with gas chromatography result from an oil sample considering also laboratory uncertainty. Performance of the gas-in-oil measurement may also be affected by oil properties and other chemical compounds dissolved in oil.

Table 17 OPTI00 calculated parameters

Property	Description/Value
Total dissolved combustible gases (TDCG)	Combined total of H ₂ , CO, CH ₄ , C ₂ H ₆ , C ₂ H ₄ , and C ₂ H ₂
24 h average	Available for single gases, moisture, TDCG, and total gas pressure
Rate of change (ROC)	Available for single gases and TDCG for 24 h, 7 d, and 30 d periods
Gas ratios ¹⁾	Available ratios: <ul style="list-style-type: none"> • CH₄/H₂ • C₂H₂/C₂H₄ • C₂H₂/CH₄ • C₂H₆/C₂H₂ • C₂H₄/C₂H₆ • CO₂/CO

1) Calculated from 24 h average values. See standard IEC 60599.

Table 18 OPT100 operating environment

Property	Description/Value
Transformer oil type	Mineral oil
Required minimum fire point ¹⁾ of transformer oil	+125 °C (+257 °F)
Transformer oil pressure at oil inlet	Max. 2 bar _{abs} continuous Burst pressure 20 bar _{abs}
Transformer oil temperature at oil inlet	Max. +100 °C (+212 °F)
Ambient humidity range	0 ... 100 %RH, condensing
Ambient temperature range in operation	-40 ... +55 °C (-40 ... +131 °F)
Storage temperature range	-40 ... +60 °C (-40 ... +140 °F)
IP rating	IP66: Dust-tight. Protected from powerful water jets from any direction.

1) *The fire point [of transformer oil] is normally approximately 10 °C [18 °F] higher than the closed flash point. See, for example, Heathcote, Martin J. The J & P Transformer Book. 13th ed. Elsevier, 2007.*

Table 19 OPT100 power supply

Property	Description/Value
Operating voltage	OPTPSU1: 100 ... 240 V AC, 50 ... 60 Hz, ±10 % OPTPSU2: 110 ... 220 V DC, ±10 %
Overvoltage category	III
Maximum power consumption	500 W
Typical power consumption at +25 °C (+77 °F)	100 W
Connector	Screw terminals (inside power supply unit) Wire size 2.5 ... 4 mm ² (14 ... 12 AWG)

Table 20 OPT100 outputs

Property	Description/Value
RS-485 interface	
Connector	Screw terminals (inside OPT100 housing) Wire size 0.5 ... 4 mm ² (20 ... 12 AWG)

Property	Description/Value
Supported protocols	Modbus RTU, DNP3 (optional feature)
Galvanic isolation	2 kV RMS, 1 min
Ethernet interface	
Connector	Industrial RJ45 connector with protective plug (outside OPT100 housing)
Supported protocols	Modbus TCP, HTTP, HTTPS, DNP3 (optional feature), IEC 61850 (optional feature)
Standard	IEEE 802.3
Physical layer	Base-T
Data rate	10/100 Mbps
Galvanic isolation	4 kV AC (50 Hz, 1 min)
Insulation voltage	250 V _{rms}
Relay outputs	
Number of relays	3 pcs, normally open (NO) or normally closed (NC), user selectable
Trigger type	Gas alert with user selectable limits
Connector	Screw terminals (inside power supply unit housing) Wire size 0.5 ... 4 mm ² (20 ... 12 AWG)
Max. switching current	6 A (at 250 V AC) 2 A (at 24 V DC) 0.2 A (at 250 V DC)
Min. switching voltage	12 V DC (at 10 mA)
Min. switching current	10 mA (at 12 V)
Contact type	1 PDT
Auxiliary device interface	
Maximum power	48 W
Voltage output	24 V DC
User interface	
Interface type	Web based user interface, can be operated with standard web browsers
Connector for service use	RJ45 connector, inside OPT100 housing (temporary local use only)

Table 21 OPT100 mechanical specifications

Property	Description/Value
Oil fitting	Stainless steel Swagelok® fitting for 10 mm (0.39 in) outer diameter tubing. See list of accessories for adapters available from Vaisala.
Max. length of oil pipe to transformer	Max. 10 m (33 ft) with 7 mm (0.28 in) inner diameter tubing Max. 5 m (16 ft) with 4 mm (0.15 in) inner diameter tubing
Recommended oil pipe properties	10 mm (0.39 in) outer diameter 1 ... 1.5 mm wall thickness Material stainless steel
Dimensions (H × W × D)	
Installed with ground mounting set and weather shield	1630 × 675 × 453 mm (64 × 27 × 18 in)
Installed with wall mounting set and weather shield	1390 × 675 × 467 mm (55 × 27 × 18 in)
Weight	
OPT100 DGA Monitor	35 kg (77 lb)
OPTPSU Power Supply Unit	12 kg (27 lb)
OPTMSET1 Wall mounting set	8 kg (18 lb)
OPTMSET2 Ground mounting set	16 kg (35 lb)
OPTSHLD1 Weather shield	6 kg (13 lb)
Materials	
OPT100 DGA Monitor housing	Marine aluminum (EN AW-5754), stainless steel AISI 316
OPTPSU Power Supply Unit housing	Stainless steel AISI 316
OPTMSET1 Wall Mounting Set	Stainless steel AISI 316
OPTMSET2 Ground Mounting Set	Stainless steel
OPTSHLD1 Weather Shield	Marine aluminum (EN AW-5754)
Materials in contact with oil	
Oil pipes, chambers, and valves	Aluminum (EN AW 6026), stainless steel AISI 316, brass
Gaskets and seals	NBR, FKM, FVMQ
Pump gears and bushing	PEEK/PTFE

1) *Bigger pipe volume will increase response time*

Table 22 OPT100 compliance

Property	Description/Value
EU directives and regulations	EMC Directive (2014/30/EU) Low Voltage Directive (2014/35/EU)
	OPT100 is specifically designed to be installed as part of another type of equipment that is excluded from the RoHS directive (2011/65/EU) scope.
EMC immunity	EN 61326-1, industrial environment IEC 61000-6-5, class 4
EMC emissions	FCC 47 CFR 15, section 15.107, class A ISED ICES-003, section 5(a)(i), class A
Safety	IEC/EN/UL/CSA 61010-1
Environmental	ISO 6270-1:2017, constant humidity condensation atmosphere, C5-M ISO 9227:2017, salt fog, C5-M IEC 61010-1:2010/AMD1:2016, pollution degree 4 (outdoor), 3 (industrial area), 2 (device internal)
Compliance marks	CE, China RoHS, EAC, RCM

6.2 OPT100 accessories and spare parts

Table 23 OPT100 accessories

Description	Part number
Wall Mounting Set	OPTMSET1
Ground Mounting Set	OPTMSET2
Weather Shield	OPTSHLD1
Tubing adapter, 10 mm to 3/8" (2 pcs)	ASM213275SP
Tubing adapter, 10 mm to 1/4" (2 pcs)	ASM213274SP

Table 24 OPT100 spare parts

Description	Part number
Power Supply Unit	OPTPSU1 (AC power)
Internal Multigas Transmitter (MHT411)	MHT411SP

Description	Part number
Solenoid valves	OPTVALVEKITSP

6.3 Dimensions with Ground Mounting Set




Figure 45 OPT100 dimensions with Ground Mounting Set

6.4 Dimensions with Wall Mounting Set




Figure 46 OPT100 dimensions with Wall Mounting Set




Figure 47 Mounting dimensions of installation beams

Appendix A. Modbus reference

A.1 Default Modbus communication settings

Table 25 Modbus TCP communication settings

Property	Specification
IP address of Modbus server	IP address of DGA monitor on interface ETH0
Modbus server port	502

Table 26 Default Modbus RTU communication settings

Property	Specification
Baud rate	19200
Parity	Even
Data bits	8
Stop bits	1
Modbus RTU slave address	240

A.2 Function codes

Table 27 Supported function codes

Function code (decimal)	Function code (hexadecimal)	Name
03	03 _{hex}	Read Holding Registers

A.3 32-bit floating point or 32-bit integer format

Registers using **32-bit float** data format are encoded using the **binary32** encoding defined in IEEE 754. The format is also known as "single-precision floating point format".

The least significant 16 bits of a floating point number are placed at the Modbus register listed in the table, while the most significant 16 bits are placed in the register with number/address + 1, as specified in Open Modbus TCP Specification, Release 1.0. This is also known as "little-endian" or "Modicon" word order.

Despite the specification, some Modbus masters may expect a "big-endian" word order (most significant word first). In such case, you must select "word-swapped" floating point format in your Modbus master for the Modbus registers of the device.

A complete 32-bit floating point or 32-bit integer value should be read and written in a single Modbus transaction.



CAUTION! Reading the measurement data registers with incorrect floating point format setting may occasionally result in correct-looking, but nevertheless incorrect values.



It is highly recommended to verify that you have configured the floating point format correctly on your Modbus host system by reading a floating point value from a test value register.

A.4 Modbus registers

Registers are numbered in decimal, starting from 1. Register addresses in actual Modbus messages (Modbus Protocol Data Unit (PDU)) are in hexadecimal and start from zero. Register number 1 corresponds to address 0_{hex} in the actual Modbus message.



CAUTION! Reading the wrong register(s) may result in correct-looking values. Check the reference documentation of your Modbus host (PLC) to verify which notation it uses for Modbus register addresses.

A.4.1 Measurement data registers

Table 28 Measurement data registers (read-only)

Register number	Address	Register description	Data format	Unit and notes
Present values				
21	0014 _{hex}	Methane	32-bit float	ppm _v
	0015 _{hex}			
23	0016 _{hex}	Acetylene	32-bit float	ppm _v
	0017 _{hex}			
25	0018 _{hex}	Ethylene	32-bit float	ppm _v
	0019 _{hex}			
27	001A _{hex}	Ethane	32-bit float	ppm _v
	001B _{hex}			

Register number	Address	Register description	Data format	Unit and notes
29	001C _{hex}	Carbon monoxide	32-bit float	ppm _v
	001D _{hex}			
31	001E _{hex}	Carbon dioxide	32-bit float	ppm _v
	001F _{hex}			
33	0020 _{hex}	Total dissolved combustible gases (TDCG)	32-bit float	ppm _v
	0021 _{hex}			
35	0022 _{hex}	Hydrogen	32-bit float	ppm _v
	0023 _{hex}			
37	0024 _{hex}	Moisture in oil	32-bit float	ppm _w
	0025 _{hex}			
39	0026 _{hex}	Temperature of in-oil measurement chamber	32-bit float	°C
	0027 _{hex}			
41	0028 _{hex}	Relative moisture in oil See Calculating relative moisture saturation inside transformer (page 14)	32-bit float	%RS
	0029 _{hex}			
43	002A _{hex}	Total gas pressure (TGP)	32-bit float	hPa
	002B _{hex}			
24 hour average values				
51	0032 _{hex}	Methane	32-bit float	ppm _v
	0033 _{hex}			
53	0034 _{hex}	Acetylene	32-bit float	ppm _v
	0035 _{hex}			
55	0036 _{hex}	Ethylene	32-bit float	ppm _v
	0037 _{hex}			
57	0038 _{hex}	Ethane	32-bit float	ppm _v
	0039 _{hex}			

Register number	Address	Register description	Data format	Unit and notes
59	003A _{hex}	Carbon monoxide	32-bit float	ppm _v
	003B _{hex}			
61	003C _{hex}	Carbon dioxide	32-bit float	ppm _v
	003D _{hex}			
63	003E _{hex}	Total dissolved combustible gases (TDCG)	32-bit float	ppm _v
	003F _{hex}			
65	0040 _{hex}	Hydrogen	32-bit float	ppm _v
	0041 _{hex}			
67	0042 _{hex}	Moisture in oil	32-bit float	ppm _w
	0043 _{hex}			
69	0044 _{hex}	Total gas pressure (TGP)	32-bit float	hPa
	0045 _{hex}			
Rate of change (ROC), 24 hour				
81	0050 _{hex}	Methane	32-bit float	ppm _v /d
	0051 _{hex}			
83	0052 _{hex}	Acetylene	32-bit float	ppm _v /d
	0053 _{hex}			
85	0054 _{hex}	Ethylene	32-bit float	ppm _v /d
	0055 _{hex}			
87	0056 _{hex}	Ethane	32-bit float	ppm _v /d
	0057 _{hex}			
89	0058 _{hex}	Carbon monoxide	32-bit float	ppm _v /d
	0059 _{hex}			
91	005A _{hex}	Carbon dioxide	32-bit float	ppm _v /d
	005B _{hex}			
93	005C _{hex}	Total dissolved combustible gases (TDCG)	32-bit float	ppm _v /d
	005D _{hex}			

Register number	Address	Register description	Data format	Unit and notes
95	005E _{hex}	Hydrogen	32-bit float	ppm _v /d
	005F _{hex}			
Rate of change (ROC), 7 days				
101	0064 _{hex}	Methane	32-bit float	ppm _v /w
	0065 _{hex}			
103	0066 _{hex}	Acetylene	32-bit float	ppm _v /w
	0067 _{hex}			
105	0068 _{hex}	Ethylene	32-bit float	ppm _v /w
	0069 _{hex}			
107	006A _{hex}	Ethane	32-bit float	ppm _v /w
	006B _{hex}			
109	006C _{hex}	Carbon monoxide	32-bit float	ppm _v /w
	006D _{hex}			
111	006E _{hex}	Carbon dioxide	32-bit float	ppm _v /w
	006F _{hex}			
113	0070 _{hex}	Total dissolved combustible gases (TDCG)	32-bit float	ppm _v /w
	0071 _{hex}			
115	0072 _{hex}	Hydrogen	32-bit float	ppm _v /w
	0073 _{hex}			
Rate of change (ROC), 30 days				
121	0078 _{hex}	Methane	32-bit float	ppm _v /m
	0079 _{hex}			
123	007A _{hex}	Acetylene	32-bit float	ppm _v /m
	007B _{hex}			
125	007C _{hex}	Ethylene	32-bit float	ppm _v /m
	007D _{hex}			
127	007E _{hex}	Ethane	32-bit float	ppm _v /m
	007F _{hex}			

Register number	Address	Register description	Data format	Unit and notes
129	0080 _{hex}	Carbon monoxide	32-bit float	ppm _v /m
	0081 _{hex}			
131	0082 _{hex}	Carbon dioxide	32-bit float	ppm _v /m
	0083 _{hex}			
133	0084 _{hex}	Total dissolved combustible gases (TDCG)	32-bit float	ppm _v /m
	0085 _{hex}			
135	0086 _{hex}	Hydrogen	32-bit float	ppm _v /m
	0087 _{hex}			
Gas ratios (24 hour average values)				
141	008C _{hex}	CH ₄ /H ₂	32-bit float	-
	008D _{hex}			
143	008E _{hex}	C ₂ H ₂ /C ₂ H ₄	32-bit float	-
	008F _{hex}			
145	0090 _{hex}	C ₂ H ₂ /CH ₄	32-bit float	-
	0091 _{hex}			
147	0092 _{hex}	C ₂ H ₆ /C ₂ H ₂	32-bit float	-
	0093 _{hex}			
149	0094 _{hex}	C ₂ H ₄ /C ₂ H ₆	32-bit float	-
	0095 _{hex}			
151	0096 _{hex}	CO ₂ /CO	32-bit float	-
	0097 _{hex}			
Other				
161	00A0 _{hex}	Time stamp of measurement result set, in seconds since start of Unix epoch	64-bit float (double)	s
	00A1 _{hex}			
	00A2 _{hex}			
	00A3 _{hex}			
165	00A4 _{hex}	Index of measurement result set	32-bit integer	-
	00A5 _{hex}			

Register number	Address	Register description	Data format	Unit and notes
Custom averages				
171	00AA _{hex}	Methane	32-bit float	ppm _v
	00AB _{hex}			
173	00AC _{hex}	Acetylene	32-bit float	ppm _v
	00AD _{hex}			
175	00AE _{hex}	Ethylene	32-bit float	ppm _v
	00AF _{hex}			
177	00B0 _{hex}	Ethane	32-bit float	ppm _v
	00B1 _{hex}			
179	00B2 _{hex}	Carbon monoxide	32-bit float	ppm _v
	00B3 _{hex}			
181	00B4 _{hex}	Carbon dioxide	32-bit float	ppm _v
	00B5 _{hex}			
183	00B6 _{hex}	Total dissolved combustible gases (TDCG)	32-bit float	ppm _v
	00B7 _{hex}			
185	00B8 _{hex}	Hydrogen	32-bit float	ppm _v
	00B9 _{hex}			
187	00BA _{hex}	Moisture in oil	32-bit float	ppm _w
	00BB _{hex}			

A.4.2 Alert registers

Gas level alert registers are 16-bit fields. Each register communicates the status of alerts of specific severity for a particular timeframe (for example, gas level caution alerts for present values).

If an alert is active, the corresponding bit is set to 1. The bit is set to 0 when the alert is deactivated, turned off, or gas level alerts are muted. For more information, see [Gas level alerts \(page 24\)](#).

Table 29 Alert registers (read-only)

Register number	Address	Register description	Data format	Bit order
11	000A _{hex}	Gas level caution alerts for present values	16-bit field	0 = Methane 1 = Acetylene 2 = Ethylene 3 = Ethane 4 = Carbon monoxide 5 = Carbon dioxide 6 = TDCG 7 = Hydrogen 8 = Moisture in oil 9 = Relative moisture in oil 11 = TGP above maximum limit 12 = TGP below minimum limit
12	000B _{hex}	Gas level caution alerts for 24 hour average ROC values	16-bit field	0 = Methane 1 = Acetylene 2 = Ethylene 3 = Ethane 4 = Carbon monoxide 5 = Carbon dioxide 6 = TDCG 7 = Hydrogen

Register number	Address	Register description	Data format	Bit order
13	000C _{hex}	Gas level caution alerts for 7 day average ROC values	16-bit field	0 = Methane 1 = Acetylene 2 = Ethylene 3 = Ethane 4 = Carbon monoxide 5 = Carbon dioxide 6 = TDCG 7 = Hydrogen
14	000D _{hex}	Gas level caution alerts for 30 day average ROC values	16-bit field	0 = Methane 1 = Acetylene 2 = Ethylene 3 = Ethane 4 = Carbon monoxide 5 = Carbon dioxide 6 = TDCG 7 = Hydrogen
15	000E _{hex}	Gas level alarms for present values	16-bit field	0 = Methane 1 = Acetylene 2 = Ethylene 3 = Ethane 4 = Carbon monoxide 5 = Carbon dioxide 6 = TDCG 7 = Hydrogen 8 = Moisture in oil 9 = Relative moisture in oil 11 = TGP above maximum limit 12 = TGP below minimum limit

Register number	Address	Register description	Data format	Bit order
16	000F _{hex}	Gas level alarms for 24 hour average ROC values	16-bit field	0 = Methane 1 = Acetylene 2 = Ethylene 3 = Ethane 4 = Carbon monoxide 5 = Carbon dioxide 6 = TDCG 7 = Hydrogen
17	0010 _{hex}	Gas level alarms for 7 day average ROC values	16-bit field	0 = Methane 1 = Acetylene 2 = Ethylene 3 = Ethane 4 = Carbon monoxide 5 = Carbon dioxide 6 = TDCG 7 = Hydrogen
18	0011 _{hex}	Gas level alarms for 30 day average ROC values	16-bit field	0 = Methane 1 = Acetylene 2 = Ethylene 3 = Ethane 4 = Carbon monoxide 5 = Carbon dioxide 6 = TDCG 7 = Hydrogen

A.4.3 Status registers

Only the first bit of each status bit field is used.

Table 30 Status registers (read-only)

Register number	Address	Register description	Data format	Notes
1	0000 _{hex}	Device stopped	16-bit field	0 = Device measuring normally 1 = Device stopped (either automatically or by administrator), being initialized, or being uninstalled
3	0002 _{hex}	Measurement reliability	16-bit field	0 = Measurement is unreliable because of high ambient temperature 1 = Measurement is reliable
4	0003 _{hex}	Gas alerts muted	16-bit field	0 = Gas level alerts operating normally 1 = Gas level alerts muted

A.4.4 Test value registers

Read the known test values from the test registers to verify the functionality of your Modbus implementation.

Table 31 Test value registers (read-only)

Register number	Address	Data format	Test value
201	00C8 _{hex}	16-bit unsigned integer	12345
202	00C9 _{hex}	32-bit unsigned integer	1234567890
	00CA _{hex}		
204	00CB _{hex}	64-bit unsigned integer	1234567890123456789
	00CC _{hex}		
	00CD _{hex}		
	00CE _{hex}		
208	00CF _{hex}	16-bit integer	-12345
209	00D0 _{hex}	32-bit integer	-1234567890
	00D1 _{hex}		

Register number	Address	Data format	Test value
211	00D2 _{hex}	64-bit integer	-1234567890123456789
	00D3 _{hex}		
	00D4 _{hex}		
	00D5 _{hex}		
215	00D6 _{hex}	32-bit float	1.23456
	00D7 _{hex}		
217	00D8 _{hex}	64-bit float	1.23456789
	00D9 _{hex}		
	00DA _{hex}		
	00DB _{hex}		

A.5 Exception responses

Table 32 Modbus exception responses

Code	Name	Reason
01	ILLEGAL FUNCTION	Unsupported function code
02	ILLEGAL DATA ADDRESS	Register address or Object ID out of valid ranges
03	ILLEGAL DATA VALUE	Otherwise invalid request

Accessing unavailable (temporarily missing) measurement data does not generate a Modbus exception. “Unavailable” value (a quiet NaN for floating point data or 8000_{hex} for integer data) is returned instead. An exception is generated only for any access outside the applicable register ranges.

A.6 Modbus communication examples

Reading acetylene value



Device address used in the following examples is 240 (F0_{hex}).
The values returned by the device differ depending on the measurement conditions. Your device may not return the same values.

Request	
Bytes on the line (hexadecimal)	Description
(silence for > 3.5 bytes)	Start of Modbus RTU frame
F0 _{hex}	OPT100 address
03 _{hex}	Function (Read Holding Registers)
00 _{hex}	Register address (Acetylene)
16 _{hex}	
00 _{hex}	Number of 16-bit registers to read (2)
02 _{hex}	
30 _{hex}	Modbus RTU checksum
EE _{hex}	
(silence for > 3.5 bytes)	End of Modbus RTU frame

Response	
Bytes on the line (hexadecimal)	Description
(silence for > 3.5 bytes)	Start of Modbus RTU frame
F0 _{hex}	OPT100 address
03 _{hex}	Function (Read Holding Registers)
04 _{hex}	Number of data bytes
40 _{hex}	Value of first register (least significant word)
40 _{hex}	
00 _{hex}	Value of second register (most significant word)
00 _{hex}	

Response	
0E _{hex}	Modbus RTU checksum
E8 _{hex}	
(silence for > 3.5 bytes)	End of Modbus RTU frame

Communication description	
Register number	23 (1-based Modbus register number) = address 0016 _{hex} (0-based address used in actual communication).
Data format	Two 16-bit Modbus registers interpreted as IEEE 754 binary32 floating point value, least significant word first.
Returned value	40400000 _{hex} , which is binary32 representation of 3 (ppm).

Index

A

accessories.....	97
alert indicator.....	33
autocalibration.....	28, 53
starting.....	73

B

bleeding.....	88
---------------	----

C

calculated parameters.....	13
calibration.....	
cleaning.....	70
configuration package.....	90
connecting to user interface.....	30
custom averages.....	67

D

date and time.....	50
delete data.....	68
device alerts.....	83
device error.....	86
device name.....	49
DGA diagnostics	
data point selection.....	40
Duval triangles.....	38
diagnostic data file.....	44
diagnostics.....	88
dimensions.....	99, 100
DNP3 protocol.....	25
configuring.....	60

F

features.....	12
---------------	----

G

gas level alerts.....	41
activation.....	24
alarm.....	108

caution.....	108
configuring.....	54
deactivation.....	24
muting.....	55
graphs.....	35

I

IEC 61850.....	26
IEC 61850 protocol	
configuring.....	61

M

maintenance.....	
remote access.....	71
software update.....	71
turning off.....	74
turning on.....	75
measured parameters.....	13
measurement.....	35
starting.....	49, 75
stopping.....	74
messages	
errors.....	33
gas level alerts.....	33
Modbus	
status registers.....	112
Modbus protocol.....	25, 59
communication examples.....	114
function codes.....	102
gas level alerts.....	108
measurement data.....	103
Modbus RTU communication settings.....	102
Modbus TCP communication settings.....	102
test value registers.....	112

N

normal operation.....	15
-----------------------	----

O

offset.....	65
options.....	12
OSS licenses.....	46

P

parts	
cable glands.....	20, 21
connectors.....	20, 21
ground mounting set.....	16
interior.....	22
wall mounting set.....	18
password.....	47
protocol test mode.....	27, 62

R

relative saturation.....	14
relays.....	64
repair.....	73
safety.....	74

S

safety.....	70, 74
serial line.....	59
software update.....	71
spare parts.....	97
standby mode.....	74
starting measurement.....	49, 75
status indicator.....	32
status LEDs.....	23
stopping measurement.....	74
system status.....	82

T

technical specification.....	92
total gas pressure.....	14, 52
troubleshooting.....	81
turning off.....	74
turning on.....	75

U

uninstalling.....	76
units.....	52
user interface.....	30, 32
about page.....	46
alerts page.....	41
control page.....	43
DGA diagnostics page.....	38
general page.....	50
network page.....	56
settings pages.....	46

V

viewing data.....	35
-------------------	----

Maintenance and calibration services



Vaisala offers comprehensive customer care throughout the life cycle of our measurement instruments and systems. Our factory services are provided worldwide with fast deliveries. For more information, see www.vaisala.com/calibration.

- Vaisala Online Store at store.vaisala.com is available for most countries. You can browse the offering by product model and order the right accessories, spare parts, or maintenance and calibration services.
- To contact your local maintenance and calibration expert, see www.vaisala.com/contactus.

Technical support



Contact Vaisala technical support at helpdesk@vaisala.com. Provide at least the following supporting information as applicable:

- Product name, model, and serial number
- Software/Firmware version
- Name and location of the installation site
- Name and contact information of a technical person who can provide further information on the problem

For more information, see www.vaisala.com/support.

Warranty

For standard warranty terms and conditions, see www.vaisala.com/warranty.

Please observe that any such warranty may not be valid in case of damage due to normal wear and tear, exceptional operating conditions, negligent handling or installation, or unauthorized modifications. Please see the applicable supply contract or Conditions of Sale for details of the warranty for each product.

Recycling



Recycle all applicable material according to local regulations.

VAISALA

www.vaisala.com

