# APPLICATION NOTE

MAESTRO FIRMWARE UPDATE PROCEDURE

ALWAYS KEEP YOUR MAESTRO UP TO DATE TO TAKE ADVANTAGE OF ALL THE NEW FUNCTIONALITIES

FOLLOW THIS EASY STEP-BY-STEP UPDATE PROCEDURE

1. Download the update file from the website at:
   http://gentec-eo.com/downloads/software-firmware
   in the Firmware tab

2. Save it to a known location on your PC (like your desktop)

3. Unzip the file:

   3.1 Locate the ZIP file on your computer
   3.2 Right-click on it and choose "Extract All..."
   3.3 Follow the instructions on the screen
   3.4 Locate the extracted folder and open it
   3.5 You should now see the BIN file

MONITORS

ENERGY DETECTORS

POWER DETECTORS

HIGH POWER DETECTORS

PHOTO DETECTORS

THZ DETECTORS

OEM DETECTORS

SPECIAL PRODUCTS

BEAM DIAGNOSTICS

APPLICATION NOTE

MONITORS

ENERGY DETECTORS

POWER DETECTORS

HIGH POWER DETECTORS

PHOTO DETECTORS

THZ DETECTORS

OEM DETECTORS

SPECIAL PRODUCTS

BEAM DIAGNOSTICS

4.   Copy the BIN file on a USB key, directly in the main folder (not in a sub-folder)

5.   Plug the USB key in the MAESTRO

6.   Go to **HOME**

7.   **ABOUT**

8.   Press the **Update** button

9.   Wait for the MAESTRO to do the update sequence

10. When the reboot message appears, turn off the MAESTRO

11. Wait a few seconds

12. Turn it on again and the update will be done

13. If you want to check the update has been done, go in **HOME** – **About** again and verify that the firmware version corresponds to the initial update file