



ECRN-50 LOW-RESOLUTION RAIN GAUGE INSTALLATION INSTRUCTIONS

18302-03
10.1.2021

METER

Preparation

Inspect and verify that ECRN-50 components are intact. Installation will require a mounting pole and mounting supplies (e.g., zip ties, wire). Most accurate rain gauge measurements are obtained through installations close to the ground or plant canopy and with a wind shield around the rain gauge to minimize rainfall under-catch from wind blowing across the rain gauge intake. However, this is not always practical, especially if objects above the rain gauge could shield it from receiving representative rainfall.

Set up and test the system (sensors and data loggers) in a lab or office. Ensure the data loggers are using up-to-date firmware and software. Check the following locations for firmware and software updates:

ZL6 metergroup.com/zl6-support
Other metergroup.com/environment/articles/buy-browse-meter-legacy-data-loggers

Read the ECRN-50 specifications at metergroup.com/ecrn-50.

Resolution	Volume Per Tip	Rainfall Per Tip
1 tip	5.0 ml/tip	1 mm

All products have a 30-day satisfaction guarantee.

Installation

Mount the ECRN-50 so the metal back is vertical against a mounting pole at the desired height and ensure the rain gauge is level. Plug the sensor cable into the data logger. Use data logger software to apply appropriate settings to the sensors plugged into each data logger port. Gather and secure the cables to the mounting pole in one or more places to relieve strain on the connections.

METER Group, Inc. USA
2365 NE Hopkins Court, Pullman, WA 99163
T +1.509.332.2756 F +1.509.332.5158
E info@metergroup.com W metergroup.com

NORTH AMERICA
E support.environment@metergroup.com
T +1.509.332.5600

EUROPE
E support.europe@metergroup.com
T +49 89 12 66 52 0

